

Common Covered Task 003

Test Breakout Tank Overfill Protective Devices

Directions

This training guide is to be used by a Veriforce Authorized Evaluator/Trainer and Trainee during on-the-job training (OJT) or prior to an evaluation as a resource. (S) Indicates a demonstration or skill task; (K) indicates a knowledge task.

OJT Reminder

OJT is an active hands-on process. Practice should be as similar to the actual job task as possible. However, if the training is being provided on an actual job site while a covered task is actually being performed, the Evaluator either needs to be qualified on that covered task or be assisted by someone who is qualified on the covered task. The Evaluator should closely monitor the Trainee's practices to ensure safe and correct task performance. At no time should a non-qualified individual perform, or train for, a covered task unless directed and observed by a qualified individual. However, if the *"span of control"* for that particular covered task is "1:0" (requiring only qualified individuals to perform the covered task), the training must be simulated. Training is simulated by "walking through" the task and simulating all actual manipulations (valves, switches, tools, etc.) an individual would use during the performance of a covered task. Simulating includes the use of safety and administrative requirements as if the task were being performed live. Refer to the Veriforce Evaluator Training Program for more on how to conduct formal OJT.

Disclaimer

This training resource is offered in good faith. Anyone choosing to utilize or rely on this training resource is doing so at their own discretion, risk and choice. Although every attempt has been made by Veriforce, LLC (the "Company") to ensure the correctness and suitability of this document and to correct any errors brought to the attention of the Company, the Company makes no representation or warranty regarding correctness or suitability (either directly or indirectly) of information referenced or implied within this training resource.

In no event shall the Company be liable for any damages (including, but not limited to, special, incidental or consequential damages) whatsoever (including, but not limited to, death, personal injury, damage to person or property, loss of use, and/or loss of revenues), whether in an action of contract, negligence, or other action, arising out of or in any way associated with the use or misuse of this document.

All critical information should be independently verified by the user and the user shall not rely on the contents provided herein without such independent verification. The subject matter included in this training has been compiled from a variety of sources and is subject to change without notice. The Company reserves the right to add, remove and alter information contained in this document without notice.

The Company may provide links to other sites for your convenience; however, the Company takes no responsibility and makes no representation or warranty regarding the accuracy or currency of information contained within such sites. The Company does not endorse any information, goods, or services referred to within such sites, and the provision of links by the Company shall not be interpreted to be an endorsement of such information, goods or services. The content of this training resource is provided for personal use only, and all other use, copying or reproduction of this training or website or any part of it is prohibited.

Common Covered Task 003 Test Breakout Tank Overfill Protective Devices

Recommended Student Training or Resources:

- DOT 49 CFR 195.428

Introduction

An overfill protection device is a device used to prevent overfill or alert breakout tank operators that fluid level in the tank has reached a potentially dangerous level. Some devices can simply activate an alarm, while others may be able to shut down any flow into the breakout tank automatically with no operator interaction.

Knowledge: Explain what is required prior to performing this task.

Pipeline Operator-Approved Procedures and Appropriate Equipment/Material

Prior to performing this task, you will need to have the pipeline operator-approved procedures as well as the appropriate equipment and materials. The procedures will outline requirements for performing this task that are specific to the pipeline operator. Operators may also have specific requirements regarding the type of equipment that can be used to perform this task.

Therefore, it's important to follow the specific requirements of the procedures and only use operator-approved equipment. Doing so can ensure the task is performed correctly and according to the pipeline operator's standards.

Knowledge: Explain the key indicators used in categorizing breakout tank overfill protection systems.

Breakout tank overfill protection is divided into categories. The categories classify breakout tank facilities based on certain characteristics of the facility's overfill protection.

Category 1

Category 1 facilities are operated manually. Meaning that an individual must physically be at the tank to control fluid transfers in and out of the tank.

Breakout tanks at category 1 facilities either have to be measured or **strapped** manually for volume or may be equipped with some sort of automatic tank gauging system (ATGS), such as a ball float-operated volume meter.

The overfill protection for a category 1 breakout tank facility is totally dependent on the local tank operator. If there are no alarms, the operator will have to pay close attention to the amount of fluid that is entering the breakout tank. The operator will have to manually stop the fluid from entering the breakout tank to prevent overfill.

Category 2

Category 2 facilities can be run either manually or remotely or through a combination of the two. If a local operator is not present at a category 2 breakout tank, then an operator in a control room should be able to control the flow of fluid in and out of the tank.

Category 2 facilities should be using an ATGS for measuring fluid levels in the tank. The ATGS should also have an alarm. The alarm can be a light, siren, or combination of the two that activates when a dangerous fluid level is reached.

Category 3

Category 3 breakout tank facilities are very similar to category 2. They can be operated both locally at the tank and remotely from a control center.

Category 3 facilities will also have ATGS with alarms that should activate when a predetermined fluid level is reached inside the tank, just like category 2 facilities.

The difference between the two categories is that category 3 facilities must have an independent alarm system when the high-high fluid level of concern is reached. (Fluid levels of concern will be covered in our next objective.) This alarm is in addition to the ATGS and any other alarms associated with the ATGS. Having two different independent systems creates redundancy in the breakout tank's overflow protection. This means that should the ATGS fail for some reason, the additional high-high level alarm should continue to function.

AOPS

Many breakout tank operators believe there should be a fourth category for an automatic overflow protection system (or AOPS). An AOPS would more than likely be combined with category 2 or category 3 facility overflow protection systems. The AOPS can completely control the flow of fluid in and out of the tank, meaning that in the event of an overflow condition, the system will stop flow. The AOPS does not require an operator to perform this function. If the entire breakout tank facility is equipped with an AOPS, then there is no need for that facility to be manned.

The AOPS should be independent and in addition to any other systems, such as the ATGS, just like in category 3 facilities. This way, should the ATGS fail, the AOPS will continue to function and operate in an overflow situation.

Knowledge: Identify the levels of concern used for breakout tank overflow protection systems.

Levels of concern (or LOCs) are the fluid levels in a breakout tank that are predetermined for normal operations and possible hazardous conditions. One of the main considerations when determining the levels of concern for a breakout tank is the response time of the breakout tank facility personnel to respond to an overflow situation. The following are some of the generally used levels of concern.

Maximum Working Level

The maximum working level is the maximum amount of fluid that the breakout tank should be filled to during normal tank operations. If needed, a breakout tank facility operator may need to check the ATGS or strap the tank to see if this level has been reached. Depending on the facility, there may or may not be an alarm or indicator that would activate if the LOC has been reached.

High-High Level

The high-high LOC is the first level at which category 2 and category 3 facilities need to have some sort of alarm indicating this level has been reached. For clarification of what to do if this level is reached, consult with the pipeline operator representative or pipeline operator procedures for the actions that may need to be taken to prevent further fluid from entering the breakout tank. An example of a breakout tank operator action could be the manual closing of the valve used to fill the tank with fluid.

AOPS (Optional Level)

As mentioned earlier in the course, some category 2 and 3 breakout tank facilities may have breakout tanks equipped with an AOPS. If an AOPS is in place, it may have its own LOC. If the breakout tank does have an

AOPS LOC, then the system will begin to operate at this level. The independent AOPS alarm should register at this level, and the AOPS should automatically stop flow coming into the breakout tank.

Critical High Level

At this level, overflow is likely to occur. Besides damage to the breakout tank, injury to operator personnel and impact to the environment could occur. Another alarm should sound at this level. Emergency overflow procedures must be consulted and activated when this level is reached.

Skill: Determine the steps to follow in testing overflow protection devices.

Overflow devices, just like any other mechanical equipment, need to be maintained and tested. When testing the overflow devices on your breakout tanks, always follow the pipeline operator's procedures and manufacturer's specifications for the overflow devices in your facility.

Before testing any devices, make sure the equipment can function and is in good mechanical condition. One possible issue could be corrosion on the parts of the overflow protection devices that are exposed to a corrosive environment or to the fluid inside the breakout tanks.

Some overflow devices will have moving components. If scratches, dents, or gouges on these components are present, this could be an indication of a mechanical issue that could affect the device's ability to move.

Federal regulations require that inspections are not to exceed 15 months, but must occur at least once each calendar year. Highly volatile liquid service breakout tanks require inspections not to exceed 7.5 months, but must occur at least twice each calendar year.

When it comes to the actual testing of the overflow devices at your facility, make sure you follow the pipeline operator-approved procedures for testing the devices. Devices may vary from facility to facility and even tank to tank.

The most reliable way for testing any overflow device is a full wet test. With this test, the tank needs to be filled with fluid to the different levels of concern to see if the overflow protection devices respond accordingly. The issues with this method are the possibilities of actually overflowing the breakout tank and the time it would take to fill tanks to these levels.

One possible testing method of overflow protection devices that have movable parts is to manually move the parts to see if the alarms trigger. For example, you could raise a float detector manually to the desired level of concern to see if the overflow protection system (or OPS) responds. Also, if the overflow device uses fluid-sensing equipment, you may be able to test it by using a wet probe to contact the fluid-sensing area of the device.

Many OPS in use for category 2 and 3 facilities have built-in proof-testing methods. These testing methods could range from a simple push button test to switching relays around inside the controlling device to simulate the alarms. Regardless of the testing method, it is extremely important to make sure the equipment is capable of activating alarms, shutting down, or isolating a breakout tank to prevent an overflow condition. Once again when asked to test the OPS, follow your pipeline operator's procedures for the OPS on the breakout tank you're testing.

Abnormal Operating Conditions (AOCs)

Candidates are required to possess the ability to **RECOGNIZE** and **REACT** to the listed AOCs for each task. Be prepared to answer questions concerning additional AOCs that may be relevant. Evaluators may ask questions about AOCs throughout the evaluation.

An AOC is defined in **49 CFR §§ 192.803** and **195.503** as:

A condition identified by the pipeline operator that may indicate a malfunction of a component or deviation from normal operations that may:

- Indicate a condition exceeding design limits; or
- Result in a hazard(s) to persons, property, or the environment.

Recognize: Unintentional releases, vapors, or hazardous atmosphere could be signs that an abnormal operating condition has occurred. Examples could include, but are not limited to:

- Puddles
- Ice accumulation
- Vapors

React/Respond: Proper reactions and/or responses to take in the event of an unintentional release, vapors, or hazardous atmosphere include the following:

- Eliminate potential ignition sources.
- Move to a safe location.
- Notify emergency response personnel, as appropriate.
- Notify designated pipeline operator representative.

Recognize: Material defects, anomalies, or physical damage of a pipe or component are abnormal operating conditions. Examples could include, but are not limited to:

- Broken/damaged components
- Plugged devices
- Corrosion

React/Respond: Proper reactions/responses to take in the event of material defects, anomalies, or physical damage of a pipe or component include the following:

- Stop activity and notify the designated pipeline operator representative.
- Mark the location so it may be easily located.

Recognize: An unintended fire and/or explosion on or near the facility is an abnormal operating condition.

React/Respond: Proper reactions/responses to take in the event of an unintended fire and/or explosion on or near the facility include the following:

- Move to a safe location.
- Notify emergency response personnel, as appropriate.
- Notify the designated pipeline operator representative.

Recognize: Failure or malfunction of facility component(s) is an abnormal operating condition. Examples could include, but are not limited to:

- Alarm/lights failure
- Instrumentation failure
- Leaking tubing
- Unexpected relief valve operation

React/Respond: Proper reactions/responses to take in the event of failure or malfunction of facility component(s) include the following:

- Stop activity.

- Notify the designated pipeline operator representative.

Glossary

AOC

abnormal operating condition

CCT

common covered task

CFR

Code of Federal Regulations