

# Choosing Agglomeration Equipment

A product's intended use often dictates what type of agglomeration equipment should be used. Presented here is a discussion of the main types of equipment and methods for forming agglomerates

**A**gglomeration is the process of converting fine powder particles into larger ones through the introduction of external forces. Agglomeration offers numerous benefits for bulk solids processors, including significant dust reduction, improved handling, more complete utilization of raw materials and densification. Agglomeration can be accomplished by a variety of means, including mixing with a liquid, applying pressure and heating.

This article describes various technologies available for particle size enlargement. The technologies fall into three general categories: (1) tumble-growth agglomeration, (2) pressure agglomeration, and (3) agglomeration by heating or sintering. Tumble-growth agglomeration includes both wet and dry methods. Stresses developed in pressure agglomeration equipment can range from moderate to extreme. For some materials, agglomeration by heating or sintering can be accomplished at relatively moderate temperatures. An end product's intended use often dictates what type of agglomeration equipment should be used.

## General principles

Tumble-growth agglomeration equipment tends to have lower capital costs than the other methods, but costs may be higher if drying is required. Agglomerates produced by tumble-growth technologies tend to have a lower bulk density and a wider particle size distribution as compared to other agglomeration methods. Binders frequently must be added to ensure that "green" (that is, wet) or dry agglomerates have sufficient strength.

Pressure agglomeration equipment, as well as equipment that agglomerate particles by heat or sintering, tend to have higher cap-



Feeco International

**Greg Mehos**

University of Rhode Island

**Chris Kozicki**

Feeco International

## IN BRIEF

GENERAL PRINCIPLES

TUMBLE-GROWTH AGGLOMERATION

PRESSURE AGGLOMERATION

TEMPERATURE AND SINTERING


HANDLING AGGLOMERATED PRODUCTS

FINAL REMARKS

**FIGURE 1.** This disk pelletizer is an example of a tumble-growth wet agglomeration technology, in which fine particles are wetted with a liquid, usually water

ital costs, but lower operating costs. The agglomerates formed by these methods have a higher bulk density, but they may be prone to attrition if the pellets that are produced have sharp edges.

Particles are held together by a number of mechanisms. Solid bridges between particles can be the result of sintering, partial melting and recrystallization during drying. Binders that readily adhere to solid particles are effective agglomerating aids. Liquid bridges in spaces between individual particles can form strong agglomerates as a result of capillary forces that develop when the voids are completely filled with the liquid. Attractive forces, such as van der Waals interactions, valence forces and hydrogen bridges can also hold solid particles together. If adjacent particles



**FIGURE 2.** Binders are often introduced into wet agglomeration equipment, such as the pin mixer shown here, to improve the agglomerates' crush strength

have shapes that allow interlocking, very strong agglomerates can form.

Simple tests can be used as screening tools to determine the most suitable agglomeration process for a particular powder. Liquid can be added to a fine powder in a small kitchen blender to determine if the liquid will indeed wet the powder. This simple test can also give the investigator a sense of how much liquid must be added to avoid producing a slurry or paste. To gauge the likelihood that pressure agglomeration methods will be a suitable technology, hydraulic presses can be used. Differential scanning calorimetry (DSC) can be used to estimate the temperature required to agglomerate a fine powder by melting or sintering.

Many vendors of agglomeration equipment have test facilities for conducting feasibility studies with pilot-scale agglomerators. Often, the equipment is available for rent, and potential users can perform thorough evaluations at their sites.

When conducting a feasibility study, the following properties should be measured:

**Crush strength.** Crush strength tests determine how much pressure is required to crush an agglomerate completely. Crush tests are performed on single agglomerates, using a metal plate to gradually apply increasing pressure to the agglomerate until it fractures.

**Green/wet crush strength.** Green/wet crush strength tests are essentially crush

strength tests performed on agglomerates made using a wet process. The tests are conducted on green agglomerates prior to drying. To prevent breakage during the drying process, the green pellets must have sufficient crush strength.

**Cohesive strength.** Unlike crush strength, cohesive strength is a bulk property. Cohesive strength tests are conducted using a shear-cell tester to measure the stress required to cause a consolidated sample of agglomerates to fail. Together with wall friction test results, cohesive strength measurements can be used to design hoppers, bins and silos that will reliably handle both the agglomerated product and the fine powder that is to be fed into the agglomeration equipment.

**Particle size.** The particle size of an agglomerated product is usually measured by sieve analysis. Sieves are made up of circular metal trays, each with a screen-like wire mesh in the bottom. Using sieves with a range of sizes allows a material's particle-size distribution to be measured. Other methods for measuring particle size include laser diffraction and dynamic image analysis.

## Tumble-growth agglomeration

Tumble-growth agglomeration can be either wet or dry.


**Wet agglomeration.** In a wet agglomeration process, the fine particles are wetted with an appropriate liquid, typically water. In some cases, a surfactant or other chemical is added to improve the wettability of the solid particles and improve pellet formation. Binders are frequently introduced to improve the agglomerates' crush strength. In a wet tumble-growth process, powder, liquid and additives are fed continuously into a chamber where the wetted mass is then sheared or kneaded until the liquid is evenly distributed and the granules have the desired size and strength. Examples of organic binders are waxes, rosin, starch and alginates. Inorganic binders include alkali silicates, bentonite and various aqueous solutions and dispersions. The major criteria for selecting a binder are cost, availability, compatibility with the product's final use, and its ability to give agglomerates their desired crush strength.

Popular wet agglomeration equipment includes pin mixers, plough mixers, disc pelletizers, fluidized beds and other technologies. Figures 1 and 2 are photographs of a disk pelletizer and a pin mixer, respectively.

In general, wet agglomeration of fine powders occurs in three stages. The first stage


is a mixing stage where powder, liquid and binder are combined. Next, moist particles are joined together to form green agglomerates. The green particles are generated by first forming nuclei that then grow into larger aggregates by layering or coalescence. In some cases, nucleation and aggregate growth take place in two separate pieces of equipment. For example, agglomerates from a pin mixer can be fed into a disk pelletizer. The final stage is drying or curing, which takes place in a separate device. An example of a wet agglomeration process is diagrammed in Figure 3.

The optimal amount of liquid added to a powder (that is, the amount that gives green agglomerates their greatest strength) is typically 40–90% of its full saturation. Saturation is the fraction of the total void space that can be filled with a liquid. When the liquid is added to a dry powder, liquid bridges will begin to form at contact points between particles. This is known as the pendular stage of saturation. Moisture is attracted to the interfaces between powder particles by capillary forces. As saturation levels are increased, the funicular stage is approached, where all



internal solid surfaces become surrounded by liquid. At this point, the bulk mixture becomes more paste-like, the tensional forces disappear, and the agglomerates become significantly weaker. When the powder be-

**FIGURE 3.** The major components of a wet agglomeration process are shown here



**FIGURE 4.** When liquid is added to powder, the agglomerates formed typically have their optimal strength at 40–90% of their full saturation amount

comes fully saturated, the capillary state is reached, and at higher moisture levels, the mixture begins to behave as a slurry. Saturation states of powder are illustrated in Figure 4 [1].

The optimum saturation state of a powder often depends on the equipment used for size enlargement. In general, the higher the shear imparted to the powder by the equipment, the lower the optimum saturation state and the smaller the size of the agglomerate.

Since producing a green pellet with an optimum saturation state is critical, careful control of the liquid and solids feedrates is required. Providing a steady liquid stream is usually not a problem, but providing a stable powder feedrate or ensuring a constant solids-to-liquid ratio may be a challenge for some powders. Methods for designing reliable powder feed systems are discussed by Mehos and Morgan [2].

**Dry agglomeration.** Dry agglomeration can be somewhat of a misnomer because the technology frequently requires moisture, although the amount is significantly less than what is required for wet agglomeration processes. The most common equipment used in dry agglomeration is an inclined drum.

**FIGURE 5.** Dry agglomeration processes, such as those using drum agglomerators like the one shown here, also use moisture, but significantly less than that used in wet agglomeration processes



Often, spray nozzles run along the interior of the drum to coat particles with liquid. This promotes adhesion and particle coalescence. A drum agglomerator is shown in Figure 5.

The major advantages of dry tumble-growth agglomerators are the reduced drying costs and higher throughputs. Disadvantages include the difficulty in predicting the time required to granulate powder, the fact that seed particles are often required during startup, and the high product-recycle rates that are usually necessary.

Other kinds of tumble-growth agglomerators include V-blenders and other batch mixers that are equipped with spray nozzles. Fluidized beds can also be used for size enlargement. Mechanical agitation in mixing equipment creates a turbulent environment that allows particles to contact with both liquid and each other, and coalesce, grow and form agglomerates. A similar environment can exist when particles are suspended in a fluidized bed. Fluidization occurs when the upward flow of gas provides drag forces equal to the weight of the bed of particles.

In a fluidized-bed agglomerator, dry powder is fed into a chamber equipped with a distributor plate through which the fluidizing gas is fed. Spray nozzles above the fluidized bed provide a fine mist of liquid. The gas is heated, which removes the added liquid while agglomeration takes place.

If the dry powder is isolated by spray-drying, agglomeration can be accomplished by feeding partially dried particles into an integrated fluidized-bed dryer. In a fluidized spray dryer, gas not only enters the top of a tower, where it contacts the atomized suspension or solution of solids, but also enters from the bottom of the tower through a distribution plate. Because only partial drying is achieved in the spray dryer section of the tower, particles reaching the bottom are slightly cohesive, and size enlargement will occur during fluidization. In most cases, the final drying also takes place in the fluidized bed.

### Pressure agglomeration

Pressure agglomeration falls in two general categories: roll compaction and die compaction. Because attractive forces between particles intensify

as the distance between them decreases, applying pressure can lead to exceptionally strong agglomerates.

**Roll compactors.** Roll compactors use a mechanical force to press powder. Fine particles are first fed between two counter-rotating rolls, which draw material into the gap between them. The powder is compressed into a sheet if smooth rolls are used, or formed into strips if the compactor is equipped with corrugated rollers. The sheet or strips are then fed through a flake breaker. The agglomerates are irregular in shape, but often have sufficient flowability. A roll compactor is shown in Figure 6.

The starting material is fed into the gap between the rolls by gravity or with a feeder. The equipment works best when the powder is de-aerated before it reaches the rolls. This is accomplished by one or more of the following methods: equipping the feed hopper with a screw that compresses the material as it is conveyed downward; fabricating the hopper with gas-permeable walls and applying vacuum on the clean side; using one or two gas-permeable rolls and providing vacuum in the interior; or a combination


of these methods.

**Die compaction.** Die compaction also relies on mechanical forces to press fine powders, but also allows agglomerates with a desired shape. Die compaction equipment includes briquetters and pellet mills.

**Briquetters.** Briquetters are roll compactors that have pocketed rolls. Briquetters allow the material to be molded into a desired geometry as it is pressed into recessed cavities on the two rolls. Each roll has one half of the desired form, and as the rolls approach each other, the halves unite, pressing the material into the desired shape.

**Pellet mills.** Pellet mills are devices that force fine powders into dies that are open at both ends. There are two common types: flat die mills and ring die mills. Flat die mills are similar to extruders, in that a screw is used to convey powder into an orifice plate. A cutter at the opposite side of the screw cuts the

Feeco International



**FIGURE 6.** Roll compactors, like the one shown here, are examples of pressure agglomeration equipment

Greg Mehos



**FIGURE 7.** In a ring die mill, powder is fed into the interior of a cylinder and rollers push the material out through holes in the cylinder

exposed pellets.

**Ring die mills.** In a ring die mill, powder is fed into the inside of a cylindrical chamber. Two rollers inside the cylinder then compress the powder through the die holes. Cutters outside the cylinder then cut the pellets as they leave the mill. Figure 7 is a schematic diagram of a ring die mill.

Typical die geometries are shown in Figure 8. Because considerable pressures develop ahead of the die, it must be designed so that it will not fail during operation of the mill. Straight bores are rarely used. Instead, a small chamber located at the inlet is employed to guide powder into the die. To reduce frictional resistance, the size of the die is often larger at the die inlet, outlet or both. A tapered die outlet is beneficial because it can prevent sudden expansion and breakage due to springback.

## Temperature and sintering

Extruders are typically used to heat powders to temperatures high enough to cause melting or sintering. Two types of extruders are commonly used: ram extruders and auger or screw extruders.

**Ram extruders.** A ram extruder is used batch-wise. Powder is fed into a barrel equipped with a die plate and then isolated by a hydraulically-driven piston. The powder is then forced toward the die. The barrel may be heated, although the temperature will likely rise even without the introduction of heat because of friction. The entire plug of powder does not necessarily have to reach its melting point, because only a thin layer of liquid needs to be sheared between the wall and the plug.

The extruder is equipped with cutters immediately downstream of the die plate. Because high pressures are generated, the feed material must have a low moisture content. Otherwise, the liquid will flash upon leaving the die plate and potentially fracture the pellets that are formed.

**Screw extruders.** Auger or screw extruders

are widely used to manufacture pellets continuously. The screw comprises four sections: a feed section, a conveying section, a melting or sintering section, and a pumping section. If the feed hopper is conical, the pitch of the screw beneath its outlet should equal the diameter of the hopper outlet. For cohesive materials, the hopper outlet should have a length that is at least twice its width, and the screw should have a tapered shaft to ensure that the feed hopper is fully activated. By reducing the diameter of the shaft linearly in the direction of flow, the capacity of the screw will be constant, and all the contents of the hopper will be able to enter the extruder.

A short conveying section follows the feed section, followed by the melt or sintering section. Friction or a heated barrel increases the temperature of the conveyed powder. Frequently, the diameter of the barrel is reduced or the shaft diameter is increased to enhance shear. Pressure is generated by pumping the material through a die plate or restricted orifice. If necessary, the extrudate leaving the die plate or orifice can be immersed in a water bath to reduce its temperature to below its melting point. Cutters are used to convert the extrudate into pellets.

## Handling agglomerated products

Because agglomerated products are typically non-cohesive, they can be susceptible to segregation by particle size during handling. This is especially true if the product has a wide particle-size distribution and the mean particle size exceeds approximately 100  $\mu\text{m}$ . Such a material is prone to side-to-side segregation when a hopper, bin or silo is filled [3]. Once a pile has formed, larger particles, having better flowability, will flow toward the periphery. Smaller particles will then percolate down the center of the solids bed.

Storage vessels should therefore be designed for mass flow to ensure that all material will flow when the gate is opened or when the feeder is started. Otherwise, the particle size may cycle during discharge. A mass flow pattern will develop if the hopper walls are steep enough and low enough in friction to allow flow of solids along the walls.

## Final remarks

Agglomeration of powders is desirable for a variety of reasons, including reduced dust levels and improved flowability. It is important to recognize that the product's intended use often dictates what type of agglomeration equipment should be used. For example, many operators must be able to return the

**FIGURE 8.** Many different die geometries, like the diagrams here, exist, but straight bores are rarely used



Greg Mehos

agglomerates back to their initial particle size, which would eliminate sintering as a possible agglomeration method. Some applications require a constant particle-size distribution, and therefore tumble-growth processes will require classification equipment to recycle undersized agglomerates to the front end of a process and oversized agglomerates to a milling process. Simple screening tests that use bench scale presses and mixers will provide insight to the best choices. To select the most appropriate agglomeration equipment, larger scale tests should be conducted at manufacturers' facilities or rental equipment should be evaluated at the user's site. Crush tests, cohesive strength tests, and particle-size measurements can then be used to select the most applicable technology. Wolfgang Pietsch [4] is an excellent reference for reviewing agglomeration technologies. ■

*Edited by Scott Jenkins*

## References

1. Mehos, G. and Kozicki, C., "Consider Wet Agglomeration to Improve Powder Flow," *Chem. Eng.*, January 2011.
2. Mehos, G., and Morgan, D., "Hopper Design Principles," *Chem. Eng.*, January 2016.
3. Mehos, G., "Preventing Segregation in Agglomeration Processes," presented

at the 34th biennial Institute for Briquetting and Agglomeration Conference, Scottsdale, Arizona, 2015.

4. Pietsch, W., "Agglomeration Processes – Phenomena, Technologies, Equipment," Wiley-VCH, Weinheim, Germany, 2002.

## Authors



**Greg Mehos** is an adjunct professor at the University of Rhode Island (51 Lower College Road, Kingston, RI 02881; Phone: (978) 799-7311; Email: gmehos@uri.edu) and is available for independent consulting and contract work. Mehos has expertise in a wide range of bulk-solids handling areas, including design of hoppers, dryers, gasifiers and moving-bed reactors, as well as analyses of purge and conditioning columns. He received his B.S. and Ph.D. in chemical engineering from the University of Colorado and an M.S.Ch.E. from the University of Delaware. He is a registered professional engineer in Massachusetts and a member of AIChE. He served on the executive board of AIChE's Particle Technology Forum and is a past chair of the Boston AIChE section.



**Chris M. Kozicki** is a process sales engineer at Feeco International, Inc. (3913 Algoma Rd., Green Bay, WI 54311-9707; Phone: 920-468-1000; Email: ckozicki@feeco.com; Website: www.feeco.com) a complete solutions provider that engineers, designs and manufactures systems, including agglomeration, drying/cooling and material handling. Kozicki has been associated with limestone and gypsum pelletizing systems, mineral byproduct briquetting and agricultural chemical processing. He is a past president of the Institute for Briquetting and Agglomeration and received a B.S. degree in engineering mechanics from the University of Wisconsin.