

REALLY DEEP TRENCH PANEL BRACING CHART
INTERLOCKING ALUMINUM UPRIGHTS

as supplied by Really Deep, LLC

Trench Depth (ft)	Soil Type A (25 psf)		Soil Type B (45 psf)		Soil Type C60 (60 psf)		Soil Type C80 (80 psf)		*Allowable Panel Moment (ft-lb)
	Moment Created by Soil Load (ft-lb)	Maximum Spacing Allowed (ft)	Moment Created by Soil Load (ft-lb)	Maximum Spacing Allowed (ft)	Moment Created by Soil Load (ft-lb)	Maximum Spacing Allowed (ft)	Moment Created by Soil Load (ft-lb)	Maximum Spacing Allowed (ft)	
0-4	137	note 2	246	note 2	328	note 2	438	note 2	3411
>4-8	1095	8	1971	8	2628	8	2347	7	3411
>8-12	2147	8	3135	7	3243	6	3167	5	3411
>12-16	3203	8	2531	5	3375	5	2987	4	3411
>16-20	3369	7	3281	5	2880	4	2720	3	3411



*Maximum strength of a single trench panel (16" wide)


Chart Notes:

- Chart designates maximum allowable spacing of cross members required to keep panel moment below compromising level of 3411 ft-lb.
- All rescue personnel should refer to OSHA, CFR 1926 Subpart P, NFPA 1670, NFPA 1006, and your organization's safety guidelines before installing Really Deep Trench Shields.
- All other members of trench system and equipment are assumed to be of adequate strength to provide support for panels at bracing locations shown above.
- All panels to be braced within 2 ft. of top and bottom of the trench.
- Aluminum panel alloy shall be 6061-T6.
- Chart applies to trench rescue panels installed per supplier's written specifications.

Pricing for Really Deep Panel Packages

Really Deep Trench Panel systems are priced in kits built to suit your department's needs and budget!

<p>12' depth x 12' length </p> <p style="margin-left: 100px;">Includes:</p> <p style="margin-left: 100px;">18 – 8 foot panels 18 – 5 foot panels 4 – Knuckles 2 – Inside corner adapters 1 – Plate clamp</p>	<p>8' depth x 12' length </p> <p style="margin-left: 100px;">Includes:</p> <p style="margin-left: 100px;">18 – 8 foot panels 4 – Knuckles 2 – Inside corner adapters 1 – Plate clamp</p>
---	---

Additional panels or knuckles may be purchased at any time 

*Pricing in flux due to fluctuating aluminum prices

Manufactured by:

Really Deep, LLC
Shannon, IL

exclusively for RescueVac Industries



Tips for Using Really Deep Panels

- When starting to set trench panels on a straight line or simple opposing wall configuration, it is best to place the panels directly opposite one another
 - If opposing panels are placed offset of one another, bracing becomes more difficult
- If it is a T trench or L trench configuration, it is best to start at a corner with a knuckle and place the interconnecting panels from both directions
 - Starting at the corner, with a knuckle, will automatically center the rest of your build
- If you cannot start in a corner due to safety reasons, you can start from a safe zone and work your way to a corner
 - Once at the corner, multiple knuckles or extra backfill may be needed in order to stabilize and shape the corner correctly
- Wall sections can be stacked vertically as long as there is a 12 inch overlap at the connecting seam
- When removing the panels from the trench, use the metal worker's sheet clamp that is provided with every set
 - Use of mechanical equipment is strongly suggested; such as a crane or lift to remove panels
- Strong-backs can be attached to Really Deep Panels to allow the use of wooden shoring
 - Simply drill ¼ diameter holes in the panels to allow double headed nails to be driven thru the panel and into wooden strong-backs
- After use, pressure wash and dry panels prior to storage


 Signature: 
 Date: 4/19/16
 Exp. Date: 11/30/16