







## COMPONENTS


PER POST

<b>A</b>	FRONT GROUND ANCHOR	x1	
<b>B</b>	GROUND PEG	x1	
<b>C</b>	LARGE QUICK RELEASE BUTTON	x1	
<b>D</b>	ARROW HEAD NET FIXING with attached LOCKING PIN	x2	
<b>E</b>	RESPECT BARRIER POST	x1	
<b>F</b>	POST CAP	x1	

## OPTIONAL EXTRA

	<b>CHAIN LINK</b> 25 Metres	
--	--------------------------------	---

## DO NOT THROW THE LOCKING PINS AWAY





### WARNING





DO NOT LEAN ON POSTS OR CHAIN.

RESPECT BARRIER POSTS WILL NOT BE REPLACED WITHIN THE GUARANTEE PERIOD IF MISUSED. THE RESPECT BARRIER IS ONLY A SEPARATOR BETWEEN SPECTATORS AND PLAYERS.


## RESPECT BARRIER - CHAIN LINK WITH PLASTIC ANCHOR

Post sizes available  
815mm or 580mm LONG -




## FRONT GROUND ANCHORS


HAMMER FULL DOWN INTO THE GROUND




1. Make sure the front Ground Anchor is inserted fully and level with the grass surface. If the ground anchor is not fully inserted when pegged down, tension will cause the peg slot to break.




SPARE PARTS TEL: 0114 242 4244



1. With your first barrier post in position use the tension peg to reinforce stability before assembling the rest of the barrier pack. Always start erecting the barrier from one side for an easy and efficient assembly (steps 1 - 2).



1. Attach your first chain link onto the arrowhead fitting. You will need approximately 5 metres of chain link per post distance (steps 3 - 4).



1. On the last barrier post use a tension peg to complete your barrier system and reinforce stability. To dismantle simply start at one end and follow the steps in reverse order un-pegging and un-linking the posts (steps 5 - 6).

**Please note: This is a temporary quick-fit barrier to separate spectators from players for a more permanent solution please visit [itsagoal.net](https://itsagoal.net)**