

## Install Batteries

Open the battery cover. Insert two AA batteries as shown in the diagram on the bottom of the battery compartment.

The 2-buzzer model uses a regular carbon-zinc battery.

High-volume 6-buzzer model uses alkaline batteries. The Panasonic Evolta has a lower battery power, which may result in a lower volume; it is not an alkaline battery. If you find the volume to be lower but sufficient when testing with non-alkaline batteries, then it's OK.

## Set clock date and time

Press any key to turn on the display, then press keys 8 and 9 simultaneously. The year 2023 will appear. Enter the last 2 digits of the Common Era. For example, enter 24 for 2024. Next, enter the month and day, for example, 0123. Then enter the 24-hour time, for example, 1850. If there is a input that should be kept, you can click the "Next" button to skip to the next input. The same applies to the following.

## Check the date and time on the clock.

The screen is normally off. Press any key(digits or Next key) and release immediately. It will display the time for 3 seconds and the date for 0.5 seconds. Since the alarm clock is usually kept in the bedroom and not looked at, it saves a lot of electricity. When displaying a date, there is no colon (:), for example, "9 30". When displaying a time, there is a colon (:), for example, "9:30". The same applies to the following. You can press the "Next" key to reduce noise.

## Weekly alarm, one-time alarm

Long press a key	Setting
<b>0</b>	the days of a week of weekly alarm A and its time
<b>1</b>	the time of Weekly alarm A
<b>2</b>	the days of a week of weekly alarm B and its time
<b>3</b>	the time of weekly alarm B
<b>4</b>	the days of a week of weekly alarm C and its time
<b>5</b>	the time of weekly alarm C
<b>6</b>	the days of a week of weekly alarm D and its time
<b>7</b>	the time of weekly alarm D
<b>8</b>	the date/time of single alarm E
<b>9</b>	the date/time of single alarm F

## Set weekly alarm

There are 4 weekly alarm groups (A, B, C, and D), and each can be set to ring at any time of the week, by long-pressing one of the number keys A:01, B:23, C:45, and D:67.

## Set alarm A

1. Long press **0**
2. At this moment, the "wSel" light is flashing. The initial alarm setting is the typical day-of-the-week light that flashes Monday through Friday, as is common for office workers. This indicates that the alarm will ring on Monday, Tuesday, Wednesday, Thursday, and Friday. For example, the catering industry people want the alarm to ring on Sunday, Tuesday, Wednesday, Thursday, Friday, and Saturday. To cancel Monday, press digit **1**. To add Sun

and Sat, press the keys below Sun and Sat, which are **06**. After entering the days of the week, press the "Next" key.

3. Next, enter the time you want the alarm to ring in 24-hour clock, for example, 630 means it will ring at 6:30 AM; 2000 means it will ring at 8:00PM. If the hour input should be kept, press the "Next" button. It is recommended to set the time to the current time + 2 minutes during testing; simply adding 1 minute may not trigger an alarm. And confirm that the alarm master switch is "on".

#### **Only want to change the time of alarm A**

1. Long press **0**
2. Enter the time you want the alarm to ring in 24-hour clock, for example, 630 means it will ring at 6:30 AM; 2000 means it will ring at 8:00PM.

#### **Set alarm B, alarm C or alarm D**

1. Long press one of the keys corresponding to 2, 4, or 6 on alarm B, alarm C, or alarm D.
2. At this time, the "wSel" light flashes. The initial alarm clock setting is that the week lights are off for Monday, Tuesday, Wednesday, Thursday, and Friday, meaning they have no effect. To add, for example, Sunday, press the button below Sunday, which is 0. For example, to cancel Sunday, press 0 again. You can can multiple days a week to ring. After entering the days of the week, press the "Next" key.
3. Next, enter the time you want the alarm to ring in 24-hour clock, for example, 630 means it will ring at 6:30 AM; 2000 means it will ring at 8:00PM. If the hour input should be kept, press the "Next" button.

#### **Only want to change the time of alarm B, C or D**

1. Long press one of the keys corresponding to 3, 5, or 7 on alarm B, alarm C, or alarm D.
2. Next, enter the time you want the alarm to ring in 24-hour clock, for example, 630 means it will ring at 6:30 AM; 2000 means it will ring at 8:00PM. If the hour input should be kept, press the "Next" button.

#### **Set the alarms so that two persons wake up on Mon through Fri**

1. Refer to the section above "Only want to change the time of alarm A" 2. Refer to the section above "Set alarm B, alarm C or alarm D". Add **a** Mon through Fri alarm to alarm B.

#### **How to check the set times of alarms A, B, C, or D?**

Press any key to turn on the time display, then press 0 or 1 to display alarm A, 2 or 3 to display alarm B, 4 or 5 to display alarm C, and 6 or 7 to display alarm D.

#### **How to cancel/delete alarm A, B, C, or D?**

1. Long press one of the keys corresponding to 0, 2, 4, or 6 on alarm ABCD
2. Press the key below the lit indicator to turn off the light. Once all the lights are off, press the "Next" key to finish.

#### **How do I stop the alarm when it rings? How long will it ring if it's not stopped?**

Press any digit key to turn off the alarm. After pressing the key, it will ring at a high frequency for 0.5 seconds before stopping. If no digit keys are pressed, the ring will last for 2 minutes. If the volume is low, please make sure the battery is new. The default melody and 2-minute length are adjustable. Please see the sections at the end of the document.

#### **How do I snooze when it rings ?**

Press the "Next" key to ring again after 5 minutes. The default 5-minute length is adjustable. Please see the sections at the end of the document.

#### **How to cancel snooze if you accidentally press the "Next" key**

Turn the alarm master switch to "Off", then turn it back to "On". If you don't switch back to "On" and keep it in "Off", all future alarms will be turned off.

## **How to confirm the next alarm time?**

Press any key to turn on the time display, then press the "Next" key to display the date, day of the week, and time of the next alarm. If it displays "OFF", it means the "master alarm switch" is off, and the alarm will not ring. If no alarms are active, "----" will be displayed. When setting a new alarm, be sure to check that the date, day of the week, and time are correct. If the date is more than one year from now, the year (20XX) will be displayed first. Please check if the year was entered incorrectly when "crossing over to the next year".

## **How to postpone "weekly alarm start date" when you're on vacation?**

With the screen off, press and hold the "Next" button, then immediately press the corresponding keys 0 or 1, 2 or 3, 4 or 5, 6 or 7 on the alarm A, B, C, or D. A 20XX prompt will appear asking you to enter the year, month, and day, allowing you to set the "weekly alarm start date".

You can set the date to a fixed rest day, and it will automatically adjust. For example, if today is Thursday and you want it to be off on Friday, with Saturday and Sunday as fixed rest days, setting the date to Saturday is equivalent to setting it to Monday. Therefore, if you want it to be off tomorrow, you can always set the start date to the day after tomorrow.

To check settings: Press any key to turn on the time display, then press 0 or 1 to display alarm A, 2 or 3 to display alarm B, 4 or 5 to display alarm C, and 6 or 7 to display alarm D. The start date will be displayed first, followed by the time.

## **How to cancel the "weekly alarm start date"?**

The steps are the same as above, but you set a past date. If you find that an alarm is not working, it's probably been set; cancel it first.

## **I woke up earlier than usual today, how can I prevent the alarm from ringing?**

- You can use the method above to postpone the "weekly alarm start time" to tomorrow.
- Alternatively, you can turn off the "master alarm switch", but remember to turn it on before sleeping.

## **How to set a single alarm (for travel, work, or occasional afternoon nap)**

There are two single alarms, E and F. Long press 8 to set a single alarm (E), long press 9 to set a single alarm (F), then enter the year, month, day, hour, and minute to represent the date and time to which the alarm should ring. The time is in 24-hour format; for example, 630 means it will ring at 6:30 AM. Entering 2000 means it will ring at 8:00 PM. For example, if you need to get up early to go out or make up for work on Saturdays and Sundays, you can use a single alarm. It is recommended to set the time to the current time + 2 minutes during testing; simply adding 1 minute may not trigger the alarm. Also, confirm that "master alarm switch" is set to "on".

## **How to cancel single alarms E and F after setting them?**

If you set an a past alarm date, it is canceled.

## **How to check the set times of individual alarms E and F?**

Press any key to turn on the time display, then press 8 to display alarm E, and 9 to display alarm F.

## **How can I turn off all alarms during an uncertain vacation period when I don't know or don't want to set a start date?**

Turning the "master alarm switch" to "off" will display "OFF," turning off all alarms. Pressing the "Next" button to confirm the next alarm time will also display "OFF," indicating that the master alarm switch is off. When your vacation ends, to resume the alarm, simply turn the "master alarm switch" to "on", and it will automatically display the date, day of the week, and time of the next alarm.

## **Can it be used as a traditional alarm clock?**

For example, you can set alarm A to ring 7 days a week, and then use the "master alarm switch" to control whether the alarm will ring tomorrow, which is the traditional mode. When the alarm rings, turning the "master alarm switch" to "off" will also turn off the alarm.

## **My work cycle is not fixed or does not conform to the weekly cycle (e.g., 4 days on, 1 day off).**

For example, you can set a weekly alarm A to ring 7 days a week. On the last workday, set the "weekly alarm start date" to the next workday. Alternatively, on the last workday, turn the "master alarm switch" to "off" and turn "on" on the day before the workday.

## **The best setting if I want to wake up earlier/later than usual tomorrow?**

- Set "weekly alarm start date" to the day after tomorrow, and set a single alarm that will ring tomorrow.
- Alternatively, you can change your usual work week alarm time, just remember to change it back tomorrow night.

## **When and how to change the battery**

Under normal use (ring 5 days a week, 3 seconds a day), a carbon-zinc battery can last for more than 3 years. If the display is not bright enough or the alarm is not loud enough, you should replace the batteries. Do not remove the old batteries at first; prepare new batteries before replacing them. After removing the old batteries, if no key is pressed and the display is off and the replacement is completed within 20 seconds, the clock time and settings will not be lost.

## **Choose alarm music**

Press any key to turn on the screen, then press keys 6 and 7 simultaneously. "no:00" will be displayed. Enter the 2-digit music code, and a music preview will play. The display will change to xx : y, where xx is the code you just pressed, y is 0 when the music is not in the playlist, and y is 1 when the music is in the playlist. Press 0 to remove from the playlist, press 1 to add to the playlist. The above steps will then repeat automatically. Press the "Next" key to finish. When the alarm rings, the songs will be played in sequence. If there is only one song on the playlist, it will only play that song repeatedly. **01**:BWV 147 **02**:Scotland the Brave **03**:Loch Lomond **04**:Danny boy **05**:Skye Boat Song **06**:Jasmine **07**:Takeda Lullaby **08**:Akatombo **09**:The Sally Gardens **10**:Be Thou My Vision **11**:Bach - Minuet in G Major **12**:Twinkle Twinkle Little Star **13**:Salut d'Amour **14**:Row, Row, Row Your Boat **15**:She'll Be Coming Around the Mountain When She Comes **16**:Ode to Joy **17**:London Bridge **18**:Für Elise **19**:Maiden's Prayer **20**:Land of Hope and Glory **21**:Bach Air **22**:萍聚 **23**:Haydn: Trumpet Concerto **24**:pitch test **25**:beep A **26**:beep B **27**:beep C **28**:beep D **29**:Sonate pathétique **30**:Nearer, My God, to Thee **31**:Going Home **32**:Fantaisie-Impromptu

## **Change digit keys to snooze keys**

Press any key to turn on the screen, then press the 0 and 1 keys simultaneously to display bC:0. 0 is the current setting. Enter one number. 0: Digit keys stop, Next key snoozes. 1: Digit keys snooze, Next key stops. 2: Digit keys and Next key stop. To view only the setting, press the "Next" key to end.

## **Change the alarm music playback duration**

Press any key to turn on the screen, then press the 2 and 3 keys simultaneously to display P1: 02, where 02 is the current minute. Enter a 2-digit number; the acceptable range is 01...30. To view only the setting, press the "Next" key to finish.

## **Change the snooze duration**

Press any key to turn on the screen, then press the 4 and 5 keys simultaneously to display 5n: 05, where 05 is the current minute. Enter a 2-digit number; the acceptable range is 01...30. To view only the setting, press the "Next" key.

## **Precautions**

- Do not allow foreign objects to press on the keys for an extended period of time, otherwise the LED may remain lit for too long and the batteries may run out of power.
- If the anti-tear sticker on the screw hole is damaged, missing, or damaged by natural disasters or human error, returns or exchanges will not be accepted, and the warranty will be void.
- Do not splash water. If water gets on the clock, remove batteries and allow it to dry completely before use.

- Large-volume model has a high power consumption; please replace the batteries regularly to prevent insufficient volume.

## **Customer Service**

Product Model: AL002:Music Alarm(2 buzzers) AL004: Large Volume Music Alarm (6 buzzers)

AdvanOrigin Co.,Ltd. **This manual is available from [advanorigin.com](http://advanorigin.com)**

[support@advanorigin.com](mailto:support@advanorigin.com)

Phone: 886-970590048 Mr. Liu

US patent US12282299B2 Taiwan patent: I802922

Designed/Assembled in Taiwan

**Purchase location(future): Amazon, google AdvanOrigin**