





# Hello, Smart Home






# Door Bell

ORIGINALITY DESIGN SMART - AND BEAUTIFUL

.....








# QUICK GUIDE




# What's in the box

Please consult this checklist for all parts.




Description




Power Port	AC 12~24V
Doorbell button	Press the button to activate the doorbell
Status light	<ul style="list-style-type: none"><li>• Solid red light on: network is malfunctional</li><li>• Blinking red light: wait for network connection (quickly blinking)</li><li>• Solid blue light on: the camera is working correctly</li></ul>
Microphone	Capture sound for your video
SD card slot	Support local SD Card storage (Max. 128GB)
Reset	Press and hold on for 5 seconds with pin to reset the doorbell

## Mechanical Chime Installation

**Step 1** First turn off the power breaker at your fuse box for your existing doorbell and mechanical chime. Ring your doorbell again to confirm it is now off.



**Step 2** Find your mechanical chime that is a rectangular box, produces the sound when your doorbell is pressed. It may (or may not) be mounted immediately inside your FRONT door. And remove the cover.




(Example of a Mechanical Chime)




## Mechanical Chime Installation

- Step 3** Slightly unscrew both screw terminals and one hook from the Chime Kit under each screw (It does not matter which color wire from the Chime Kit connects to which screw).




Locate the Chime Kit included in the smart doorbell's packaging, and the terminals on the inside of the chime. Connect one of the Chime Kit's prongs to the transformer terminal (usually labeled TRANS, T, AC, or 0). Connect the other prong to the chime's front terminal (usually labeled FRONT, F1, or C1). Either prong on the Chime Kit can be connected to either of the terminals on the chime.



## Mechanical Chime Installation

- Step 4** Using the included doubles sided tape, affix the Chime Kit to your chime wherever there is space and replace the cover. Be careful not to interfere with any of the chime's moving parts.




Ensure that the Chime Kit and wires DO NOT interfere with the mechanical parts of the chime. Mount on the outside of the chime if there is not enough room to mount inside. And replace your chime's cover.





# Installation

## Mode 1 Doorbell General Installation



1. Fix the bracket to the wall with the mounting screws
2. Install the camera in the bracket and lock it with the screw

## Mode 2 Angle Wall Mount + Bracket + Doorbell Installation




1. Fix the angle wall mount to the wall
2. Fix the mounting bracket in the angle wall mount
3. Install the camera in the bracket and lock it with the screw


# Installation



Turn the doorbell power back on at the fuse box. The light on the doorbell button should turn on and after a few minutes become red slowly.



# Set Up Router



Please keep network available

2.4GHz




5GHz



The router supports the 2.4GHz WiFi (doesn't support the 5GHz), and is connected to the WiFi network. Please set the parameters of the router before connecting the WiFi network, and record the SSID and password of your WiFi.

## Install Free App



Download APP: scan the QR code below to download and install. Register and login: open the "MySmarth" APP to register and login according to the prompts.



## Customer Support





# Connect the Smart Doorbell to MySmarth App





1. Open "MySmarthH" APP, press the '+' in the upper right corner of the main screen;
2. Choose "VideoSurveillance", click "Smart Door Bell".





3. Click "Next step";

4. Choose WiFi and enter password and Tap "Next"



4. In this interface, you should scan the QR code in your phone with the camera,when the camera comes out "dong dong dong". And you click “I heard a prompt”.

00:24



Done

5

Added.



Door Bell



Device added successfully

Living Room

Master Bedroom

Office

Dining Room

Kitchen

Garage

Basement

Front Door

Family Room

22:31



Model Home



Overcast

7 °C  
Outdoor Temp.

Excellent  
Outdoor PM2.5

72.0 %  
Outdoor Humidity



Home



Away

All Devices

Living Room

Master Bedroom

Of ...



Alarm System

Family Room

11-24  
16:14



Smart Lock Gateway

Front Door



Smart Lock

Front Door



Door Bell

Front Door



Thermosta

Living Room



NVR-Recording

Basement



Garage Door

11-24  
13:33



Smart Water Meter



Home




Smart



Me

5. When connecting, you should make sure your router, mobile, and Smart Doorbell are as close as possible. When Smart Doorbell added successfully.



Now your Smart Doorbell is successfully added to MySmarth app.



## FAQ

Q: In the network process, the process bar is always not 100%, add failure?

A: This camera only supports 2.4GHz WiFi router, please make sure you are using a 2.4GHz WiFi router. And confirm the WiFi password again.

Q: Repeated additions are failures?

A: After adding a failure, it is recommended to restart the device or power off, and then try to add again.

Q: The device cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: How to cut the camera network to another router?

A: First remove and reset the device on the App and then configure the device again by the App.

Q: Why I can't get the notifications with my cell phone App?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.

Q: Why doesn't the device identify the SD card?

A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the Internet environment is not good.



# Functions

## Full-duplex audio

When the visitor push the doorbell button, you will get a call. You can see and hear the visitor in your App from the doorbell if you answer.

## Motion detection

Motion sensors will notify you when movement is detected.

## Shared device


The doorbell device can be shared with friends, and friends can also preview online. There is no limit to the number of sharing devices, but only 6 accounts are supported for online preview at the same time.

## Record

Record every moment using high capacity SD card storage.

## Day & Night

Powerful night vision means no interruptions, even in complete darkness.



Daytime



Night