

### Limited Warranty

J & J Global LLC. Products for Home Use

J & J Global LLC. (Seller) warrants to the original Buyer only, that this Sunray Product will be free from defects in material and workmanship for a period of one (1) year from date of purchase. **SELLER'S SOLE OBLIGATION AND BUYER'S EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE THE REPAIR OR REPLACEMENT OF PARTS, WITHOUT CHARGE, WHICH ARE DEFECTIVE IN MATERIAL OR WORKMANSHIP.** ANY PARTS AS DETERMINED BY THE SELLER WHICH HAVE BEEN MISUSED; ABUSED OR DAMAGED EITHER DIRECTLY OR INDIRECTLY FROM REPAIRS OR ALTERATIONS ATTEMPTED BY UNAUTHORIZED PERSONS; IMPROPER MAINTENANCE, NEGLIGENCE OR ACCIDENT ARE NOT COVERED BY THIS LIMITED WARRANTY. This warranty does not apply to damage, heat-induced coloration changes, scratching or alteration due to normal use or weathering. To make a claim under this Limited Warranty, you must return the complete product with proof of purchase, transportation prepaid, to any World Factory, Inc. authorized service center. Call 1-888-422-7800 for the location of the nearest authorized service center.

#### Additional Limitations

THIS LIMITED WARRANTY DOES NOT APPLY TO ACCESSORY OR CONSUMABLE ITEMS, INCLUDING BATTERIES, RELATED TO THIS PRODUCT. ALL IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO TWO YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS, ARISING FROM THE SALE OR USE OF THIS PRODUCT.

If any provision of this Limited Warranty is for any reason held to be invalid or unenforceable, such provision shall not affect any other provision herein, this Limited Warranty shall be construed as if such invalid and/or unenforceable provision had never been contained herein.

This warranty gives you special legal rights, and you may also have other rights which vary from state to state.

This Warranty contains the entire agreement between Seller and Buyer and supersedes any and all prior agreements, arrangements, or understandings between the parties relating to product warranty.

Due to ongoing product development  
the actual product or products may vary from  
the illustrations or photos shown within this manual.

For Manuals, Replacement Parts or Customer Service visit:  
[www.ezreplacement.com](http://www.ezreplacement.com)

### Made in China

©2016 J & J Global LLC.

Distributed by:

J & J Global LLC.

Carrollton, TX 75006

121011rev1



## Hannah Lamp Post & Planter Instruction Manual



Model No. 302010

Read the instructions and precautions before use of this product


Please keep this instruction manual for future reference

For warranty information, please refer to the back page of  
this instruction manual.

## PARTS & HARDWARE LIST

PART #	DESCRIPTION	QUANTITY
A	Lantern Assembly	1
B	Lantern Top	3
C	Lantern Body	3
D	Glass Globe	3
E	Upper Post	1
F	Middle Post	1
G	Lower Post	1
H	Support Ring	1
I	Lamp Post Base	1
J	Defuser	3
K	Top Planter Base	1
L	Bottom Planter Base	1
M	Mounting Plate	1
N	J-Bolts	3
O	Flat Washer	3
P	M10 Nut	6
Q	Acorn Nut	3
R	M4 Cap Nut	6
S	M6 Screw	3
T	M10 Bolt	3

### Parts Detail



Carefully remove the contents from the package. If any parts are missing do not attempt to use the product until they have been obtained and correctly installed.

## CARE AND MAINTENANCE

### Care Instructions


1. Clean any dirt and debris from the solar panels. The panels cannot recharge if light is obstructed. Use a soft cloth to clean the panels. Do not use abrasives or chemicals that might scratch or damage the UV coating.
2. In a region where snow and ice are likely, and the light assembly is covered with snow for an extended period of time the batteries will require recharge for at least 8 hours.

### Battery Replacement

**NOTE:** The batteries in your solar lantern come preinstalled from the factory.

1. (SEE FIGURE 8) Remove the screws from the underside of the solar panel housing. Solar panel housing is located on the top of the lantern assembly.
2. Carefully lift the solar panel off the housing. Circuit wires are attached to the solar panel, be careful not to disconnect the wires. Batteries compartment is located under the solar panel.
3. Remove old batteries.
4. Replace old batteries with 3 "AA" rechargeable Ni-Mh batteries. Reference polarity direction inside battery compartment.
5. Replace the solar panel on the housing and secure with screws retained from step 1.
6. The rechargeable batteries need to be fully charged before operating light assembly. See "Operating Solar Light" to restore solar light assembly to full operation.

Figure 8



### Recycling

Please dispose of batteries properly. Consult your local telephone listings for a battery recycling center in your area.



Ambient temperature  
maximal 40°C (105°F)



Do not dispose of  
batteries in  
household waste



Do not throw  
batteries into water!



Protect batteries  
against heat and fire  
risk of explosion



Recycling

## OPERATING SOLAR LIGHT

### Instructions for First Time Use

Allow Lamp Post to charge for at least 8 hours in full sunlight with the On/Off switch in the Off position. Once the batteries have fully charged, set the On/Off switch to the desired setting.

**Note:** If the Lamp Post does not turn on after initial charging, ensure the batteries are making contact with the terminals and the On/Off switch is in position "A" or "W".

### Where to Place the Solar Light

Place the Lamp Post in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours of nighttime illumination is directly proportional to the number of hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its burn time will be limited. Do not place the Lamp near other outdoor lighting like porch or streetlights – these may fool the auto sensor and keep the light from coming on, or cause it to turn off automatically.

### On / Off Switch

- (SEE FIGURE 7) Slide the On/Off selector switch to the desired position:

Position	Function	Comments
"Off"	Off	Used for initial or re-charging after battery replacement
"A"	On (Amber)	Auto Dusk to Dawn operation – 3 Amber LED's per head
"W"	On (White)	Auto Dusk to Dawn operation – 6 White Super Bright LED's per head





Figure 7

## ASSEMBLY INSTRUCTIONS

### Lantern Assembly

- (SEE FIGURE 1) Put lantern body (C) onto lantern assembly (A) turn clockwise to secure.
- Connect the LED circuit wires found on the bottom of the lantern body (C) to the LED circuit wires found on the bottom of the defuser (J). Insert defuser (J) into lantern body (C) and turn clockwise to lock.
- Put the glass globe (D) into the lantern body (C) over the defuser (J)
- Place the lantern top (B) over the studs in lantern body (C) and secure with cap nut (R).
- Repeat with the other 2 lantern bodies (C).

Figure 1




### Planter Base Assembly

**Note:** If using ground mounting instead of planter base mounting refer to "Ground Mounting" on page 3.

- (SEE FIGURE 2) Attach lamp post base (I) to bottom planter base (L) using M10 bolts (T), mounting plate (M), Flat washer (O), and hex nut (P). Make sure the mounting plate, flat washer and hex nut are secured to the hex bolt on the underside of the bottom of planter base (L).


Figure 2



- (SEE FIGURE 3) Attach the top planter base (K) to the bottom planter base (L) by lining up the 4 tabs and pulling the top planter base up until tabs snap into place. Turn the top planter base clockwise to lock the tabs into place.

**Note:** It may be necessary to put pressure on the bottom planter base when pulling the top planter base up.

Figure 3



## Support Ring Assembly

1. (SEE FIGURE 4) Place the support ring (H) onto the top of the lower lamp post (G). Attach lower lamp post (G) to lamp post base (I) using 1 in. screw (S) in 3 places. Lower the support ring down the post until it rests on the top of the top planter base (L). To complete the solar lamp post with planter go to "Lamp Post Assembly" steps 2, 3 and 4 on page 4.

**⚠ CAUTION:** To prevent product damage or personal injury from tip-over, lamp post planter base must be placed on a flat, level surface and be filled with 4 in. (minimum of 40 lbs.) of gravel or stone. Damage due to improper site selection, weighting or stabilization of the Lamp Post is not covered by Warranty.

Figure 4





Figure 5



## Lamp Post Assembly

1. (SEE FIGURE 6) Attach lower lamp post (G) to lamp post base (I) using 1 in. screw (S) in 3 places.
  2. Place the completed lantern assembly (A) on the upper lamp post (E) and twist clockwise to secure.
- Note:** If using the planter base to mount the lamp post refer to Figure 4 before proceeding to the next step for lamp post assembly.
3. Place the middle lamp post (F) onto the lower lamp post (G) and twist clockwise to secure.
  4. Place the upper lamp post (E) onto the middle lamp post (F) and twist clockwise to secure.

Figure 6

