



Unlock & Adjust Length -Re-lock



Load Cup

Close Cup With Grip



Ready to Use

Preparing To Tee Up The Ball

Adjust the REACHERGOLF to the length desired and lock it. For type of tee used it is recommend to use tees that have a Magnum Top like the Martini or similar type of tees. It's easier to replace the ball on this type of tee in case the ball is accidentally knocked off.

Teeing Up The Ball

Load the cup and tee into 3D mold. With one hand on the grip apply pressure on the trigger to close the cup.

Placing Ball & Tee Into The Ground

The REACHERGOLF should hang vertically and then slowly push down until the ball is placed at the height desired. Release the grip pressure to open the cup and leave the ball on the tee; ready to hit.

After hitting ball pick up the tee with the cup and get ready to play the hole.

Ball & Turf Entry

Practice a few times. So when the ball is released tee into the ground the ball isn't knocked off the tee. If this happens, pick up the ball with the cup and place back on the tee.

Bending & Club Management

Manage bending on the course by using the StepKick Caddy in conjunction with REACHERGOLF products. REACHERGOLF also provides a hook and adjustable wrist strap for easy access while hanging on the golf bag between uses on the course, as well as for picking up the REACHERGOLF from the ground using the club head or grip.

Using On The Green

Use for ball placement , with a magnetic or any type of marker and retrieve ball from cup.