

SECTION 08460 DITEC DS18 AUTOMATIC SLIDING DOOR – ALL GLASS

1. GENERAL

1.01 Summary

- A. Work included: Furnishing and installing factory fabricated and finished “All Glass” Automatic sliding door system.
- B. Related Work: [Insert applicable section including]
 - 1. Section 07900 – Caulking
 - 2. Section 08400 – Entrances and Storefronts
 - 3. Section 08710 – Finished Hardware
 - 4. Section 08800 – Glazing
 - 5. Section 12670 – Entrance Mats
 - 6. Section 16120 – Electrical Supply and Termination

1.02 Submittals

- A. Product Data: Provide manufacturer’s product and complete installation data for all materials in this specification.
- B. Shop Drawings: Show profiles, joining methods, location of components, anchorage details, adjacent construction interfacing and dimensions as well as all necessary wiring and electrical requirements.
- C. Samples: Sized to adequately represent material
- D. Contract Closeout: Submit the Manufacturer’s warranty and performance certification (if applicable)
- E. Installation Guide: Provide written installation and operating manuals and/or installation recommendations.

1.03 Quality Assurance

- A. Installation and maintenance shall be performed by an authorized dealer and in strict compliance with the manufacturer’s recommendations.
- B. Installing dealer shall provide factory authorized and trained service professionals 24 hours a day, seven days a week. The installing and servicing dealer shall be a certified member of AAADM (American Association of Automatic Door Manufacturers).
- C. ENTREMATIC Sliding Door product(s) and other products provided conform to the following codes and standards:
 - ANSI/BHMA A156.10 – Power Operated Pedestrian Doors.
 - ANSI/UL325 – Door, Drapery, Gate, Louver and Window Operators and Systems.
 - CUL/USA Listed – Product Safety.

ENTREMAT^{IC}

1.04 Product Handling

- A. All materials shall arrive in the manufacturers original sealed, labelled containers.
- B. Store materials in a dry, protected, well-vented area. Reports damaged material immediately to the delivering carrier and note such damage on the carrier's freight bill of lading.
- C. Remove all protective materials after installation.

1.05 Job Condition

- A. Verify that other trades are complete before installing the automatic sliding door system.
- B. Mounting surfaces shall be plumb, straight and secure; substrates shall be proper dimension and material.
- C. Refer to the construction documents, shop drawings and manufacturer's installation instructions.
- D. Coordinate installation with the glass, glazing and electrical work.
- E. Observe all appropriate OSHA safety guidelines for this work.

1.06 Warranty/Guarantee

- A. Manufacturer's Standard Limited Warranty: Warranted materials shall be free of defect in material and workmanship for three years after installation.

2. PRODUCTS

2.01 Manufacturer: ENTREMAT^{IC} Group AB

Entrematic Canada Inc.
221A Racco Parkway
Vaughan, Ontario, L4J 8X9
Phone: 1-877-348-6837

Entrematic USA Inc.
1900 Airport Rd
Monroe, NC, 28110
Phone: 1-866-901-4284

2.02 Automatic "All Glass" Sliding Door System

- A. Automatic "All Glass" Sliding Door System: Shall be DITEC Series DS18. The system shall consist of sliding ½" thick glass door(s) and ½" thick glass sidelight(s), header, jambs, DITEC digital slide system, ¼" threshold (optional), actuating and safety controls. The system shall be completely engineered, manufactured and assembled by ENTREMAT^{IC}. All components shall be factory assembled in the header and tested. Field wiring consists of connection to job-site power and actuators.
- B. Sliding Glass Doors: Provide ½" (12mm) thick glass units to dimension heights and widths with corresponding glazing as shown on plans and specifications. The sliding door system shall include a one-point deadlock securing the bottom stiles to the finished floor via a dustproof strike or ¼" (6mm) thick aluminum threshold (optional). The active panel, bottom rail sliding door lock shall be provided with a key cylinder on the exterior and a thumbturn on the interior.

ENTREMAT^{IC}

- C. Door Operation: Shall be single slide or bi-part slide, one-way or two-way traffic. Sliding panel(s) shall allow “breakout” to the full open position to provide instant egress at any point in the door’s movement.
- D. Aluminum Frame & Extrusions: Shall be a minimum .125” (3mm) in integral structural sections. The frame shall be 4 ½” (114mm) deep x 1 ¾” wide (44mm) section. The bi-part transom package shall contain one vertical transom tube, specify if desired. Transoms are available for ¼” (6mm) or 1” (24mm) glazing.
- E. Aluminum Extrusion Finish: Standard anodized finish shall be Clear, Bronze or Light Bronze. Special anodized, painted and clad finishes are available upon request. Specify type and color.
- F. Fixed ½” (12mm) thick glass Sidelight(s): Provide ½” (12mm) thick tempered glass through mechanically secured sidelight panel(s) to dimension heights and widths as shown on plans and specifications.
- G. Header Case: Shall be 4½” wide x 7½” high (108 mm x 180mm) extruded aluminum. The header shall be capable of supporting a single door leaf of 300 pounds or bi-parting door leaf of 225 pounds each over a span of 16’ with minimal deflection. It shall contain the ENTREMAT^{IC} digital slide system and door mounting components. The header cover shall have a continuous hinge and open flush with the top of the header.
- H. Door Hanger Wheels: Shall be 2½” (64mm) diameter urethane wheels with precision lifetime lubricated ball bearing centres. The sliding door(s) shall be held on the track by 4 Delrin anti riser blocks. The roller track shall be field replaceable. Doors can be adjusted down up to ½”.
- I. Trackless Bottom Door Guides: Aluminum “J” molding guide and pivot rollers shall be required to guide the slide panel(s) from close to open and open to close. The “J” molding is located in the bottom stile of the sidelight(s). Pivot rollers that allow the sliding panel(s) to slide and breakout are located in the heel of the sliding panel(s).
- J. DITEC Digital Slide System: The drive system shall consist of an electromechanical 75W, brushless SPP (Standard Performance Plus) DC motor and enclosed hypoid gear system that offers higher speed range and faster acceleration with maximum opening speed of 750 mm/sec. Provide 120 VAC, 3 amps single-phase power supply minimum to operator.
- K. DS18 Ferrite Chip Control Unit: The DS18 control system shall monitor doorway holding beams, door position, electric lock position, activators, motor temperature, and condition of power. The microprocessor control shall perform on a continuous basis a self-diagnostic system check and shall display faults by flashing LED’s and/or buzzer noise on the control panel. Torque shall be factory set as prescribed by ANSI A156.10. In the event of power failure active doors maybe opened manually.
- L. Electrical: The electrical contractor shall provide 120V AC, 60Hz Single Phase, 15Amp service to the door operator system on a separate dedicated circuit. All wiring shall be housed in a separate channel raceway away from all moving parts. (Motor current draw shall be 3 amps or less for each door operator).

ENTRE/MATIC

- M. Doorway Holding Beams: Doorway holding beams shall be the factory installed at 24" (610 mm) and 48" (1219 mm) from finished floor. The beam when interrupted shall inhibit an open door from closing. A single Doorway beam is also provided to monitor the breakout position of the sliding door panel(s). Breaking of this beam via the top door rail will cut power to the door operator.
- N. Motion Sensor: Activity shall include self contained motion / presence detector mounted on each side of the door for traffic detection in each direction. Unit shall be self monitoring and in physical communication with DS18 control for door(s) to go into fail safe mode in the event of sensor failure.
- O. Reverse on Obstruction with Safety Search Circuitry: The door(s) shall recycle open if an object is encountered during the closing cycle. The circuitry shall time-out for 5 seconds then search for that object at 50% speed on the next closing cycle. If the obstruction is encountered again the door(s) will recycle open. The door(s) shall keep timing-out and recycling at 50% speed until obstruction is cleared. If an object is encountered while opening, the door(s) will stop, reverse direction one inch, time-out for 5 seconds and close at 50% speed. The next opening the circuitry shall search for that object at 50% speed. If the obstruction is encountered again the door(s) shall stop reverse direction one inch, time out and close. The door(s) shall continue recycling at 50% until the object is cleared.
- P. Door Motion Adjustments: The DS18 control digital interface provides the means to make the following door adjustments; open high speed, open low speed, open braking force, close high speed, close low speed, close braking force, opening time.
- Q. Accessories: The DS18 automatic sliding door package shall have the following accessories to reduce energy loss: Nylon sweep(s) on the bottom of the sliding door(s), pressure fitting clear vinyl weather-stripping for the sliding door/side panel meeting vertical edges, single pile weather-stripping between the carrier and the header and the pivot stile(s) of the sliding door(s).
- R. ACCESS CONTROL Options:
 - a) Magnetic Breakaway Latch Device.
 - b) Battery Backup (200 cycle) power supply (concealed within header).
 - c) Electric Lock – Fail Secure or Fail Safe configuration.
 - d) Keyed Multi-Function Program Switches.

2.03 OPERATING CONDITIONS

- A. Climate Conditions: All automatic sliding door system components shall operate between –4 F (-20C) and +120F (50C) in all climate conditions.

3. EXECUTION

3.01 Inspection

- A. Verify that the automatic sliding door system installation will not disrupt other trades. The door installer shall verify that the installation area is dry, clean and free of foreign matter. Check as-built conditions and verify the manufacturer's automatic sliding entrance system details for accuracy to fit the wall assembly prior to fabrication. Report in writing to the Contractor any detrimental conditions to the proper functioning of the automatic sliding entrance system.

Entrematic Canada, Inc.: 877-348-6837, www.ditecentrematic.ca
Entrematic USA, Inc.: 866-901-4284, www.ditecentrematic.us

ENTREMATIC

Installation shall proceed once the unsatisfactory conditions have been corrected in accordance to the manufacturer's recommendations.

3.02 Installation of Automatic Sliding Door System

- A. Installation shall be by an installer approved and trained by the manufacturer in strict accordance with the manufacturer's instructions and fire marshal's listing requirements.
- B. Comply with the automatic sliding door system manufacturer's recommendations and/or installation guide when installing the automatic sliding entrance system. Set all units plumb, level and true.
- C. Provide all fasteners required for installation of the automatic sliding door system.
- D. Adjustment and Cleaning: After repeated operation of the completed installation, re-adjust door operators and controls for optimum operating condition and safety. Clean all metal surfaces promptly after installation.
- E. Explain and review the Daily Safety Check Procedure.

END SECTION 08460

All the rights concerning this material are the exclusive property of Entrematic Group AB. Although the contents of this publication have been drawn up with the greatest care, Entrematic Group AB cannot be held responsible in any way for any damage caused by mistakes or omissions. We reserve the right to make changes without prior notice.