



Images are for illustration purpose only

ENGINE

IVECO heavy duty diesel engine
4-cycle, water cooled, naturally aspirated, direct injection

12/24 Volt starter and charge alternator with battery, rack and cables

Replaceable air, fuel and oil filter

Industrial type radiator

Flexible fuel piping

Oil sump drain valve and extension pipe

Industrial/Residential type exhaust silencer.

Jacket Water Heater

Diesel gen-set maintenance and operating instructions and electrical circuit diagram

ALTERNATOR

Brushless, single bearing, 4-pole alternator coupled with flexible disc coupling

H type insulation class

IP 23 protection

Self exciting

Electronic AVR

CONTROL PANEL

DeepSea mains sensing or remote start control module

Emergency stop push button

Output circuit breaker

Static battery charger

Ready for remote monitoring

CANOPY

Modular type sound-proof canopy

Built from galvanized steel and epoxy, polyester powder painted

Lockable doors on both sides of canopy designed for easy access to essential replacement parts

Emergency stop push button

Control Panel viewing window

Bunded base fuel tank (Optional)

Forklift Pockets (Optional)

Power cable entry with a gland plate

Standby Power

Applicable for supplying power to varying electrical load for the duration of power interruption of a reliable utility source, Overload is not allowed.

Prime Power

The maximum power which a generating set is capable of delivering continuously whilst supplying a variable electrical load. Average load should be 70%. The generator can be overloaded 10% for 1 hour per 12 hrs.

Base Power

Continuous power rating is used in applications where supplying power is at a constant 100% load for an unlimited number of hours each year.



EA Power Systems reserves the right to make changes in model, technical specifications, color, equipment & accessories without prior notice

EA Power Systems Ltd.

3rd Floor St Georges House 6 St Georges Way LE11QZ Leicester

United Kingdom

www.eapowers.com +44(0)1163180570





MODEL		EA275	EA330	EA385	
OUTPUT	Standby	kVA	275	330	385
		kW	220	264	308
	Prime	kVA	250	305	350
		kW	200	244	280
ENGINE	Engine		IVECO	IVECO	IVECO
	Model		NEF67TE8W	CURSOR87TE4	CURSOR13TE2A
	Configuration		INLINE	INLINE	INLINE
	No. of Cylinders		6	6	6
	Speed	rpm	1500	1500	1500
	Displacement	l	6,73	8,7	12,9
	Bore x Stroke	mm	104 x 132	117 x 135	135 x 150
	Compression Ratio		17,5:1	15,9:1	16,5:1
	Aspiration		Turbocharged	Turbocharged	Turbocharged
	Governor Type		Electronic	Electronic	Electronic
	Cooling		Water	Water	Water
	Coolant Capacity	l	25,5	58	68
	Lubrication Oil Capacity	l	17,2	28	35
	Fuel Consumption l/h	100%Load	52	67	76,1
75% Load		41	53	67,4	
50%Load		26	37	52	
ALTERNATOR	Phase		3	3	3
	Pole		4	4	4
	No. of Leads		12	12	12
	Excitation System		AVR	AVR	AVR
	Insulation Class		H	H	H
	IP Protection		IP23	IP23	IP23
	Power Factor		0,8	0,8	0,8
	Frequency	Hz	50	50	50
	Voltage	V	400	400	400
SIZE	Canopy Set Dimensions (LxWxH) & Weight	mm	3600 x 1200 x 2490	3750 x 1400 x 2645	3750 x 1400 x 2645
		kg	2461	3522	3475
	Open Set Dimensions (LxWxH) & Weight	mm	3100 x 1200 x 2490	3175 x 1400 x 2100	3175 x 1400 x 2100
		kg	2143	2982	2934
	Fuel Tank Capacity	l	360	846	846

EA Power Systems reserves the right to make changes in model, technical specifications, color, equipment & accessories without prior notice

EA Power Systems Ltd.

3rd Floor St Georges House 6 St Georges Way LE11QZ Leicester

United Kingdom

www.eapowers.com +44(0)1163180570



CONTROL MODULE

DSE 6 Series Control Module

State of the art, microprocessor controlled

4line, 64 x 132 pixel display LCD display

Automatic mains failure sensing

Front panel manual programming

User friendly setup and button layout

Remote start

Event logging, showing date and time

Stop/Reset, Manual

Displays

Engine Speed (rpm)

Oil pressure

Fuel Level (%)

Coolant temperature

Running Hours

Battery voltage monitoring

Generator Voltage (LL. LN)

Generator Current (L1-L2-L3)

Generator Frequency (Hz)

Generator Load & Power Monitoring (kW. kVA. kVAR.

pf)

Mains Voltage (LL. LN)

Mains Frequency

Generator Set Ready

Mains Ready



Alarms

High coolant temperature

Low Fuel Level

Low oil pressure

Charge failure

Battery Low/High voltage

Fail to start

Fail to stop

High/Low Generator voltage

Generator Over/Under frequency

Generator Over/Under Speed