



Images are for illustration purpose only

### ENGINE

IVECO heavy duty diesel engine  
4-cycle, water cooled, turbocharged,  
direct injection

12/24 Volt starter and charge  
alternator with battery, rack and  
cables

Replaceable air, fuel and oil filter

Industrial type radiator

Flexible fuel piping

Oil sump drain valve and extension  
pipe

Industrial/Residential type exhaust  
silencer.

Jacket Water Heater

Diesel gen-set maintenance and  
operating instructions and electrical  
circuit diagram

### ALTERNATOR

Brushless, single bearing, 4-pole  
alternator coupled with flexible disc  
coupling

H type insulation class

IP 23 protection

Self exciting

Electronic AVR

### CONTROL PANEL

DeepSea mains sensing or remote  
start control module

Emergency stop push button

Output circuit breaker

Static battery charger

Ready for remote monitoring

### CANOPY

Modular type sound-proof canopy

Built from galvanized steel and epoxy,  
polyester powder painted

Lockable doors on both sides of  
canopy designed for easy access to  
essential replacement parts

Emergency stop push button

Control Panel viewing window

Bunded base fuel tank (Optional)

Forklift Pockets (Optional)

Power cable entry with a gland plate

### Standby Power

Applicable for supplying  
power to varying electrical  
load for the duration of  
power interruption of a  
reliable utility source,  
Overload is not allowed.

### Prime Power

The maximum power  
which a generating set is  
capable of delivering con-  
tinuously whilst supplying  
a variable electrical load.  
Average load should be  
70%.The generator can  
be overloaded 10% for 1  
hour per 12 hrs.

### Base Power

Continuous power rating  
is used in applications  
where supplying power is  
at a constant 100% load  
for an unlimited number  
of hours each year.



EA Power Systems reserves the right to make changes in model, technical specifications, color, equipment & accessories without prior notice

EA Power Systems Ltd.

3rd Floor St Georges House 6 St Georges Way LE11QZ Leicester

United Kingdom

www.eapowers.com +44(0)1163180570

Registered in England & Wales No:11023250





MODEL		EA440	EA550	EA660	
OUTPUT	Standby	kVA	440	550	660
		kW	352	440	528
	Prime	kVA	400	500	600
		kW	320	400	480
ENGINE	Engine		IVECO	IVECO	IVECO
	Model		CURSOR13TE3A	CURSOR13TE7W	CURSOR16TE1W
	Configuration		INLINE	INLINE	INLINE
	No. of Cylinders		6	6	6
	Speed	rpm	1500	1500	1500
	Displacement	l	12,88	12,9	15,9
	Bore x Stroke	mm	135 x 150	135 X 150	141 X 170
	Compression Ratio		16,5:1	16,5:1	15,9:1
	Aspiration		Turbocharged	Turbocharged	Turbocharged
	Governor Type		Electronic	Electronic	Electronic
	Cooling		Water	Water	Water
	Coolant Capacity	l	68	38,1	52,5
	Lubrication Oil Capacity	l	35	35	38
	Fuel Consumption l/h	100%Load	86	101	117
75% Load		70	80	93	
50%Load		43	52	59	
ALTERNATOR	Phase		3	3	3
	Pole		4	4	4
	No. of Leads		12	12	12
	Excitation System		AVR	AVR	AVR
	Insulation Class		H	H	H
	IP Protection		IP23	IP23	IP23
	Power Factor		0,8	0,8	0,8
	Frequency	Hz	50	50	50
	Voltage	V	400	400	400
SIZE	Canopy Set Dimensions (LxWxH) & Weight	mm	3750 x 1400 x 2645	3705 x 1400 x 2645	3705 x 1400 x 2645
		kg	3522	4750	4975
	Open Set Dimensions (LxWxH) & Weight	mm	3175 x 1400 x 2100	3450 x 1400 x 1885	3450 x 1400 x 1885
		kg	2982	4303	4528
	Fuel Tank Capacity	l	846	880	880

EA Power Systems reserves the right to make changes in model, technical specifications, color, equipment & accessories without prior notice

EA Power Systems Ltd.

3rd Floor St Georges House 6 St Georges Way LE11QZ Leicester

United Kingdom

www.eapowers.com +44(0)1163180570

Registered in England & Wales No:11023250





### CONTROL MODULE

DSE 6 Series Control Module

State of the art, microprocessor controlled

4line, 64 x 132 pixel display LCD display

Automatic mains failure sensing

Front panel manual programming

User friendly setup and button layout

Remote start

Event logging, showing date and time

Stop/Reset, Manual

### Displays

Engine Speed (rpm)

Oil pressure

Fuel Level (%)

Coolant temperature

Running Hours

Battery voltage monitoring

Generator Voltage (LL. LN)

Generator Current (L1-L2-L3)

Generator Frequency (Hz)

Generator Load & Power Monitoring (kW. kVA. kVAR.

pf)

Mains Voltage (LL. LN)

Mains Frequency

Generator Set Ready

Mains Ready



### Alarms

High coolant temperature

Low Fuel Level

Low oil pressure

Charge failure

Battery Low/High voltage

Fail to start

Fail to stop

High/Low Generator voltage

Generator Over/Under frequency

Generator Over/Under Speed

