

Using IP Office Embedded Voicemail IP Office Mode

© 2021, Avaya Inc. All Rights Reserved.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published in varying mediums which may include product information, operating instructions and performance specifications that are generally made available to users of products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless such modifications, additions, or deletions were performed by or on the express behalf of Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or Documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on Avaya hardware and software. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product while under warranty is available to Avaya customers and other parties through the Avaya Support website: https://support.avaya.com/helpcenter/getGenericDetails?detailld=C20091120112456651010 under the link "Warranty & Product Lifecycle" or such successor site as designated by Avaya. Please note that if You acquired the product(s) from an authorized Avaya Channel Partner outside of the United States and Canada, the warranty is provided to You by said Avaya Channel Partner and not by Avaya.

"Hosted Service" means an Avaya hosted service subscription that You acquire from either Avaya or an authorized Avaya Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Avaya or Avaya Channel Partner (as applicable) for more information.

Hosted Service

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN AVAYA HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE), THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO UNDER THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO UNDER THE LINK "AVAYA SOFTWARE LICENSE TERMS (Avaya Products)" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AVAYA CHANNEL PARTNER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA CHANNEL PARTNER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants You a license within the scope of the license types described below, with the exception of Heritage Nortel Software, for which the scope of the license is detailed below. Where the order documentation does not expressly identify a license type, the applicable license will be a Designated System License as set forth below in the Designated System(s) License (DS) section as applicable. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the documentation or other materials available to You. "Software" means computer programs in object code, provided by Avaya or an Avaya Channel Partner, whether as stand-alone products, pre-installed on hardware products, and any upgrades, updates, patches, bug fixes, or modified versions thereto. "Designated Processor" means a single stand-alone computing device. "Server" means a set of Designated Processors that hosts (physically or virtually) a software application to be accessed by multiple users. "Instance" means a single copy of the Software executing at a particular time: (i) on one physical machine; or (ii) on one deployed software virtual machine ("VM") or similar deployment.

License type(s)

Designated System(s) License (DS). End User may install and use each copy or an Instance of the Software only: 1) on a number of Designated Processors up to the number indicated in the order; or 2) up to the number of Instances of the Software as indicated in the order, Documentation, or as authorized by Avaya in writing. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, Instance, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time as indicated in the order, Documentation, or as authorized by Avaya in writing. A "Unit" means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an email or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software. Units may be linked to a specific, identified Server or an Instance of the Software.

Cluster License (CL). End User may install and use each copy or an Instance of the Software only up to the number of Clusters as indicated on the order, Documentation, or as authorized by Avaya in writing with a default of one (1) Cluster if not stated.

Enterprise License (EN). End User may install and use each copy or an Instance of the Software only for enterprise-wide use of an unlimited number of Instances of the Software as indicated on the order, Documentation, or as authorized by Avaya in writing.

Named User License (NU). End User may: (i) install and use each copy or Instance of the Software on a single Designated Processor or Server per authorized Named User (defined below); or (ii) install and use each copy or Instance of the Software on a Server so long as only authorized Named Users access and use the Software as indicated in the order, Documentation, or as authorized by Avaya in writing. "Named User", means a user or device that has been expressly authorized by Avaya to access and use the Software. At Avaya's sole discretion, a "Named User" may be, without limitation, designated by name, corporate function (e.g., webmaster or helpdesk), an e-mail or voice mail account in the name of a person or corporate function, or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software.

Shrinkwrap License (SR). End User may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License") as indicated in the order, Documentation, or as authorized by Avaya in writing.

Transaction License (TR). End User may use the Software up to the number of Transactions as specified during a specified time period and as indicated in the order, Documentation, or as authorized by Avaya in writing. A "Transaction" means the unit by which Avaya, at its sole discretion, bases the pricing of its licensing and can be, without limitation, measured by the usage, access, interaction (between client/server or customer/organization), or operation of the Software within a specified time period (e.g. per hour, per day, per month). Some examples of Transactions include but are not limited to each greeting played/message waiting enabled, each personalized promotion (in any channel), each callback operation, each live agent or web chat session, each call routed or redirected (in any channel). End User may not exceed the number of Transactions without Avaya's prior consent and payment of an additional fee.

Heritage Nortel Software

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software is the software contained within the list of Heritage Nortel Products located at https://support.avaya.com/LicenseInfo under the link "Heritage Nortel Products" or such successor site as designated by Avaya. For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Avaya. All content on this site, the documentation, Hosted Service, and the product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Unless otherwise stated, each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two Instances of the

same type of products, then two products of that type must be ordered

Third Party Components

"Third Party Components" mean certain software programs or portions thereof included in the Software or Hosted Service may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). As required, information regarding distributed Linux OS source code (for those products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the products, Documentation or on Avaya's website at: https:// support.avaya.com/Copyright or such successor site as designated by Avaya. The open source software license terms provided as Third Party Terms are consistent with the license rights granted in these Software License Terms, and may contain additional rights benefiting You, such as modification and distribution of the open source software. The Third Party Terms shall take precedence over these Software License Terms, solely with respect to the applicable Third Party Components to the extent that these Software License Terms impose greater restrictions on You than the applicable Third Party Terms.

The following applies only if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM.

Service Provider

THE FOLLOWING APPLIES TO AVAYA CHANNEL PARTNER'S HOSTING OF AVAYA PRODUCTS OR SERVICES. THE PRODUCT OR HOSTED SERVICE MAY USE THIRD PARTY COMPONENTS SUBJECT TO THIRD PARTY TERMS AND REQUIRE A SERVICE PROVIDER TO BE INDEPENDENTLY LICENSED DIRECTLY FROM THE THIRD PARTY SUPPLIER. AN AVAYA CHANNEL PARTNER'S HOSTING OF AVAYA PRODUCTS MUST BE AUTHORIZED IN WRITING BY AVAYA AND IF THOSE HOSTED PRODUCTS USE OR EMBED CERTAIN THIRD PARTY SOFTWARE, INCLUDING BUT NOT LIMITED TO MICROSOFT SOFTWARE OR CODECS, THE AVAYA CHANNEL PARTNER IS REQUIRED TO INDEPENDENTLY OBTAIN ANY APPLICABLE LICENSE AGREEMENTS, AT THE AVAYA CHANNEL PARTNER'S EXPENSE, DIRECTLY FROM THE APPLICABLE THIRD PARTY SUPPLIER.

WITH RESPECT TO CODECS, IF THE AVAYA CHANNEL PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED THE H.264 CODEC OR H.265 CODEC, THE AVAYA CHANNEL PARTNER ACKNOWLEDGES AND AGREES THE AVAYA CHANNEL PARTNER IS RESPONSIBLE FOR ANY AND ALL RELATED FEES AND/OR ROYALTIES. THE H.264 (AVC) CODEC IS LICENSED UNDER THE AVC PATENT PORTFOLIO LÍCENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO: (I) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (II) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP:// WWW.MPEGLA.COM.

Compliance with Laws

You acknowledge and agree that it is Your responsibility for complying with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Avaya product is used.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services

Avaya Toll Fraud intervention

If You suspect that You are being victimized by Toll Fraud and You need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: https://support.avaya.com or such successor site as designated by Avaya.

Security Vulnerabilities

Information about Avaya's security support policies can be found in the Security Policies and Support section of https://support.avaya.com/security.

Suspected Avaya product security vulnerabilities are handled per the Avaya Product Security Support Flow (https://support.avaya.com/css/P8/documents/100161515).

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: https://support.avaya.com, or such successor site as designated by Avaya.

Contact Avaya Support

See the Avaya Support website: https://support.avaya.com for product or Hosted Service notices and articles, or to report a problem with your Avaya product or Hosted Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: https://support.avaya.com (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, its licensors, its suppliers, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners. Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

Contents

Chapter 1: Embedded Voicemail	6
Which Voicemail Do I Have?	6
Logging in normally	7
Trusted sources introduction	7
Default mailbox controls	7
Caller options overview	ξ
Full mailbox introduction	ξ
Chapter 2: Listen to messages	10
Listening to your messages	10
Saving a message	11
Forwarding a message	11
Calling the sender	11
Chapter 3: Change your mailbox settings	12
Changing your password	12
Trusted sources and system administration	12
Recording your greeting	13
Listening to your greeting	14
Transfer options overview	14
Recording your name	14
Chapter 4: Voicemail notification	16
Chapter 5: Voicemail Email	17
Switching on email notification	
Switching off email notification	
Chapter 6: Outcalling	19
Configuring initial outcalling	
Setting your outcalling destination	
Setting your outcalling timeout	
Turning outcalling on	
Turning outcalling off	
Answering outcalling calls	
Cancel message notification	
Chapter 7: Visual voice introduction	
Visual voice controls	24

Chapter 1: Embedded Voicemail

This document covers mailbox operation on IP Office system using Embedded Voicemail running in Intuity mailbox mode. If you are not sure which system you have and the mode it is operating in, see Which Voicemail Do I Have? on page 6.

Which Voicemail Do I Have?

The operation of voicemail is highly customizable. So it is important that you use the correct mailbox guide:

How Do I Determine Which Guide to Use?

Your system administrator can tell you what type of voicemail your Avaya IP Office system is using. However, the following process may help you to determine it for yourself:

- 1. On your phone, dial *17 to access voicemail.
- 2. After the initial greeting, if the voicemail asks "Please enter extension and pound key", then the voicemail system is running in Intuity mode. Otherwise, go to step 3.
 - a. Press 7. If the system responds with a set of scan options, your voicemail server is Voicemail Pro.
 - b. If the system doesn't respond, your voicemail server is Embedded Voicemail.
- 3. If otherwise, your voicemail system is running in IP Office mode. Press *05.
 - a. If the system responds with a set of options, your voicemail server is Embedded Voicemail.
 - b. If the system doesn't respond, your voicemail server is Voicemail Pro.

Depending on the above, the following mailbox user guides are available:

- Using IP Office Embedded Voicemail IP Office Mode
- Using IP Office Embedded Voicemail Intuity Mode
- Using a Voicemail Pro Intuity Mode Mailbox
- Using a Voicemail Pro IP Office Mode Mailbox

Logging in normally

Procedure

- 1. At your own extension, dial *17.
- 2. If requested, enter your password and press #.

The system requests a password if you are accessing a mailbox from a number not set as a trusted source for that mailbox.

- 3. After you log in, the voice prompts provide instructions. See Default Mailbox Controls for a summary of the controls.
 - For help at any time: Press *4.
 - To return to the activity menu: Press 8.

Trusted sources introduction

By default, even when you have a password set, you can access your mailbox from your own extension without needing to use the password. This is because your extension number is set as a 'trusted source'. Your system maintainer can change that if required. They can also add other numbers as trusted sources for your mailbox if required.

Mailbox access from numbers that are not trusted sources requires entry of your mailbox password.

Example

Entry of your password is usually required if your maintainer has configured a method for you to access your mailbox from remote locations other than your own extension.

Default mailbox controls

The following is a summary of the options that are available after you have logged into a mailbox.

New messages start playing by default.	Configuration
• Play old messages = 1	• Edit greeting = 3
• Play saved messages = 2	• Record Name = *05
• Fast forward = #	Change mailbox code = *04
• Rewind = *	Direct all to email = *01
• Repeat last message = 7	Send email notification = *02
• Skip current message = 9	• Turn email off = *03
Delete current message = 4	Outcalling options = *07
• Save current message = 5	• Help = *4
• Mark Message as new = *06	
• Call back sender = **	
• Forward message = 6	
3. Edit Greeting	6. Forwarding
Listen to greeting = 1	Forward to extensions = 2
• Record new greeting = 2	Forward with header message = 3
• Save new greeting =3	[Follow each extension number with # and then a
• Save new greeting as a loop = 4	final # to finish.]
• Return to mailbox = 8	
*07. Outcalling	
• Listen to settings = 0	
Configure outcalling = 1	
• Turn outcalling off = 6	
• Turn outcalling on = 9	
• Return to mailbox = 8	

Note:

Old Messages are automatically deleted after 24 hours.

After you listen to new message, it is marked as 'old' and it is automatically deleted after 24 hours. If you do not want the message deleted, you must mark it as a 'saved' message.

• To mark the current message as saved, press **5** while listening to the message.

You can also use the following short codes to control your mailbox. These are default system features, however your system maintainer can change them. For users with Avaya telephones that include programmable buttons, your system administrator can also assign these functions to buttons.

• Turn Voicemail On: *18

Causes calls to go to voicemail when you are busy or do not answer. If the extension to which you forward your calls does not answer calls will also go to voicemail.

- Turn Voicemail Off: *19

Voicemail Ringback On: *48

If ringback is on, when you have new messages, the voicemail system will ring you following the completion of any call.

- Voicemail Ringback Off: *49

Caller options overview

Callers to your mailbox can perform the following actions:

- **Skip Your Mailbox Greeting**: Callers can skip your greeting message and go straight to leaving a message by pressing **1**.
- **Transfer to another number**: Depending on your settings, the caller can select a transfer to another extension rather than leaving a message.
- Leave a message: After hearing the tone, your caller can start recording a message. The system only saves messages that are longer than 3 seconds. The default maximum message length is 120 seconds. However, the system administrator can adjust that.
- Options after leaving a message: After leaving a mailbox message, callers can press # rather than hanging up immediately. The caller hears a prompt informing them if the system saved the message. The system then disconnects the call.

Full mailbox introduction

When a mailbox is full and unable to store new voicemail messages, the voicemail system plays an information message and disconnects the call.

Chapter 2: Listen to messages

This section covers actions you can perform while listening to your messages.

The system groups messages into the following categories:

- New: After you have listened to a new message, it automatically becomes an old message.
- **Saved**: This category applies to messages you marked as saved . You would normally do this for messages that you do not want the system to automatically delete.
- **Old**: After you have listened to a new message it automatically becomes an old message. Unless you delete them sooner, the system automatically deletes old messages after 24 hours.

When you get your messages, the system automatically starts playing your new messages if you have any. After each message, the system plays details of when the message was left and the caller.

Listening to your messages

Procedure

- 1. Log in to your mailbox.
- 2. If you have any new messages, the system starts playing them.
 - To switch to playing old messages: Press 1.
 - To switch to playing saved messages: Press 2.
- 3. While playing a message, you can use the following options:
 - · To fast forward: Press #.
 - To rewind: Press *.
 - To repeat the last message: Press 7.
 - To skip the current message: Press 9.
 - To delete the current message: Press 4.
 - To mark the message as saved: Press 5.
 - To call back the sender: Press **.
 - To forward the message: Press 6.

Saving a message

About this task

Once you have played a message it is marked as old. The system automatically deletes old messages after 24 hours. To stop this happening to the current message, you can mark it as being a saved message.

Procedure

Press **5** when listening to a new or old message.

Forwarding a message

About this task

You can forward a message to a different mailbox or to several mailboxes at the same time. When you do this, you can record a comment at the start of the message.

Procedure

- 1. While listening to the message, press 6.
 - To forward the message as is, press 2.
 - To add a comment before forwarding, press **3**. After the tone, record your comment and press **#** to finish recording.
- 2. Enter the extension number to forward the message and press #.
- 3. If you want to send the message to more than one extension, repeat the process of enter each extension number followed by #.
- 4. Press # to finish addressing and forward the message.

Calling the sender

About this task

When an internal caller leaves a message, the system will capture the caller's number and store that with the message. You can choose to make a call to the caller's number.

Procedure

While listening to a message, press **.

Chapter 3: Change your mailbox settings

This section covers the changing general mailbox settings.

Changing your password

About this task

You are not required to set a password for your mailbox if you only access it from your own extension. For access to your mailbox from other locations, including in response to Outcalling, you will need to have a password set. If you do set a password it is used, however when accessing your mailbox from certain trusted sources (see below), you will not need to enter it. By default, the system sets your extension as a trusted source.

Procedure

- 1. Log in to your mailbox.
- 2. Press *04 to change your password.
- 3. Enter your current password and press #. If you have no current password just press #.
- 4. Enter your new password followed by #.

Enter at least four digits and up to 15. Do not set an obvious code. For example:

- Your extension number.
- A sequence of digits, for example 1234.
- The same repeated digits, for example 1111.
- 5. Re-enter your new password followed by #.
 - The system will prompt you if the codes do not match or is not acceptable. It will also confirm the change of password if successful.

Trusted sources and system administration

By default, even when you have a password set, you can access your mailbox from your own extension without needing to use the password. This is because your extension number is set as a

'trusted source'. Your system maintainer can change that if required. They can also add other numbers as trusted sources for your mailbox if required.

Mailbox access from numbers that are not trusted sources requires entry of your mailbox password. For example, entry of your password is usually required if your maintainer has configured a method for you to access your mailbox from remote locations other than your own extension.

System Administration

The system administrator cannot see your password. However, they are able to clear your existing password.

Recording your greeting

About this task

By default, callers to your mailbox hear the default system greeting. You can replace this with a personal greeting.

You can record the greeting heard by callers to your voicemail. At any time, you can listen to a greeting message and re-record it.

A greeting must be longer than 3 seconds. The maximum length of a greeting is 120 seconds by default.

Procedure

- 1. Log in to your mailbox.
- 2. Press **3** to select the option to edit your greeting.
- 3. Press 2 to change your greeting.
- 4. When prompted, speak your new greeting.
 - The greeting must be longer than 3 seconds.
 - A long (approximately 10 seconds) period of silence will disconnect you from voicemail.
- 5. Press **2** when you have finished recording your greeting.
- 6. Press 1 to listen to your new greeting. After you have listened to your greeting:
 - To save the new greeting: Press 3.
 - To re-record the new greeting: Press 2.
 - To save the new greeting as a continuous loop: Press 4.

Callers are not able to leave messages.



☑ Note:

When you select this option, you can only change the greeting back to a normal greeting by recording a new greeting.

Listening to your greeting

About this task

If you want to check your greeting, use the following process.

Procedure

- 1. Log in to your mailbox.
- 2. Press 3 to select the option to edit your greeting.
- 3. Press 1 to hear your greeting.

If no greeting has been recorded your will hear "The message has not yet been recorded".

Transfer options overview

Your system administrator can set up to 3 transfer numbers for your mailbox. When a caller to your mailbox presses **0**, **2** or **3**, the system transfers them to the matching number configured by your system administrator. Typically, this feature allows the system to transfer callers to the receptionist or one of your colleagues.

Contact your system administrator to find out if they have set any transfer numbers for your mailbox. When this feature is set, remember to alter your mailbox greeting in order to inform callers of the options they can use.

Recording your name

About this task

You hear your name played as a confirmation when you log in to your mailbox. The system also uses it for other system announcements and functions. You can change your name recording at any time.

Procedure

- 1. Log in to your mailbox.
- 2. Press *05 to select the option to record your name.
- 3. Press **1** to hear your current recording.
- 4. Press 2 to record your name. When prompted, speak your name.

The maximum recorded length is 5 seconds.

5. Press **2** when you have finished recording your name.

- 6. Press **1** to listen to your new recording. Review the recording and select one of the following options:
 - To save the new recording: Press 3.
 - To record your name again: Press 2.

Chapter 4: Voicemail notification

There are several ways that the system can alert you when you have a new message.

- Message Waiting Lamp: Most Avaya telephones include a message waiting lamp, typically at
 the top right of the phone. This lamp lights when your mailbox contains any new messages that
 you have not heard. In addition, many Avaya phones have a MESSAGE button which also
 lights when your mailbox contains new messages.
 - Your system administrator can also configure your message indicators to light when a group mailbox contains new messages. You can then see and access that additional mailbox through Visual Voice.
- **Ringback**: If you enable ringback, whenever you use your phone, immediately after completing the call the system will automatically call you if your mailbox contains any new messages. This is useful if you have a telephone that does not have a message waiting lamp or button.
 - To switch ringback on: Dial *48.
 - To switch ringback off: Dial *49.
- Outcalling: Outcalling allows you to specify a number that the system calls when your mailbox contains any new messages. If you answer the call, the system prompts you to login to hear your messages.
- **Voicemail Email**: The voicemail system can send an email whenever your mailbox receives a new message. The email can be just a simple alert that you have a new message or it can also include an attached copy of the message.

Chapter 5: Voicemail Email

You can have notification of new messages sent to your email address. The notification can be a simple alert to tell you that you have a message or a copy of the voicemail message if required.

- Email Address/Enabling Voicemail Email Functions
 - Before you can use the email options, your system administrator must enter your email address into the telephone system configuration. Otherwise, you hear the message 'Email is not enabled on this mailbox' whenever you try to use an email option. Your system administrator can tell you whether they have configured your mailbox to use email.
- In addition to the functions described in this section, if you have an Avaya telephone that supports Visual Voice, you can use **Visual Voice** to control your **Voicemail Email** settings. See <u>Visual voice introduction</u> on page 24.

Related links

<u>Switching on email notification</u> on page 17 <u>Switching off email notification</u> on page 18

Switching on email notification

About this task

When you switch on email notification, you can also select the type of notification required.

Procedure

- 1. Log in to your mailbox.
- 2. Select the required type of email notification.
 - For an email alert: Press *02. When you have a new voicemail message in your mailbox, you will receive an email advising you of this.
 - To have the message forwarded to your email: Press *01. When you have a new voicemail message in your mailbox, the system forwards it to your email address as an attachment. The system deletes the original message from your mailbox.

Related links

Voicemail Email on page 17

Switching off email notification

About this task

You can turn off email notification when it is not required. Doing this does not change your other email settings.

Procedure

- 1. Log in to your mailbox.
- 2. Press *03.

You hear a confirmation message.

Related links

Voicemail Email on page 17

Chapter 6: Outcalling

You can receive notification of a new voice message by using the outcalling feature. When you receive a new message, the voicemail system notifies you by calling a number that you have set. You can then retrieve the message from the number at which you received the notification. Systems running Release 7.0 or higher support this option.

Each outcalling alert rings for a duration you can set. The default is 15 seconds. The call ends if not answered. If answered, the system prompts you to enter your mailbox password. When answer, the outcalling call automatically ends if:

- You press *# to indicate that you do not want any more outcalling calls for the current new messages.
- You enter the wrong password 3 times.
- More than 5 minutes passes with no response.

Up to 3 outcalling calls are attempted, with a minimum of 15-minutes between calls, unless you answer and press *# or access your mailbox by another method. If you receive any more new messages in the meantime they do not restart the outcalling attempts.

Related links

Configuring initial outcalling on page 19

Setting your outcalling destination on page 20

Setting your outcalling timeout on page 21

Turning outcalling on on page 21

Turning outcalling off on page 22

Answering outcalling calls on page 22

Configuring initial outcalling

About this task

The first time you access the outcalling menus, the system prompts you to set a destination number for outcalling alerts.

Once set, you can then change the number, turn outcalling on, turn outcalling off and change the timeout used for how long outcalling calls ring.

Procedure

1. Press *07.

An announcement tells you that you have not configured outcalling.

2. Press 1 to configure your outcalling options.

You need to specify the destination telephone number where you want to receive your new voicemail notification.

3. When you have configured an outcalling destination number, you can turn outcalling on/off.

Related links

Outcalling on page 19

Setting your outcalling destination

About this task

You can add or change the telephone number that outcalling uses.

Procedure

- 1. Log in to your mailbox.
- 2. Press *07 to access your outcalling settings.
- 3. Press 1.
- 4. Press 2 for number entry.
- 5. Press **1** and then enter the number that you want outcalling to call. Remember to include any external dialing prefix that you would normally dial to make the call.
 - A * in the number is treated as a pause (1.5 seconds) in the dialing.
 - To enter a # into the number: Dial *#.
 - You can also use internal numbers as your outcalling destination. The calls will follow any internal forwarding and will honor do not disturb. However, the outcalling attempt ends if the call goes to voicemail.
- 6. Press # to finish number entry.

Related links

Outcalling on page 19

Setting your outcalling timeout

About this task

The timeout controls how long the outcalling call rings the destination number before hanging up if not answered. The default is 15 seconds with the maximum being 59 seconds.

If the destination specified is an internal number, outcalling does not go to voicemail if unanswered. However, if the destination is an external number with its own voicemail, the timeout must be set to less than the time before the external voicemail might answer. For example, if you have voicemail active for your mobile telephone, where any calls go to voicemail if not answered after 30 seconds, you must set the outcalling timeout to less than 30 seconds.

Procedure

- 1. Log in to your mailbox.
- 2. Press *07 to access your outcalling settings.
- 3. Press 1.
- 4. Press 3 for timeout entry.
- 5. Enter a number between 5 and 59 and then press #.

Related links

Outcalling on page 19

Turning outcalling on

About this task

Once you have a set an outcalling destination, you can choose to switch outcalling on.

Procedure

- 1. Log in to your mailbox.
- 2. Press *07 to access your outcalling settings.
- 3. Press 9 to switch outcalling on.

Related links

Outcalling on page 19

Turning outcalling off

About this task

You can turn outcalling off. Doing this does not delete the outcalling number or timeout you have set.

Procedure

- 1. Log in to your mailbox.
- 2. Press *07 to access your outcalling settings.
- 3. Press 6 to switch outcalling off.

Related links

Outcalling on page 19

Answering outcalling calls

About this task

When you have a new message, the system tries to call your outcalling destination number three times with a 15-minute interval between each call.

Procedure

- 1. Answer the outcalling alert.
- When you hear the outcalling announcement, enter your extension number and press #.Log in to voicemail in the usual way and collect your new message.

Related links

Outcalling on page 19

Cancel message notification on page 22

Cancel message notification

About this task Procedure

- 1. Answer the outcalling alert.
- 2. When you hear the outcalling announcement, enter *#.

The system cancels any further outcalling for that new message. You still receive outcalling alerts for any subsequent new message.

Related links

Answering outcalling calls on page 22

Chapter 7: Visual voice introduction

Visual Voice allows you to access your mailbox using the display menu of your phone rather than following spoken mailbox prompts. Not all phones support Visual Voice.

To use Visual Voice your system maintainer must add a **Visual Voice** button to your phone. Alternatively, your system maintainer can set the MESSAGES button on your phone to act as a **Visual Voice** button.

- On phones that have a display but do not support visual voice operation, use of the button for user mailbox access using voice prompts and for direct to voicemail transfer during a call is supported (does not include T3 and T3 IP phones).
- On T3 phones, the **Visual Voice** button goes direct to the **Listen function of Visual Voice**. To access the full set of Visual Voice functions use **Menu** > **Settings** > **Voicemail Settings**.

Using visual voice button for voicemail transfer

If pressed when you have a call is connected, the **Visual Voice** button allows entry of an extension number for direct to voicemail transfer of the connected call.

Related links

Visual voice controls on page 24

Visual voice controls

The arrangement of options on the screen will vary depending on the phone type and display size. You can access controls not shown on the current display by using the phone's < and > buttons to move between screen pages.

Button	Functions
Listen	Accesses your mailbox. When pressed, the screen shows the number of New , Old and Saved messages. Select one of those options to start playback of messages in that category. Once message playback is selected, the available controls change:
	Previous: Play the previous message.
	Next: Play the next message.
	Rewind: Rewind approximately 5 seconds.
	FFwd: Step forwards approximately 5 seconds.
	Delete: Delete the current message.
	Save: Mark the messaged as a saved message.
	• Copy: Copy the message to another mailbox. When pressed, the phone displays:
	- Pre-Rec : Record a message to attach to the start of the copied message.
	- Targets: Enter the destination for the message copy.
	- Done : Copy the message using the targets entered.
	Pause: Pause the current message. Press the button again to unpause.
Main(0)	Hunt group names may be displayed you have been configured for hunt group mailbox access. The number shows the number of new messages in the mailbox. Press the button to access the mailbox in the same way as the Listen option above.
Message	Record and send a voicemail message to another mailbox or mailboxes.
Greeting	Change the main greeting used for callers to your mailbox. If you have not recorded a greeting, the system's uses its default mailbox greeting.
	Record: Record a new greeting.
	Listen: Listen to the current greeting or the new greeting just recorded.
	Submit: Submit the new greeting just recorded.
	Delete: Delete the current greeting. The mailbox reverts to using the default system greeting.
Email	This system shows this option if you have a configured email address for voicemail email usage in the telephone system configuration. This control allows you to see and change the current voicemail email option used for new messages received by your mailbox. Use Change to change the mode displayed. Press Done to save the change. The modes are:
	Email Mode Off: Voicemail email is not used.
	Email Mode Copy: Copy new voicemail messages to the email address, leaving the original message in the mailbox.
	 Email Mode Fwd: Forward new voicemail messages to the email address, deleting the original message from the mailbox.
	Email Mode Alert: Send an alert email message to the email address, leaving the message in the mailbox.

Table continues...

Visual voice introduction

Button	Functions
Password	Change the mailbox password. To do this requires entry of the existing password.
Voicemail	Switch voicemail usage on or off. When off, the voicemail system does not answer unanswered calls.

Related links

Visual voice introduction on page 24

Index

answering outcalling	A	M	
C	answering outcalling	mailbox controls	<u>7</u>
Calls ender		mailbox introduction	<u>9</u>
Call sender	•	Mailbox mode	<u>6</u>
Caller option Section Section	C	message forwarding	<u>11</u>
caller overview .9 N calling sender .11 name record .14 cancel message .22 normal login .7 change setting overview .12 .2 changing password .12 .2 Changing settings .12 .2 configuring initial outcalling .19 outcalling calls .22 configuring initial outcalling .19 outcalling alls .22 outcalling calls .22 outcalling alls .22 outcalling ff .22 outcalling of .22 outcalling imeout .21 .21 email notification .17 .18 embedded overview .6 .6 embedded voicemail .6 .6 Embedded Voicemail .6 .6 F record greeting .13 forward message .11 recording name .14 full mailbox .9 .9 G .1 .2 <td< td=""><td>call sender11</td><td>message saving</td><td><u>11</u></td></td<>	call sender11	message saving	<u>11</u>
caller overview .9 N calling sender .11 name record .14 cancel message .22 normal login .7 change setting overview .12 .2 changing password .12 .2 Changing settings .12 .2 configuring initial outcalling .19 outcalling calls .22 configuring initial outcalling .19 outcalling alls .22 outcalling calls .22 outcalling alls .22 outcalling ff .22 outcalling of .22 outcalling imeout .21 .21 email notification .17 .18 embedded overview .6 .6 embedded voicemail .6 .6 Embedded Voicemail .6 .6 F record greeting .13 forward message .11 recording name .14 full mailbox .9 .9 G .1 .2 <td< td=""><td></td><td></td><td></td></td<>			
calling sender .11 cancel mostification .22 change setting overview .12 changing password .12 Changing settings .12 configuring initial outcalling .19 outcalling calls .22 outcalling destination .20 outcalling off .22 outcalling on .21 contracting off .22 outcalling on .21 outcalling on .21 contracting on .21 contracting inteneut .21 permiseded overview .6 embedded voicemail .6 Embedded Voicemail .6 F record greeting .13 forward message .11 full mailbox .9 G Save a message .11 full mailbox .9 G Save a message .11 full mailbox .9 G Save a message .11 full mailbox	-	N	
cancel message 22 name record 14 cancel notification 22 normal login 7 change setting overview 12 0 Changing password 12 0 Changing settings 12 0 configuring initial outcalling 19 outcalling calls 22 configuring initial outcalling 19 outcalling calls 22 default mailbox 7 outcalling off 22 default mailbox 7 outcalling off 22 uctalling off 22 outcalling off 22 outcalling off 22 outcalling off 22 uctalling off 22 outcalling off 22 uctalling off 22 outcalling off 22 uctalling off 22 outcalling off 22 password changing 12 answord changing 12 password changing 12 answord changing 12 password changing 12 answord changing 13		IV.	
cancel notification 22 normal login 7 change setting overview 12 changing password 12 changing password 12 changing settings 12 changing settings 12 changing settings 12 changing settings 19 cutcalling destination 19 cutcalling calls 22 cutcalling on 20 cutcalling on 22 cutcalling on 23 cutcalling on 24 cutcalling on 24 cutcalling on 25 cutcalling on 26 cutcalling on 27 cutcalling on 27 cutcalling on 28 cutcalling on 28 cutcalling on 28 cutcalling on 28 cutcalling on 29 cutcalling on	_	name record	14
Changing pastword			
changing password 12 Changing settings 12 outcalling 19 outcalling 19 outcalling 19 outcalling 19 outcalling calls 22 outcalling destination 20 outcalling destination 20 outcalling off 22 outcalling on 21 outcalling on 22 outcalling on 22 outcalling on 22 outcalling on 22 outcalling on 21 outcalling imeout 21 outcalling on 22 outcalling imeout 21 outcalling on 22 outcalling on 22 outcalling on 22 outcalling on 22 outcalling imeout 24 outcalling on 22 outcalling imeout 28 outcalling on 22 outcalling imeout 22 outcalling imeout 23 outcalling imeout 23 outcalling imeout 24 outcalling imeout 25 outcalling imeout 26 outcalling imeout 26 outcalling imeout 26 outcalling imeout 26 outcalling imeout 27 outcalling imeout 27 outcalling imeout 28 outcalling imeout 28 outcalling imeout 28 outcalling imeout 29 outcalling imeout	 -		_
Changing settings			
19 0utcalling 19 0utcalling 19 0utcalling 20 19 0utcalling destination 20 20 20 21 22 21 22 21 22 23 24 24 24 24 24 24		0	
D		4	40
D	ooringuring miliar outcaming	<u> </u>	
Outcalling off 22			
default mailbox	D	<u> </u>	
P P P P P P P P P P		•	
P	default mailbox <u>7</u>	<u> </u>	
P P P P P P P P P P		outcalling timeout	<u>21</u>
email notification 17, 18 embedded overview 5 embedded voicemail 6 Embedded Voicemail 6 Embedded Voicemail 6 R record greeting 13 forward message 11 recording name 14 full mailbox 9 5 G Save a message 11 greeting listening 14 setting outcalling destination 20 setting outcalling timeout 21 switching email notification 17 switching email notification 17 switching email notification 12 Intuity mode 6 6 T IL transfer option 12 Isten to greeting 14 transfer overview 14 tisten to messages 10 trusted source 7 listening to messages 10 trusted sources 12 listening to messages 10 trusted sources 12 listening to messages 10 trusted source 12 listening to messages<	E		
embedded overview .6 password changing 12 embedded voicemail .6 R F record greeting .13 forward message .11 recording name .14 full mailbox .9 .9 G Save a message .11 greeting listening .14 setting outcalling destination .20 setting outcalling timeout .20 switching email notification .17 switching off email .18 system administration .12 Intuity mode .6 IP Office mode .6 Isten to greeting .14 tisten to messages .10 listen to messages .10 listening to message .10 listening to messages .10 listening to messages .10 listening of messages .10 listening of messages .12 listening of messages .12 listening of messages .12 listening of		P	
embedded voicemail .6 Embedded Voicemail R F record greeting .13 recording name .14 recording your greeting .13 recording your gre			
F		password changing	<u>12</u>
F	en de la companya de		
Tecording name 14 14 15 15 15 15 15 15	Embedded Voicemail6	R	
Tecording name 14 14 15 15 15 15 15 15			40
forward message 11 recording your greeting 13 recording your greeting G S greeting listening 14 setting outcalling destination 20 setting outcalling timeout 21 setting outcalling timeout 21 switching email notification 17 switching email notification 17 switching off email 18 system administration 12 system administration 13 system administration 12 system administration 12 system administration 13 system administration 12 system administration 12 system administration 13 system administration 12 system administration 13 system administration 14 system administration 12 system administration 14 system administration	F	0 0	
S S Q G Save a message 11 greeting listening 14 setting outcalling destination 20 setting outcalling timeout 21 switching email notification 17 switching off email 18 initial outcalling 19 Intuity mode 6 IP Office mode 6 IP Office mode 5 T transfer option L transfer overview listen to greeting 14 listen to messages 10 trusted source introduction 7 trusted sources 12 listening to messages 10 listening to messages 10 turning off outcalling 22			
Save a message		recording your greeting	<u>13</u>
G Save a message 11 greeting listening 14 setting outcalling destination 20 setting outcalling timeout 21 switching email notification 17 switching off email 18 initial outcalling 19 Intuity mode 6 IP Office mode 7 L transfer option 14 listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to message 10 trusted sources 12 listening to messages 10 turning off outcalling 22 Internal control ling 22 23	full mailbox9		
Save a message	_	S	
Setting outcalling destination 20 Setting outcalling destination 21 Setting outcalling timeout 21 Switching email notification 17 Switching off email 18 System administration 12 System administration 13 System administration 14 System administration 14 System administration 14 System administration 15 System administration 16 System administration 17 System administration 18 System administration 19 System administration 19 System administration 19 System administration 19 System administration 10 System administration 11 System administration 11 System administration 12 System administration 12 System administration 12 System administration 12 System administration 13 System administration 14 System administration 12 System administration 12 System administration 12 System administration 13 System administration 14 System administration 14 System administration 15 System administration 16 System administration 16 System administration 16 System administration 16 System administ	G	Savo a massaga	11
I setting outcalling timeout 21 switching email notification 17 switching off email 18 initial outcalling 19 system administration Intuity mode 6 IP Office mode 5 T L transfer option 14 listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to message 10 trusted sources 12 listening to messages 10 trusted sources 12 listening to messages 10 truning off outcalling 22	greating listening		
Switching email notification	greeting listerling <u>14</u>		
switching off email 18			
initial outcalling 19 system administration 12 Intuity mode 6 6 T IP Office mode 6 T L transfer option 14 listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to message 10 trusted sources 12 listening to messages 10 trusted sources 12 listening to messages 10 trusted sources 12 turning off outcalling 22			
Intuity mode 6 IP Office mode 6 T transfer option 14 Listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to message 10 trusted sources 12 listening to messages 10 trusted sources 12			
L transfer option 14 listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to messages 10 trusted sources 12 listening to messages 10 trusted sources 22		system administration	<u>12</u>
L transfer option 14 listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to message 10 trusted sources 12 listening to messages 10 turning off outcalling 22 listening to messages 10 turning off outcalling 22	Intuity mode <u>6</u>		
transfer overview 14 listen to greeting 14 trusted source .7 listen to messages 10 trusted source introduction .7 listening to message 10 trusted sources .12 listening to messages 10 trusted sources .22	IP Office mode6	T	
transfer overview 14 listen to greeting 14 trusted source .7 listen to messages 10 trusted source introduction .7 listening to message 10 trusted sources .12 listening to messages 10 trusted sources .22		transfer entian	4.4
listen to greeting 14 trusted source 7 listen to messages 10 trusted source introduction 7 listening to message 10 trusted sources 12 listening to messages 10 trusted sources 12 listening to messages 10 trusted sources 24	L	·	
listen to messages			
listening to messages			_
listening to messages turning off outcalling turning off outcalling			
turning to Moodageo	listening to message <u>10</u>		
	listening to messages <u>10</u>		
		turning outcalling on	<u>21</u>

Index

U

User guides	<u>6</u>
V	
visual voice	24
voice button	24
voicemail email	
voicemail notification	<u>16</u>
Voicemail Pro	
voicemail transfer	