




operating instructions



Backrest Angle Adjustment

To alter the angle of the backrest, lift the lever (1) and move the backrest to your desired position.

This is best done whilst sitting. Return lever to the downward position to lock in place.

Seat Tilt Adjustment





The seat is locked in position when paddle (2) is in the downward position, to unlock the seat tilt action, lift the paddle up. Leave unlocked for free float or, if preferred, lock when the desired seat angle is reached.

Seat Height Adjustment

Lift handle (3) and raise or lower seat until desired height is found. Release handle to set height. To lower the seat, body weight must be applied to the seat surface. Adjustments should be made when sitting in the chair.

Back Height Adjustment

Lock the backrest in a vertical position. When seated, grasp the sides of the backrest and raise until comfortable. This is a 6- position ratchet system. To re-position the back, lift fully to the top, lower to the bottom and raise to the desired height.



Inflatable Lumbar Support.

Adjust the lumbar support by depressing the inflation pump bulb (5) located under the seat at the rear. (If necessary, reposition the backrest). Deflate the air-cell, by pressing the valve button attached to the bulb.

Body Weight Tension Adjustment

The body weight tension adjuster (6) is located under the seat and operated by turning it clockwise to increase the tension and anti-clockwise to reduce.



Seat Depth Adjustment

Seat depth adjustment lever is located on the left-hand under side of the seat.

Lift lever (7) to slide the seat to the desired depth. Release the lever to set.

Head / Neck Support.

Height Adjustment
Raise or lower by grasping the headrest mechanism. Lift up or push down to achieve desired height.
Angle - Rotate the pad manually to achieve the angle you need.

setting up and caring for your chair

setting up
your chair**a. Seat Height**

Ideally, your hips should be slightly higher than your knees to promote good posture. When your shoulders are relaxed and elbows are at right angles, your forearms should be just above the surface of the desktop, parallel to the floor.

b. Seat Depth

Your bottom should be at the back of the seat with roughly three fingers gap between the front of the seat and behind your knees. This will ensure adequate thigh support but without obstructing leg movement and lower leg circulation.

c. Back Height

The lumbar support of the backrest should fit into the small of your back to maintain the natural 'S' shape of the spine.

Armrests:

The armrests should touch the underside of your forearms when your shoulders are relaxed and elbows are at right angles. This will avoid strain in the neck, shoulders and upper limbs.

Tension

Create a feeling of floating (when your feet are off the floor) to encourage improved blood circulation and comfortable changes of posture. The tension should be not too soft so that you instantly recline and not too hard that you can't naturally push back.

Ergochair

care & maintenance
warranty**Care of cloth upholstery**

To maintain the cloth upholstery, regular vacuum cleaning is recommended. Marks and stains may be removed with a proprietary cleaner. In difficult cases, consult a reputable firm of cleaners, or ourselves for advice.

Care of leather upholstery

Leather upholstery should be wiped with a slightly damp cloth and gently rubbed dry. A good proprietary hide food should be applied at least once a year, and more often if the leather is in a dry atmosphere or close to a heat source.

Care of plastic parts

Plastic compound parts are best cleaned by wiping with a slightly damp cloth and gently rubbing dry with a soft duster.

This product includes a comprehensive warranty. Details of this warranty are available from Ergochair Customer Services Department. Should you have an issue with your chair, please contact us and on our website - details are below.

