



CELLNYX
CONNECT • COMMUNICATE • GROW

Yealink CORDLESS PHONE

USER GUIDE

Everything you need to know
to use your Yealink cordless phone
with confidence.



EASY TO USE

Intuitive controls and clear display
make calling simple.



STAY CONNECTED

Reliable cordless coverage that
keeps you moving.



BUILT FOR BUSINESS

Powerful features designed to
improve productivity.



CELLNYX SUPPORT

We're here to help when
you need it.



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

CONNECT • COMMUNICATE • GROW

Yealink CORDLESS PHONE

USER GUIDE



TABLE OF CONTENTS

1.	Getting Started	1
2.	Handset Overview	2
3.	Understanding the Screen & Icons	4
4.	Making Calls	7
5.	Answering Calls	10
6.	During a Call	12
7.	Call History	15
8.	Contacts	17
9.	Voicemail	19
10.	Intercom & Paging (If Applicable)	21
11.	Settings	23
12.	Troubleshooting	28
13.	Safety & Care	30
14.	Quick Reference Guide	31



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

GETTING STARTED

Thank you for choosing the Yealink cordless phone. This guide will help you set up your phone and get familiar with the basics so you can start working right away.



IN THE BOX

Your Yealink cordless phone package includes the following items:

- W56H Handset
- W70B Base Station
- Charging Cradle
- Power Adapter for Base Station
- Power Adapter for Charging Cradle
- Ethernet Cable
- Quick Start Guide



W56H Handset
in Charging Cradle



W70B
Base Station



BEFORE YOU BEGIN

- ✓ Your base station and handset have been set up and registered by your system administrator.
- ✓ Place the base station in a central location with a stable power and internet connection.
- ✓ Fully charge the handset before first use for the best battery performance.



INITIAL SETUP OVERVIEW

Follow these simple steps to get your phone ready:

1

CHARGE THE HANDSET

Place the handset in the charging cradle and allow it to fully charge.

**2**

CHECK CONNECTION

Ensure the base station has power and internet. All LEDs should be green.

**3**

VERIFY REGISTRATION

The handset screen will show your extension and line information.

**4**

YOU'RE READY!

Your phone is ready to make and receive calls. Enjoy!



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com



HANDSET OVERVIEW

Familiarize yourself with the buttons and features on your Yealink cordless phone.



KEY	DESCRIPTION
1	 Earpiece Listen to audio from the handset.
2	 LED Indicator Shows call status, messages, and charging.
3	 Color Screen Displays calls, menus, and information.
4	 Left Soft Key Press to select the option shown at the bottom left of the screen.
5	 Right Soft Key Press to select the option shown at the bottom right of the screen.
6	 Speaker / Volume Key Adjusts earpiece, ring tone, and speaker volume.
7	 Message Key Access voicemail or view messages.
8	 Navigation Key / OK Navigate menus and press OK to confirm selections.
9	 End Call / Power Key End calls or go back to idle screen. Press and hold to power on/off.
10	 Call Send Key Make or answer calls. Press to view call logs.
11	 Keypad Dial numbers, enter letters, and symbols.
12	 Transfer Key Transfer calls.
13	 Mute Key Mute or unmute the microphone.
14	 Microphone Speak into the handset.



TIP: Use the navigation key and soft keys to easily move through menus and customize your phone.



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

UNDERSTANDING THE SCREEN & ICONS

The color screen and icons provide at-a-glance information about your phone's status, calls, messages, battery, and more.

IDLE SCREEN OVERVIEW



#	ITEM	DESCRIPTION
1		Signal Strength Shows the wireless signal strength.
2		Battery Status Displays the current battery level.
3	10:39	Time Displays the current time.
4	Thur. Mar 26	Date Displays the current date.
5		Handset Name / Line Displays the handset name or registered line name. (Example: Kyle Wu Handset)
6	History	Left Soft Key Label Shows the action available for the left soft key.
7	Line	Right Soft Key Label Shows the action available for the right soft key.

COMMON ICONS (IDLE SCREEN)

ICON	DESCRIPTION
	Signal Strength The more bars, the stronger the signal.
	Battery Status Shows the battery level. (Empty to full)
	Ringer Off The ringer volume is set to 0, or the phone is in silent mode.
	Call Forward Enabled Indicates Call Forward is turned on.
	Keypad Locked The keypad is locked.
	New Voicemail You have new voice mail.
	Voicemail You have voice mail.
	Do Not Disturb (DND) DND mode is enabled.
	Intercom Mode The phone is in intercom mode.
	Charging The handset is charging.



TIP: Use the navigation key and soft keys to move through menus and view more information about your phone's status.



NOTE: Not all icons may appear at the same time. Icons vary based on your phone's status and settings.



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

MAKING CALLS

Your Yealink cordless phone makes it easy to place calls using a variety of methods. Choose the option that works best for you.



BEFORE YOU BEGIN

- ✓ Ensure your phone is powered on and registered to the base station.
- ✓ Make sure you have a strong signal () for the best call quality.



WAYS TO MAKE A CALL

You can place a call using any of the following methods:

-  **Dial Using the Keypad**
-  **Call from Contacts**
-  **Call from History**
-  **Intercom / Paging (If Applicable)**
(See Page 21)



DIAL USING THE KEYPAD

Follow these steps to dial a number using the keypad.


-  Enter the number using the keypad.
-  Press the **Send Call Key**  to place the call.
-  The call will connect.
-  Press the **End Call Key**  to end the call.



TIP: Press and hold the  key to dial the last number redial list.



CALL FROM CONTACTS

-  Press the **Navigation Key**  to access the main menu.
-  Select **Directory** and press OK.
-  Use the **Navigation Key** to find the contact.
-  Press the **Send Call Key**  to place the call.




CALL FROM HISTORY

-  From the idle screen, press History.
-  Use the **Navigation Key** to scroll through call history.
-  Press **OK** to view details or select the entry.
-  Press the **Send Call Key**  to place the call.



INTERCOM / PAGING

-  Press the **Navigation Key**  to access the main menu.
-  Select **Intercom** and press OK.
-  Choose the handset or group to page.
-  Press **OK** to start the intercom call.



IMPORTANT NOTES

- To end the call, press the red End Call Key  at any time.
- If the handset is out of range, you may experience call dropouts or poor audio.



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

ANSWERING CALLS

Your Yealink cordless phone gives you multiple ways to answer incoming calls. Choose the option that works best for you in the moment.

BEFORE YOU BEGIN

- ✓ Ensure your handset is powered on and within range of the base station.
- ✓ Make sure the ringer volume is turned up.
- ✓ A strong signal (full bars) ensures the best call quality.




WAYS TO ANSWER A CALL

When you receive an incoming call, the screen will display the caller or extension information (if available) and your phone will ring or vibrate.

-  Press the **Send Call Key**
Press the green Send Call Key to answer the call.
-  Press the **Speaker Key**
Press the Speaker Key to answer using speakerphone.
-  Press the **OK Key**
Press the OK Key to answer the call.
-  Use the **Navigation Key**
Press the center of the Navigation Key to answer.

CALL NOTIFICATION

When a call comes in, you will see:

-  • Caller Name or Extension (if available)
-  • Caller Number or Extension
-  • Ringing or Vibration
-  • Soft Keys: Answer / Silence

SILENCE THE RINGER

If you do not want to answer the call right away, you can silence the ringer.

- 1 Press the Right Soft Key **Silence**
- 2 The ringer will stop, but the call will continue to ring on other devices (if applicable).

 **TIP:** You can still answer the call later from your handset or another device.

MISSED CALLS

If you miss a call, the handset will show a missed call notification.

- 1 Press the Message Key  to view missed call alerts.
- 2 Or go to **History** to view missed calls.

 **NOTE:** Missed call notifications may vary depending on your phone system settings.

DURING A CALL

Your Yealink cordless phone provides powerful features to help you manage your calls with ease and professionalism.



TIP: Use the Navigation Key to navigate options during a call.



BEFORE YOU BEGIN

- ✓ Ensure you are in range of the base station.
- ✓ Check that your signal strength is strong (full bars) for clear calls.
- ✓ Adjust the volume if needed using the Speaker Key.



CALL INFORMATION



Caller Name or Extension (If available)

1001

Caller Number or Extension



Call Duration

Shows how long the call has been connected.



Signal Strength

Indicates the quality of your connection.

Options

Left Soft Key

Access call features and options.

End Call

Right Soft Key

End the current call.



ADJUST VOLUME

Adjust the earpiece or speaker volume during a call.

- 1 Press the Speaker Key to increase the volume.
- 2 Press the Speaker Key to decrease the volume.



MUTE / UNMUTE

Mute the microphone so the other party cannot hear you.

- 1 Press the Mute Key to mute the call.
 - 2 Press the Mute Key again to unmute.
- The screen will show **Muted** when muted.



HOLD / RESUME

Place a call on hold and resume when you're ready.

- 1 Press the Left Soft Key **Options**.
 - 2 Select Hold and press OK.
 - 3 To resume, press Resume and press OK.
- The screen will show **Held** when on hold.



TRANSFER A CALL

Transfer the call to another extension or external number.

- 1 Press the Left Soft Key **Options**.
- 2 Select Transfer and press OK.
- 3 Enter the number or extension.
- 4 Press the Send Call Key to complete the transfer.



CONFERENCE CALL

Start a 3-way conference call.

- 1 Press the Left Soft Key **Options**.
- 2 Select Conference and press OK.
- 3 Enter the number or extension and press Send.
- 4 When the party answers, press Conference again to start.



END A CALL

End the current call.

- 1 Press the End Call Key or the Right Soft Key **End Call**.
- 2 The call will be disconnected.
- 3 You will return to the idle screen.



IMPORTANT NOTE:

Feature availability may vary depending on your phone system configuration. Contact your system administrator if you need assistance with any call feature.



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

CALL HISTORY

Your Yealink cordless phone keeps a record of recent calls so you can easily review, return, or manage them.

! WHAT IS CALL HISTORY?

Call History stores information about:

- ✓ Incoming Calls (received)
- ✓ Outgoing Calls (made)
- ✓ Missed Calls (not answered)


💡 TIP:

You can dial a number directly from the history list to quickly return a call.



CALL HISTORY MENU

Access and manage your call history.

- 1  From the idle screen, press the Navigation Key  to access the main menu.
- 2  Select History and press OK .
- 3  Use the Navigation Key   to view your call lists.
- 4  Press OK  on an entry to view details or place a call.
- 5  Press the Left Soft Key Back to return to the previous screen.

CALL HISTORY ICONS

ICON	LIST	DESCRIPTION
	Incoming Calls	Calls received that were answered or missed.
	Outgoing Calls	Calls you have made.
	Missed Calls	Calls received that were not answered.
	Delete Entries	Remove individual or all call history entries.

MANAGE CALL HISTORY

While viewing a call history list, press the Left Soft Key Option to access the following:

OPTION	DESCRIPTION
Call	Dial the selected number.
Add to Contacts	Save the number to your contacts.
Delete	Delete the selected history entry.
Delete All	Delete all entries in the selected list.

! IMPORTANT NOTES:

- Call history lists are shared across all handsets registered to the same base station.
- The number of history records you can store may vary depending on your system settings.
- Call history may be cleared if the base station settings are reset.



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

CONTACTS

The Contacts directory allows you to store and manage your frequently used numbers for quick and easy access.

BEFORE YOU BEGIN




- ✓ Contacts are stored on the handset and shared with other handsets registered to the same base station.
- ✓ You can store up to 1000 contacts (depending on your system settings).
- ✓ Each contact can include a name and multiple phone numbers.

TIP: Store mobile numbers, office lines, or extension numbers and assign a unique ringtone for important contacts.



ACCESSING THE CONTACTS MENU

Follow these steps to access your Contacts directory.

-  From the idle screen, press the **Navigation Key**  to access the main menu.
-  Select **Contacts** and press **OK** .
-  Use the **Navigation Key**  to browse your contact list.
-  Press **OK**  on a contact to view details or place a call.
-  Press the **Left Soft Key** **Back** to return to the previous screen.

ADD A NEW CONTACT

-  Access the Contacts menu (see steps above).
-  Press the **Left Soft Key** **Option**.
-  Select **Add** and press **OK**.
-  Enter the contact name and numbers.
-  Press **OK** to save.

EDIT A CONTACT

-  Select the contact you want to edit and press **OK**.
-  Press the **Left Soft Key** **Option**.
-  Select **Edit** and press **OK**.
-  Make your changes.
-  Press **OK** to save.

DELETE A CONTACT

-  Select the contact you want to delete and press **OK**.
-  Press the **Left Soft Key** **Option**.
-  Select **Delete** and press **OK**.
-  Press **OK** again to confirm.

IMPORT / EXPORT CONTACTS

EXPORT CONTACTS

You can export your contacts to a file and save it to your handset.

-  In the Contacts menu, press **Option**.
-  Select **Export** and press **OK**.
-  Choose the storage location and press **OK** to save.

IMPORT CONTACTS

You can import contacts from a previously saved file.

-  In the Contacts menu, press **Option**.
-  Select **Import** and press **OK**.
-  Select the file and press **OK** to import.

TIP: Import/export features may require a USB connection via the base station (depending on your system configuration).

IMPORTANT NOTE: Contacts are stored on the handset and will be lost if the handset is reset to factory defaults. Regularly back up your contacts using the export feature.

 **CALL US**
(631) 931-0094

 **EMAIL US**
support@cellnyx.com

 **VISIT US ONLINE**
www.cellnyx.com

VOICEMAIL

Stay connected by easily accessing and managing your voicemail messages right from your Yealink cordless phone.

BEFORE YOU BEGIN


- ✓ Voicemail must be enabled on your phone system.
- ✓ New voicemail messages are indicated on the idle screen.
- ✓ The **Message Key** will flash and you will hear a stutter dial tone (if enabled).

TIP: You can also access voicemail by dialing your voicemail extension (typically *97) from the idle screen.



ACCESSING VOICEMAIL

Follow these steps to listen to your voicemail messages.

- 1  Press the **Message Key** .
OR
Dial your voicemail extension (typically *97).
- 2  Enter your voicemail PIN when prompted.
- 3  Press **OK**  to confirm.
- 4  Use the **Navigation Key**   to navigate through your messages and options.
- 5  Press the **Left Soft Key Back** to return to the idle screen.

DURING MESSAGE PLAYBACK

Use the following keys to control your voicemail playback.

-  **Play / Resume**
Press **OK** .
-  **Pause**
Press **OK** .
-  **Skip to Next Message**
Press **Right Soft Key** .
-  **Repeat Current Message**
Press **Left Soft Key** .
-  **Delete Message**
Press **Delete** .

VOICEMAIL OPTIONS MENU

During or after message playback, you can press the **Options** key to access additional voicemail features.

OPTION	DESCRIPTION
Delete	Delete the current message.
Delete All	Delete all saved messages.
Save	Save the current message.
Forward	Forward the current message.
Call Sender	Call the person who left the message.
Message Settings	Configure voicemail preferences (if supported).
Log Out	Log out of your voicemail.

VOICEMAIL INDICATORS

The following icons will appear on your screen when you have voicemail.

-  You have new voicemail message(s).
-  You have listened to all messages.
-  Voicemail is full.

TIP: Voicemail indicators may vary based on your phone system settings.

IMPORTANT NOTE:

Voicemail features and menu options may vary depending on your phone system configuration. Contact your system administrator for more information.

INTERCOM & PAGING

Use intercom to quickly speak with another handset and paging to make an announcement over a speaker or paging group.

BEFORE YOU BEGIN


- ✓ Intercom and paging features must be enabled on your phone system.
- ✓ Know the extension of the handset you want to reach.
- ✓ For paging, know the paging extension or group (e.g., PAGE, ALL PAGE).

TIP: Both intercom and paging can be dialed directly from the idle screen using the keypad.



INTERCOM: SPEAK TO ANOTHER HANDSET

Use intercom to have a private, hands-free conversation with another handset.

-  From the idle screen, enter the extension number of the handset you want to intercom.
-  Press the Send Call Key to place the intercom call.
-  Once answered, speak using speakerphone (hands-free).
-  Press the End Call Key to end the intercom call.

TIP: If the handset does not answer, the call will not go to voicemail.

PAGING: MAKE AN ANNOUNCEMENT

Use paging to broadcast a message over a speaker, zone, or paging group.

-  From the idle screen, dial the paging extension or group. Examples: Page Group (e.g., 390), All Page (e.g., 399), or a specific zone.
-  Press the Send Call Key to connect.
-  When the page tone is heard, wait for the beep, then speak clearly into the handset.
-  Press the End Call Key when you are finished.

NOTE: Paging is one-way audio. You will not hear a response from the page.

COMMON PAGING DESTINATIONS (EXAMPLES)

	All Page 399	Pages all speakers and zones system-wide.
	Page Group 390	Pages all speakers in a designated group.
	Front Desk Page 391	Pages the front desk area only.
	Service Bay Page 392	Pages the service bay area.

TIP: Ask your system administrator for the correct paging or intercom extensions for your location.

IMPORTANT NOTE: Feature availability and extension numbers may vary depending on your phone system configuration. Contact your system administrator if you need assistance.

SETTINGS

Customize your Yealink cordless phone settings to match your preferences and improve your calling experience.

BEFORE YOU BEGIN



- ✓ Some settings may be configured by your system administrator.
- ✓ Not all settings may be available depending on your system.
- ✓ Changes may require confirmation and will be saved automatically.

TIP: You can return to the idle screen at any time by pressing the End Call Key  repeatedly.



ACCESSING THE SETTINGS MENU

Follow these steps to access and navigate the Settings menu.

-  From the idle screen, press the **Left Soft Key Options**.
-  Select **Settings** and press **OK** .
-  Use the **Navigation Key**   to select a menu.
-  Press **OK**  to enter the menu.
-  Press the **Left Soft Key Back** to return to the previous screen.

TIP: Press the **End Call Key**  repeatedly to return to the idle screen.

SETTINGS MENU OVERVIEW

MENU	DESCRIPTION	COMMON OPTIONS
 1. Basic	Configure basic phone settings.	• Language • Time & Date • Key Beep
 2. Features	Configure call handling and phone features.	• Call Forward • DND (Do Not Disturb) • Auto Answer
 3. Audio	Adjust audio settings for calls and alerts.	• Ringtone Volume • Handset Volume • Ringtone Melodies
 4. Display	Customize display settings and behavior.	• Backlight • Wallpaper • Screensaver
 5. System	Configure system settings and preferences.	• Reset to Default • Upgrade • About
 6. Register	Register or view your handset registration status.	• Register Handset • Base Info • Line Status

COMMON SETTINGS EXAMPLES

-  **CHANGE LANGUAGE**
- 1 Settings > Basic > Language
 - 2 Select desired language.
 - 3 Press OK to confirm.
-  **ADJUST RINGTONE VOLUME**
- 1 Settings > Audio > Ringtone Volume
 - 2 Use   to adjust the volume.
 - 3 Press OK to save.
-  **ENABLE DO NOT DISTURB**
- 1 Settings > Features > DND
 - 2 Select On and press OK.
 - 3 Set DND time/permissions if needed.
-  **ADJUST BACKLIGHT**
- 1 Settings > Display > Backlight
 - 2 Choose Always On / On Key Press / Off.
 - 3 Press OK to save.

IMPORTANT NOTE: Settings availability and default values may vary depending on your phone system configuration. Contact your system administrator if you need assistance.

 **CALL US**
(631) 931-0094

 **EMAIL US**
support@cellnyx.com

 **VISIT US ONLINE**
www.cellnyx.com

TROUBLESHOOTING

Use this guide to quickly resolve common issues you may encounter with your Yealink cordless phone.



QUICK TIPS

- ✓ Restarting the handset or base station can resolve many issues.
- ✓ Make sure your phone is updated to the latest firmware.
- ✓ Contact your system administrator if problems persist.
- ✓ Keep this guide handy for quick reference.

COMMON ISSUES & SOLUTIONS

ISSUE	POSSIBLE CAUSE	SOLUTION
 No Signal / Out of Range	- Handset is too far from the base station. - Obstructions or interference.	- Move closer to the base station. - Ensure a clear line of sight and avoid large metal objects or electronics.
 Handset Not Registered	- Handset not registered to the base station. - Registration may have been lost.	- Register the handset (see page 6). - If it fails, restart the base station and try again.
 No Audio (Caller Can't Hear You)	- Mute is enabled. - Microphone blocked. - Low battery.	- Press the Mute key to turn off mute. - Check that the microphone is not covered. - Charge the handset.
 No Ringtone When Receiving Calls	- Ringtone volume is set too low. - Do Not Disturb (DND) is enabled. - Call is sent directly to voicemail.	- Increase ringtone volume (see page 23). - Disable DND. - Check call forwarding settings.
 Voicemail Not Working	- Voicemail not set up. - Incorrect extension or PIN. - Network issue.	- Verify voicemail is enabled on your system. - Check your voicemail extension and PIN (see page 19). - Contact your system administrator if the issue continues.
 Battery Drains Quickly	- Backlight or features are set too high. - Old or defective battery. - Poor signal strength.	- Reduce backlight timeout. - Replace the battery. - Move closer to the base station.
 Call Drops or Poor Audio Quality	- Weak Wi-Fi or DECT interference. - Network congestion. - Distance from base station.	- Move away from Wi-Fi routers and other cordless devices. - Ensure your network is stable. - Move closer to the base station.
 Handset Frozen or Unresponsive	- Temporary software issue. - System overload.	- Restart the handset by removing it from the charger for 10 seconds. - If the issue remains, restart the base station.



STILL NEED HELP?

If you're experiencing an issue that isn't listed above, contact your system administrator or Cellnyx Support.



HAVE THIS INFO READY:

- Handset model and firmware version
- Details about the issue and when it occurs



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com

SAFETY & CARE

Follow these safety guidelines and care instructions to keep your Yealink cordless phone working reliably and safely.

SAFETY GUIDELINES

- ✓ **Read the Instructions**
Read this guide and other documentation carefully before using the phone.
- ✓ **Use Approved Accessories**
Use only batteries and power adapters provided or approved by Yealink.
- ✓ **Avoid Water & Liquids**
Do not expose the phone to water, rain, or any liquids.
- ✓ **Keep Away from Heat**
Keep the phone away from heat sources, direct sunlight, and extreme temperatures.
- ✓ **Electrical Safety**
Use the charger only with the recommended power source as labeled.



CARE INSTRUCTIONS

- ✓ **Clean Regularly**
Wipe the handset and charger with a soft, dry or slightly damp cloth. Do not use harsh chemicals.
- ✓ **Protect the Screen**
Avoid pressing the screen with sharp objects. Use clean, dry hands when operating.
- ✓ **Charge Properly**
Place the handset in the charger when not in use to keep the battery fully charged.
- ✓ **Update Firmware**
Keep your phone's firmware up to date for the best performance and security.
- ✓ **Handle with Care**
Do not drop or impact the phone. Rough handling can damage internal components.

BATTERY SAFETY

- Use only the Yealink-approved battery.
- Do not disassemble, crush, puncture, or short-circuit the battery.
- Do not expose the battery to fire or high temperatures.
- If the battery is leaking, avoid contact with the liquid.
- Dispose of used batteries properly according to local regulations.



IMPORTANT NOTES

- This device is designed for indoor use only.
- DECT technology operates on a dedicated frequency for secure and private communication.
- Changes or modifications not approved by Yealink may void your authority to operate this device.
- For optimal performance, keep the phone and base station in a well-ventilated area.



DISPOSAL & RECYCLING

Do not dispose of this product with household waste. Please recycle responsibly in accordance with local electronic waste regulations to help protect the environment.



NEED HELP?

If you have questions about safety, care, or experience any issues with your phone, please contact Cellnyx Support.

QUICK REFERENCE GUIDE

Your go-to cheat sheet for everyday use



TIP:

For detailed instructions, refer to the corresponding pages in this guide.

BASIC CALL FUNCTIONS

- Make a Call** [Page 8](#)
Dial the number and press
- Answer a Call** [Page 10](#)
Press when phone rings.
- End a Call** [Page 12](#)
Press to end the call.
- Mute / Unmute** [Page 12](#)
Press to toggle mute.
- Hold / Resume** [Page 12](#)
Press to hold, again to resume.
- Transfer a Call** [Page 12](#)
Press , enter extension, press



DURING A CALL SHORTCUTS

- Adjust Volume** [Page 12](#)
Use / during a call.
- Mute / Unmute** [Page 12](#)
Press to mute.
- Hold / Resume** [Page 12](#)
Press to hold, again to resume.
- Transfer** [Page 12](#)
Press , dial extension, press
- Conference (3-Way)** [Page 12](#)
Transfer the call to a second party, then press .
- End Call** [Page 12](#)
Press to end.

NAVIGATION & KEYS

- Navigate menus and options
- Select / Confirm an option
- Back / Exit (previous screen)
- Access Voicemail [Page 19](#)
- TRAN**
Quick access to transfer function

POPULAR FEATURES

- Call History**
View recent calls and options [Page 15](#)
- Contacts**
Access your phonebook [Page 17](#)
- Voicemail**
Listen to messages [Page 19](#)
- Intercom**
Speak to another handset [Page 21](#)
- Settings**
Customize your phone [Page 23](#)

INDICATOR LIGHTS & ICONS

- Solid Green**
Charging / Fully Charged
- Solid Red**
Low Battery
- New Voicemail**
You have new voice messages
- Do Not Disturb**
DND is active
- Good Signal**
Strong connection
- Battery Level**
Shows remaining charge

COMMON DIAL CODES

(If Enabled on Your System)

- *97** Dial voicemail (from idle screen)
- #** Redial last number
- *72 + Number** Call Forward (Enable)
- *73** Call Forward (Disable)
- *78** Do Not Disturb (Enable)
- *79** Do Not Disturb (Disable)

Note: Feature codes may vary based on your phone system.

COMMON TIPS

- Keep your handset charged on the base when not in use.
- If your phone does not ring, check DND and volume settings.
- If you cannot make calls, ensure your phone is registered (see page 6).
- Keep your phone's firmware up to date for best performance (see page 23).



NEED HELP?

If you run into any issues or need assistance, our team is here to help.



Call Us: (631) 931-0094



Email: support@cellnyx.com



Visit: www.cellnyx.com



CALL US
(631) 931-0094



EMAIL US
support@cellnyx.com



VISIT US ONLINE
www.cellnyx.com