

CHECKLIST – IS YOUR BUILDING READY FOR INSTALLATION?

Dear owner,

Before your Hydraloop water recycling system can be installed, you need to make sure that the building is ready for installation. Please return this document to your Hydraloop sales representative or the sales representative of your Hydraloop partner prior to installation. *Hydraloop and its installation partners can only proceed with the installation if you can answer all the following questions with yes.*

Installation address

Please fill out the exact address.

Did you check the water input connections?

Allowed input sources: water from showers and baths, and condensation water from air conditioning and tumble dryers. Optional: separate water line from the washing machine to the Hydraloop. For this, you need to install the 'washing machine option'. Be aware: Input from kitchen sinks, dishwasher, floor drains (other than shower water) or other water sources is not allowed!

Yes No Don't know

Remarks:

Can the Hydraloop be connected to back-up water?

The Hydraloop system needs a connection to tap water or rainwater as backup water. In case of rainwater, apply a pre-filter unit, please contact Hydraloop for extra information. Your back-up water supply must have a ground clearance of between 2,5 and 5 cm | 1 – 2 inches.

Yes No Don't know

Remarks:

Do you have a working WIFI connection in the room where the Hydraloop will be installed?

During installation, your Hydraloop will be connected to the internet. You need a working WIFI connection in the room. A cable internet connection is not possible.

Yes No Don't know

Remarks:

Does the room have a wall power outlet with earth safety protection?

The Hydraloop needs electricity. Ideally, the power outlet (with earth safety protection) is in a 50 cm | 20" range above or next to the Hydraloop system.

Yes No Don't know

Remarks:

Do you have at least 60 cm | 24 inches of free space in front of the Hydraloop?

You need this space in front of the Hydraloop for service and maintenance.

Yes No Don't know

Remarks:

Do the main inlet pipe and the sewage have appropriate ventilation?

Please check that all recommendations in the 'Recycle Ready Guidelines' are followed. The inlet pipe must have a minimum diameter of 50 mm | 2". The inlet pipe and the main sewage need proper ventilation to ensure waterflow without airlocks.

Yes No Don't know

Remarks:

Are the output connections prepared according to Hydraloop's Recycle Ready Guidelines?

Please check that all recommendations in the 'Recycle Ready Guidelines' are followed. Ensure that outlet 1 (toilets) is connected to a separate outlet for the toilet group. Ensure that outlet 2 (washing machine) is connected to one washing machine only. And ensure that outlet 3 (optional outlet for garden or pool) is one separate, open connection to either garden or pool.

Yes No Don't know

Remarks:

Do the output connections have the right thread?

Please check that all recommendations in the 'Recycle Ready Guidelines' are followed. Ensure that all connections are placed as close to the floor as possible, not higher than 2,5 cm | 1 inch above the floor. We recommend putting all output connections (except the sewage) in the wall. In case of in-wall connections: all hydraulic connections must end in a ½" male thread to the recycled water outlets. In case of in-floor connections: all hydraulic connections must have a ½" male thread to the recycled water outlets.

Yes No Don't know

Remarks:

Are all construction and building activities finished?

The Hydraloop system can't handle water with building residue, chemicals, paint and other waste. Make sure that all building activities are finished before installation. If the Hydraloop is installed while during building activities, you risk damaging the greywater cleaning mechanism. In that case, the owner will lose his or her warranty.

Yes No Don't know

As the owner of the Hydraloop system, I have checked every topic in this document.

Full name

Email address

Phone number

Please fill out your phone number including the country code – and without the first 0 (for instance +44 88 1003500)

Place and date

By filling out this date field, I validate my replies and I allow Hydraloop and/or its partners to contact me prior to the installation.

Signature

Please return this document to your Hydraloop sales representative or the sales representative of your Hydraloop partner prior to installation.

For more information, please visit www.hydraloop.com