

PT BANDAR BERLAYAR INTERNASION

12th Floor, Menara Batavia, Jl. KH Mas Mansyur, Kav 126, Jakarta 10220, Indonesia. Tel: +62 21 2528 613, 614, 615, 616 | Fax: +62 21

2528 613 | Phone: +62 811 1609 711

Email: marketing@smartin.agency | bbi@smartin.id Website: https://bbi.smartin.id

PORT INFO INDONESIA KENDAWANGAN (WEST KALIMANTAN)

| ICENIEDAL INICADIMATION | | |
|----------------------------|---|---|
| NAME OF PORT | • | Kendawangan Open Sea Loading Anchorage |
| LOADING ANCHORAGE POSITION | | There are 2 loading anchorage positions for Kendawangan anchorage |
| 1st Loading anchorage | ÷ | 02 Deg 34.00 South & 110 Deg 03.00 East |
| 13t Lodding unchorage | • | - |
| | | 1st Loading anchorage has draft restriction of : 14 Mtr at Tropical Sea Water Shipper will load care out to vecsel draft 11 00 Mtr before chiffing to 2nd loading point. |
| | | Shipper will load cargo upto vessel draft 11.00 Mtr before shifting to 2nd loading point But if vessel max draft below 12 mtr all loading operation will be finish at |
| | | 1st loading anchorage |
| 2nd Loading anchorage | | 02 Deg 32.00 South & 109 Deg 57.00 East |
| and codding disciolage | • | Water Depth is at 17 Mtr. Dedicated from supramax upto panamax type vessel |
| | | Water density at Kendawangan loading anchorage is 1.022 (Tropical Sea |
| | | Water) |
| | | 2 Shift of Stevedores will stay on board Vessel during Loading. |
| | | Please Kindly Proceed directly Kendawangan 1st Loading anchorage at |
| POSITION | : | 02 Deg 34.00 South & 110 Deg 03.00 East |
| | : | Drop Anchor at Indicated Loading Anchorage and Wait for Agent and port authority to |
| | | board vessel for Inward Formality. |
| | : | Pilotage is not Compulsory & Also No Pilot Available. |
| ISPS | : | Once complete inward formality loading operation will start soon. Kendawangan anchorage port is under control directly by Ketapang Sea |
| 1575 | : | port. |
| | | Port is ISPS Compliant |
| | | Current Port security Level is LEVEL 1 |
| | | Our PFSO Contact : Mr. Marbun (Kendawangan Port Harbor Master) |
| | | Contact No . +62 8125776431 |
| BUNKER & PROVISION | | (Any Changes in Port Security Level we shall inform you in advance) No Bunker Supply Available. |
| | : | No Ship Chandler Available but we can assist you to buy some provision if |
| | | you need. Just contact our Boarding agent. |
| WATER DENSITY | | |
| | : | Kendawangan Loading Anchorage is 1.022 (Tropical Sea Water) Kendawangan Loading Anchorage Water Depth |
| | | Excerpt from Indonesian Sea Chart No. 286 (Revision 7th January 2005) |
| | | All Depth Stated in Meter |
| | | All Depart Stated in Pieter |
| LOADING PROCEDURE | : | Loading operation will be carried out by vessel gears attached with steel bucket from shipper. |
| | | 2. Shipper will provide 6 unit of steel bucket for loading operation. |
| | | Each bucket weight is 3 Mt and can load abt 15-20 Mt of cargo (depends on vessel crane SWL) Expected Loading rate: 8-10,000 Mt Pwwd Shinc. |
| | | 5. No Regulation on ballast exchange at Kendawangan loading anchorage. However request master |
| | | kind cooperation during de ballasting process to coordinate with boarding loading master |
| | | from shipper to ensure that de ballasting process is not too fast to avoid floating crane loading |
| | | operation being interrupted due to higher air draft. |
| | | Loading operation will be carried out at Kendawangan Open Sea Anchorage. Cargo will be Transported to Vessel Using Flat top Barges from Shipper Stockpile at Mining Site stockpile. |
| | | Distance from Shipper stockpile to Loading anchorage is Abt 21 NM |
| | | (8 Hours Towing From Stockpile to loading anchorage) Most of the time Cargo Barge will be standby |
| | | at Kendawangan River mouth waiting for Vessel. Towing Time From Kendawangan River Mouth |
| | | to Loading Anchorage abt 2 Hours |
| | | 8. Loading operation is 24 Hours with 2 shifts of stevedores staying onboard vessel during loading operation. |
| | | Agent and stevedores will stay on board vessel during loading operation. Please kindly supply Boarding stevedores with sufficient Fresh water for their daily consumption |
| | | (Drinking & Cooking). |
| | | 10. Pls also kindly provide room & accommodation for 1 boarding foreman & 1 boarding shipper's |
| | | loading Master to stay on board vessel during vessel loading operation at Kendawangan loading anchorage |
| | | as they are deployed on board by shipper to ensure vessel safe & smooth loading operation. |
| | | And we are hoping for your good cooperation with them both during loading operation |
| OTHER USEFUL INFORMATION | | |
| Local Time | • | GMT + 7 HOURS |
| Working Hours | : | Working time at Loading Point is 24 Hours (Sunday & Holiday Included) Except Super Holiday. |
| Wheather Condition | : | Rainny Season : Januari to Mei, average rainfall max. 100 mm / min.50 mm. |
| | | Worst Season on Nopember & Desember, Wind: Nopember to April, |
| | | from North, BL speed 5 - 9 knots.On Months of May variabel direction, speed 4 - 7 knots, June s/d Oct from southeast with speed 4 - 10 knots. |
| Type of Port | | OPEN SEA |
| .,, | - | |

ALL INFORMATION ABOVE PROIVIDED IN GOOD FAITH BY BBI AGENCY. WE

ACCEPT NO LIABLTY FOR INACURATE INFORMATION

BBI AGENCY - AS AGENTS ONLY