

SUBMITTAL



P.O. BOX 595, TROY, NEW YORK 12181
TEL 518 274 0961 - FAX 518 274 0210
WWW.ROSSVALVE.COM

SUBMITTAL

**42AFCV Solenoid Operated
(Throttling) Control Valve**

ROSS TECHNOLOGY PARK
75 102ST STREET, TROY, NY 12181
TEL 518.274.0961 - WWW.ROSSVALVE.COM





SUBMITTAL NOTES

PROJECT: _____

Ross Model 42AFCV – Solenoid Operated (Throttling) Control Valve

Size: _____ inch / mm

Every Ross Valve shall be hydrostatically tested for body integrity and tight seating at the factory prior to shipment. Field operating conditions are simulated, and the controls are adjusted for proper operation. In order to design and test each valve under operating conditions similar to those in the field, please complete / confirm the following:

- Intended Application: [] Flow Control [] Pressure Control [] Level Control
Inlet (supply) pressure _____ psi
Outlet (downstream) pressure _____ psi
Voltage available to operate electrical controls: _____ VAC, _____ Hz or _____ VDC
There are 3 options for the valve's response to a power failure. Please designate the desired operation:
Main Valve will: [] Hold Last Position [] Fully Open [] Fully Close

The Ross Globe Body Style Valve can be installed in any position. In order to properly design the valve and orient the controls, please confirm the physical layout of the installation. (** Designates standard valve orientation.)



Valve inlet & outlet (flow) : [] Horizontal ** or [] Vertical
Valve piston axis : [] Vertical ** or [] Horizontal [] Horizontal

The valve shall be furnished with:


- ANSI B16.1 Class 250 cast iron body & cap, with: [] Class 125 flanges [] Class 250 flanges
Internal metal parts - Bronze construction
Two (2) ASCO Series 8210 2-Way Solenoid valves: Closing Control (part #26) and Opening Control (part #27) .
Note: Normally Closed solenoids will be provided with Manual Operator features.
Ross Model 5F2 Strainer (part #25) with Stainless Steel Filter Element and Blow-Off
Ross Standard Fine-Thread Needle Valves: Opening Control (part #32) and Closing Control (part #33)
Isolation valves: 0.5" Ball Valves, Bronze/Stainless Steel (part #18)
Position Indicator, Bronze (part #20)
Red brass pipe fittings and rigid control piping
Tapped ports with gauge cocks on inlet & outlet (gauges by others)
PAINTING: Ferrous surfaces of valve shall be coated with ANSI/NSF Standard 61 Certified Epoxy (Tnemec Series N140F) - Meets the performance requirements of AWWA D102 Inside System No. 1.
Operation & Maintenance Manual (shipped with the valve).
[] Other (Code / Description) _____ / _____

(Please list any additional features that are required. A representative may need to contact you for any relevant operating data.)

The valve will be constructed with materials and options stated on this notes page & cut view drawing & quote only, any changes or adders will be reviewed by Ross Valve Mfg. Co., Inc. with possible additional charges to quoted valve pricing. All information following the cut view drawing is for general information. Any special submittal requirements will be an additional charge to purchaser. The Ross Valve Mfg. Co., Inc. reserves the right to modify valve construction which will result in equal or superior performance to existing designs. These modifications may be made at any time and at the sole discretion of the manufacturer.



VALVE SIZE (IN)	ANSI B.16.1 CLASS	SHIPPING WEIGHT (LBS)	DIMENSIONS (INCHES)			
			A	B	C&D	E&F
4	125	235	14	9	4-3/4	7
	250	275	14-5/8	10	4-3/4	7
6	125	375	17-3/4	11	6-5/8	9
	250	430	17-3/4	12-1/2	6-5/8	9
8	125	690	24	13-1/2	8-3/4	12-1/2
	250	750	24-13/16	15	8-3/4	12-1/2
10	125	920	24-7/8	16	10	14-1/4
	250	1000	26-1/4	17-1/2	10	14-1/4
12	125	1375	30	19	12	15-1/2
	250	1475	31-1/2	20-1/2	12	15-1/2
14	125	1770	34-1/4	21	14	18
	250	1850	35-3/4	23	14	18
16	125	2400	37-7/8	23-1/2	15	21-1/2
	250	2600	39-1/4	25-1/2	15	21-1/2
18	125	3300	41-7/8	25	18-3/8	24
	250	3500	41-7/8	28	18-3/8	24
20	125	3550	42-3/8	27-1/2	18-3/8	24
	250	3800	42-3/8	30-1/2	18-3/8	24
24	125	5200	47	32	20	25
	250	5500	47	36	20	25
30	125	13000	63-3/4	38-3/4	26-1/4	34
	250	13500	65-1/16	43	26-1/4	34
36	125	16000	65	46	26-1/4	34
	250	18700	65	50	26-1/4	34



PART	DESCRIPTION	QTY.	MATERIAL
1	VALVE SHELL	1	CAST IRON
2	TOP CAP	1	CAST IRON
3	BOTTOM STEM GUIDE NUT	1	BRONZE
4	BOTTOM CUP FOLLOWERS (SET OF 2)	1	BRONZE
5	PISTON CUP PACKING	2	LEATHER
6	BOTTOM STEM LOCK NUT	1	BRONZE
7	STEM NUT	1	BRONZE
8	SEAT DISC	1	BRONZE
9	SEAT PACKING	1	POLYURETHANE
10	SEAT PACKING SUPPORT	1	BRONZE
11	STEM	1	BRONZE
12	MAIN CUP PLATES (SET OF 2)	1	BRONZE
13	MAIN CUP PACKING	2	LEATHER
14	MAIN BUSHING	1	BRONZE
15	TOP STEM NUT	1	BRONZE
16	BOTTOM CAP	1	CAST IRON
18	ISOLATION VALVE	3	BRONZE
20	INDICATOR ROD	1	BRONZE
21	INDICATOR STUFFING BOX	1	BRONZE
22	BOLTS & NUTS (SEAT RING)	VARY	BRONZE
23	BOTTOM CAP CYLINDER	1	BRONZE
24	SEAT RING	1	BRONZE
25	STRAINER	1	BRONZE/STAINLESS
26	2-WAY SOLENOID (N.C.) - CLOSING	1	BRONZE/STAINLESS
27	2-WAY SOLENOID (N.C.) - OPENING	1	BRONZE/STAINLESS
28	CHECK VALVE	1	BRONZE
32	NEEDLE VALVE - OPENING CONTROL	1	BRONZE
33	NEEDLE VALVE - CLOSING CONTROL	1	BRONZE
	BOLTS & NUTS (TOP & BOTTOM CAP)	VARY	STEEL
	BOLTS & NUTS (CUP PLATES)	VARY	BRONZE
	BOLTS & NUTS (SEAT DISC)	VARY	BRONZE
	INDICATOR ROD PACKING (SET)	1	TEFLON
	MAIN STUFFING BOX PACKING (SET)	1	TEFLON
	COVER & MAIN BUSHING GASKETS	3	COMPOSITION
	STEM GASKETS	3	COMPOSITION

ROSS VALVE Mfg. Co., Inc.

6 OAKWOOD AVENUE - TROY, NEW YORK, 12180 - TEL. (518) 274 0981
 POST OFFICE BOX 595 - TROY, NEW YORK, 12181 - FAX (518) 274 0210

WEBSITE: www.rossvalve.com - E-MAIL: sales@rossvalve.com


DRAWING	42AFCV	DATE	3/27/00 RJC
GLOBE BODY	4" - 36"	NO SCALE	FIGURE 14A

Model 42AFCV
 AUTOMATIC FLOW CONTROL VALVE

DIMENSIONS

Globe Body Minimum Clearances

Piston Valve Sizes: 4" - 48"



Size (Inches)	4"	6"	8"	10"	12"	14"	16"	18"	20"	24"	30"	36"	42"	48"
O	14	16	18	21	23	28	28	33	33	36	43	46	54	60
P	4 1/2	5 1/2	6 1/2	1	1	1	1	1	1	1	1	1	1	1

Note

1. Dimension "O" is clearance for removal of the top cap and piston for repacking the main valve. Additional working space for the convenience of the service man should be considered above as well as around the valve.
2. Dimension "P" as listed is the desirable clearance under the valve for removal of the STANDARD bottom cap. This dimension may be reduced to 1 inch for all valves on special applications.

Note

- A. **Do not obstruct vent hole located at the center of the bottom cap.**
- B. Consideration should be given for installation of valves 14" or larger under manhole in the roof of the valve vault or for additional clearance above the valve since a mechanical hoist will probably be required for removal of the piston. An eye bolt or hook cast in the cover slab over the center of the valve is useful.
- C. If clearance under the valve is limited, dimensions "O" and "P" can be modified. Consult the factory concerning special applications.

Features

- Wide range of pressure ratings, sizes, and resilient materials provide long service life and low internal leakage
- High Flow Valves for liquid, corrosive, and air/inert gas service
- Industrial applications include:
 - Car wash
 - Laundry equipment
 - Air compressors
 - Industrial water control
 - Pumps

Construction

Valve Parts in Contact with Fluids		
Body	Brass	304 Stainless Steel
Seals and Discs	NBR or PTFE	
Disc-Holder	PA	
Core Tube	305 Stainless Steel	
Core and Plugnut	430F Stainless Steel	
Springs	302 Stainless Steel	
Shading Coil	Copper	Silver

Electrical

Standard Coil and Class of Insulation	Watt Rating and Power Consumption				Spare Coil Part Number			
	DC Watts	AC			General Purpose		Explosionproof	
		Watts	VA Holding	VA Inrush	AC	DC	AC	DC
F	-	6.1	16	40	238210	-	238214	-
F	11.6	10.1	25	70	238610	238710	238614	238714
F	16.8	16.1	35	180	272610	97617	272614	97617
F	-	17.1	40	93	238610	-	238614	-
F	-	20	43	240	99257	-	99257	-
F	-	20.1	48	240	272610	-	272614	-
H	30.6	-	-	-	-	74073	-	74073
H	40.6	-	-	-	-	238910	-	238914


Standard Voltages: 24, 120, 240, 480 volts AC, 60 Hz (or 110, 220 volts AC, 50 Hz). 6, 12, 24, 120, 240 volts DC. Must be specified when ordering.
 Other voltages available when required.

Solenoid Enclosures

Standard: RedHat II - Watertight, Types 1, 2, 3, 3S, 4, and 4X; RedHat - Type I.

Optional: RedHat II - Explosionproof and Watertight, Types 3, 3S, 4, 4X, 6, 6P, 7, and 9; Red-Hat - Explosionproof and Watertight, Types 3, 4, 4X, 7, and 9.

(To order, add prefix "EF" to catalog number, except Catalog Numbers 8210B057, 8210B058, and 8210B059, which are not available with Explosionproof enclosures.)
 See *Optional Features Section* for other available options.



Nominal Ambient Temp. Ranges

RedHat II/
 RedHat AC: 32°F to 125°F (0°C to 52°C)

RedHat II DC: 32°F to 104°F (0°C to 40°C)

RedHat DC: 32°F to 77°F (0°C to 25°C)
 (104°F/40°C occasionally)

Refer to *Engineering Section* for details.

Approvals

CSA certified. RedHat II meets applicable CE directives.

Refer to *Engineering Section* for details.

STRAINER

Model Number: 5F-2

Sizes: ½" – 1"

Located: On any external piping

Purpose: To protect external piping and control devices from fouling or damage from foreign particles

Screen: Cylindrical Dutch weave stainless steel wire mesh

Piping Connection: Standard pipe thread

Operation

1. Water enters the cylindrical screen (#2) from the top and passes out through the sides of the cylinder.
2. Any particle too large to pass through .012 inch openings gets trapped in the cylinder, where, unless there is unusual turbulence, they settle at the bottom.

Recommendation


1. Strainer should be "blown down" frequently to remove collected foreign material from the sediment chamber.
2. Strainer screen should be removed occasionally for inspection and thorough cleaning.

Note

1. To clean without shutting down the line, open the flush cock (#5) in the bottom cap (#4) for several seconds.
2. To remove the screen (#2), which requires shutting down the line, unscrew the bottom cap assembly (#5).

Option

Two strainers installed in parallel (with the appropriate isolation valves) to permit uninterrupted service while cleaning.



PARTS

1. Body – Bronze
2. Screen – Stainless Steel
3. Cap Gasket – Rubber
4. Cap – Brass
5. Flushing Cock – Brass

NEEDLE VALVE

Sizes: One size fits all piston valves

Primarily Controlled By: Manually Adjusted

Located: On external control circuit of the main valve

Purpose: To limit flow in and out of the operating chamber

Standard Shipped Adjustment:

Course Needle: 5/6 to 2 turns off the seat

Fine Needle: Based on individual specifications

Operation

The simple construction reliably limits maximum flow through the external piping, depending on the position of the adjustable stem/needle (#4) relative to the seat.

1. When the needle (#4) is adjusted counter-clockwise to a raised position,
 - a. More water can pass through the needle valve.
 - b. Water enters (leaves) the operating chamber more quickly.
 - c. The main valve piston moves up and down more quickly.
2. When the needle (#4) is adjusted clockwise to a lowered position,
 - a. Less water can pass through the needle valve.
 - b. Water enters (leaves) the operating chamber more slowly.
 - c. The main valve piston moves up and down more slowly.

Adjustment

To adjust needle valve, which can be done without shutting down the main valve:

1. Remove the hex cap (#2) and lock (#1).
2. With a screw driver;
 - a. Turn the needle (#4) counter-clockwise to raise it
 - b. Turn the needle (#4) clockwise to lower it
3. Once the optimum position is determined, no further adjustment of the needle should be required.

Note

It is advisable to occasionally remove the cap (#2) and lock (#1) and change the position of the needle (#4) momentarily to insure against gradual plugging.


Option

Two separate needle valves on one main valve – Provides independent control of opening and closing speeds.



PARTS

1. Lock – Brass
2. Cap – Bronze
3. Cap Gasket – Rubber
4. Needle – Brass
5. Body – Bronze



TECHNICAL DATA continued

SHELF LIFE 24 months at recommended storage temperature.
FLASH POINT - SETA Part A: 82°F (28°C) Part B: 80°F (27°C)
HEALTH & SAFETY Paint products contain chemical ingredients which are considered hazardous. Read container label warning and Material Safety Data Sheet for important health and safety information prior to the use of this product. **Keep out of the reach of children.**

APPLICATION

COVERAGE RATES*

	Primer			Intermediate / Topcoat		
	Dry Mills (Microns)	Wet Mills (Microns)	Sq Ft/Gal (m ² /Gal)	Dry Mills (Microns)	Wet Mills (Microns)	Sq Ft/Gal (m ² /Gal)
Suggested (1)	4.0 (100)	6.0 (150)	273 (25.4)	5.0 (125)	7.5 (190)	218 (20.3)
Minimum	3.0 (75)	4.5 (115)	364 (33.9)	4.0 (100)	6.0 (150)	273 (25.4)
Maximum	5.0 (125)	7.5 (190)	218 (20.3)	6.0 (150)	9.0 (230)	182 (17.0)

(1) Note: Roller or brush application requires two or more coats to obtain recommended film thickness. Series N140F can be spray applied to an optional high-build film thickness range of 6.0 to 8.0 dry mils (150 to 205 dry microns) or 8.5 to 11.5 wet mils (215 to 290 wet microns). Allow for overspray and surface irregularities. Film thickness is rounded to the nearest 0.5 mil or 5 microns. Application of coating below minimum or above maximum recommended dry film thicknesses may adversely affect coating performance.

MIXING

1. Start with equal amounts of both Parts A & B.
2. Using a power mixer, separately stir Parts A & B.
3. Add Part A to Part B under agitation, stir until thoroughly mixed.
4. Both components should be above 50°F (10°C) prior to mixing. For application to surfaces between 35°F to 50°F (2°C to 10°C), allow mixed material to stand thirty (30) minutes and restir before using. For optimum application properties, blended components should be above 40°F (4°C).

POT LIFE

4 hours at 35°F (2°C) 2 hours at 77°F (25°C) 1 hour at 100°F (38°C)

THINNING

Use No. 4 Thinner. For air spray, thin up to 10% or ¾ pint (380 mL) per gallon. For airless spray, roller or brush, thin up to 5% or ¼ pint (190 mL) per gallon. **Caution:** Series N140F NSF certification is based on thinning with No. 4 Thinner. Use of any other thinner voids ANSI/NSF Std. 61 certification.

SURFACE TEMPERATURE

Minimum 35°F (2°C) Maximum 135°F (57°C)
 The surface should be dry and at least 5°F (3°C) above the dew point. Coating won't cure below minimum surface temperature.

APPLICATION EQUIPMENT

Air Spray

Gun	Fluid Tip	Air Cap	Air Hose ID	Mat'l Hose ID	Atomizing Pressure	Pot Pressure
DeVilbiss MBC or JGA	E	765 or 78	5/16" or 3/8" (7.9 or 9.5 mm)	3/8" or 1/2" (9.5 or 12.7 mm)	75-100 psi (5.2-6.9 bar)	10-20 psi (0.7-1.4 bar)

Low temperatures or longer hoses require higher pot pressure.

Airless Spray

Tip Orifice	Atomizing Pressure	Mat'l Hose ID	Manifold Filter
0.015"-0.019" (380-485 microns)	1800-3000 psi (124-207 bar)	1/4" or 3/8" (6.4 or 9.5 mm)	60 mesh (250 microns)

Use appropriate tip/atomizing pressure for equipment, applicator technique and weather conditions.
Note: Application over inorganic zinc-rich primers: Apply a wet mist coat and allow tiny bubbles to form. When bubbles disappear in 1 to 2 minutes, apply a full wet coat at specified mil thickness.
Roller: Roller application optional when environmental restrictions do not allow spraying. Use 3/8" or 1/2" (9.5 mm or 12.7 mm) synthetic nap covers.
Brush: Recommended for small areas only. Use high quality natural or synthetic bristle brushes.

CLEANUP

Flush and clean all equipment immediately after use with the recommended thinner or MEK.


*Values may vary with color.

WARRANTY & LIMITATION OF SELLER'S LIABILITY: Tnemec Company, Inc. warrants only that its coatings represented herein meet the formulation standards of Tnemec Company, Inc. THE WARRANTY DESCRIBED IN THE ABOVE PARAGRAPH SHALL BE IN LIEU OF ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES THAT EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. The buyer's sole and exclusive remedy against Tnemec Company, Inc. shall be for replacement of the product in the event a defective condition of the product should be found to exist and the exclusive remedy shall not have failed its essential purpose as long as Tnemec is willing to provide comparable replacement product to the buyer. NO OTHER REMEDY (INCLUDING, BUT NOT LIMITED TO, INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, ENVIRONMENTAL INJURIES OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS) SHALL BE AVAILABLE TO THE BUYER. Technical and application information herein is provided for the purpose of establishing a general profile of the coating and proper coating application procedures. Test performance results were obtained in a controlled environment and Tnemec Company makes no claim that these tests or any other tests, accurately represent all environments. As application, environmental and design factors can vary significantly, due care should be exercised in the selection and use of the coating. **FOR INDUSTRIAL USE ONLY.**

ROSS VALVE SUPPORT SERVICES

PROVIDES PERSONAL SERVICE IN EVERY PHASE OF DEVELOPMENT, INSTALLATION AND MAINTENANCE.

We are always available to provide answers to any questions. No sale is ever "final"



DEDICATED SUPPORT LINES

Sales engineers available Monday through Friday 7am to 5:00pm EST

Phone to help with any questions — (518) 274-0961

Fax machine – (518) 274-0210

After Hours Support – (518) 279-4373

E-Mail – sales@rossvalve.com



TRAINING

Factory Training — Ross Valve believes that our customers should know as much as possible about our products. That is why we periodically host Customer Training seminars at our Ross Technology Park in Troy, NY. Here, our customers learn the workings of the valves, how to correctly maintain them, and how they are manufactured.

In addition, Ross representatives are often in the field giving product seminars for your convenience.

FIELD SERVICE

When a repair, upgrade, or modification is required for an existing Ross Valve, Factory Authorized Ross Service Technicians offer the best service available, including:

Technical assistance for start-up or continuing training.

Fully inventoried service vehicles to allow replacement of necessary parts.

Confined Space/OSHA trained with latest equipment

On-site / hands-on training for your staff.

Ability to return older valves to "like-new" condition.

YEARLY CONTRACTS AVAILABLE

WARRANTY

All valves and materials are guaranteed free from defects for 1 year from the date shipped.

Ross Valves are economically rebuilt. Every internal part is replaceable through the top of the valve, without removing it from the line. All seals and internal packings are replaceable, which contributes to the valve's longevity.

Ross Valve stocks a wide variety of repair parts which can be received by the customer as early as the next day. In-house computer links track packages to ensure timely delivery.

Detailed historical record keeping gives us a full report of all maintenance or upgrades that have been made on each valve. This allows us to evaluate performance in the past and maximize performance in the future.



ROSS VALVE

Automatic Control Valves & Pre-Packaged
Vaults for Water & Wastewater

www.rossvalve.com

P.O. Box 595,

Troy, New York 12181, USA

Phone: (518) 274-0961 Fax: (518) 274-0210

E-Mail: sales@rossvalve.com