



Hay Trailer Maintenance Schedule

Year:

Trailer:

Purchase Date:

Item	Inspection/Service	Each Trip	Each Month	Every 6mo or 6,000 mi.	Every year or 12,000 mi.	Completed Y / N	Comments/Notes
Cleaning	<p>Remove any hay residue, dirt, or debris from the trailer cradle(s) and other areas using a broom or brush.</p> <p>Wash the trailer with water and mild soap to remove any remaining dirt or grime. Pay special attention to areas where hay may have accumulated, as this can lead to corrosion if left unchecked.</p> <p>Allow the trailer to dry completely before proceeding with further maintenance tasks.</p>	✓				Y / N	
Breakaway Brakes -Electric -Hydraulic	<p>Check Operation</p> <p>Check Operation</p>	✓			✓	Y / N	
Breakaway Battery	<p>Fully Charged,</p> <p>Connections Clean</p>	✓				Y / N	
Brakes -Electric -Hydraulic	<p>Check operation</p> <p>Check operation</p> <p>Check reservoir level</p>	✓		✓	✓	Y / N	

Item	Inspection/Service	Each Trip	Each Month	Every 6mo or 6,000 mi.	Every year or 12,000 mi.	Completed Y / N	Comments/Notes
Shoes & Drums	Adjust	✓		✓	✓	Y / N	
Safety Chains & Hooks	Check for wear & damage	✓		✓		Y / N	
Receiver & Hitch Ball	Check for cracks, pits, and flats. Replace w/ ball and receiver having trailer GVW Rating. Grease. Check locking device & replace when worn.	✓		✓		Y / N	
King Pin And Fifth Wheel	Check for cracks, pits, and flats. Replace w/ ball and receiver having trailer GVW Rating. Grease. Check locking device & replace when worn.	✓		✓		Y / N	
Tires	Check tire pressure when cold. Inflate as needed. Check for damage. Inspect tread and sidewalls thoroughly. Replace tire when treads are worn, when sidewall has a bulge, or sidewall is worn. Rotate every 5,000 Miles.	✓		✓		Y / N	
Wheels - Lug Nuts Or Bolts & Hub	Tighten. For new and remounted wheels, check torque after first 10, 25 & 50 miles of driving and after any impact.	✓				Y / N	

Item	Inspection/Service	Each Trip	Each Month	Every 6mo or 6,000 mi.	Every year or 12,000 mi.	Completed Y / N	Comments/Notes
Lubrication	Lubricate tilt deck pivot points (if equipped). Lubricate hydraulic cylinder ends (if equipped).		✓			Y / N	
Brakes, electric • Magnet • Controller (in tow vehicle)	Check wear and current draw. Check power output (amperage) and modulation.				✓	Y / N	
Brakes; All Types -Shoes & Drums	Check for scoring and wear. Replace per manufacturer's specifications.				✓	Y / N	
Jack, Drop-leg (if equipped)	Grease gears at top.				✓	Y / N	
Structure -Frame Structure -Welds	Inspect all frame members, bolts & rivets. Repair or replace damaged, worn or broken parts. Inspect all welds. Repair as needed.				✓	Y / N	
Wheels • Wheel Bearings • Rims	Disassemble / inspect / assemble and repack. Replace promptly if immersed in water. Inspect for cracks & dents. Replace as needed.				✓	Y / N	
Structure • Axle Attachment Bolts	Check BY DEALER				✓	Y / N	