

VT2 ELECTRONIC ADVANCE CLOCK

SETUP & OPERATION Rev. 7/7/2026

Make sure clock is pointing off & set in cabinet as you always would. Make sure your station switch below is in the proper position. With switch in manual, turn dial around once so it lands $\frac{1}{2}$ way between 11 & off.

Turn slide switch to automatic. Clock should advance to off & stop. Clock is now properly set.

Cycle start is accomplished either by central start signal or holding down toggle switch for a minimum of 3 seconds. Clock will advance to each station and park at end of cycle.

Stations may be cancelled or advanced to next station by moving manual slide switch off & on again. **WAIT 2 SECONDS BEFORE MOVING BACK TO AUTO.**

NOTE:

Moving dial by hand will disrupt exact timing & might result in stations not coming on.

If dial is disturbed or stopped between stations, repeat initial start procedure of placing between 11 & off and letting clock park. This will reset the timing.

If you need more time on a particular station, you could slide the switch to manual which would stop the clock from advancing. Moving back to auto would then restart the cycle and advance to the next station.

For technical assistance call: (732) 600-1352.

