

Compact  
Affordability



# Datacolor 110<sup>®</sup>



## **Rugged, Dependable Color Measurement**

- Affordable, Full-range Spectrophotometer
- Best Spectrometer in its class -SP2000
- Automated specular port (SCI/SCE)
- Small Enough to Fit in Any Workspace
- Automatic gloss compensation
- Easy maintenance

# 110<sup>®</sup> BENCH-TOP SPECTROPHOTOMETER

With the state-of-the-art Datacolor 110<sup>®</sup> your customer's vision becomes reality - reliably and economically.

## FEATURES

- Dependable performance at an affordable price
- State-of-the-art SP2000 spectral technology
- 256 dual diode array provides phenomenal spectral resolution
- Superior Dark End Stability
- Automated specular port (SCI/SCE)
- Small footprint single aperture device for easy use
- Three aperture sizes available
- Shared mastering with Datacolor 600 reference instrument for reliable supply chain performance



The compact 110 is one of the most powerful, versatile and affordable compact spectrophotometers you can buy. The 110 offers close inter-instrument agreement to the Reference-Grade Datacolor 600 Spectrophotometer, which is used by the world's leading Colorant manufacturers to formulate and control critical color.

## HARDWARE SPECIFICATIONS

	DATACOLOR 110 <sup>®</sup>
Instrument Type	Dual-beam d/8° spectrophotometer
Illumination Source	Pulsed xenon filtered to approximate D65
Sphere Diameter	51 mm / 2.0 in
Specular Port	Automated included or excluded
Specular Analyzer	Proprietary SP2000 analyzer with dual 256 diode array and high resolution holographic grating
Wavelength Range	400 nm to 700 nm, reporting at 10 nm intervals
Reporting Interval	10 nm
Photometric Range	0 to 200%
20 Read Repeatability*	0.05 (max DE CIELAB)
Inter-instrument Agreement*	0.20 (avg DE CIELAB)
Lens	3 position auto zoom
Single Aperture models	LAV (22 mm), SAV (9 mm) & USAV (6.5 mm)

\* Specification based on the following environmental conditions: 20° C; 50% RH; 2 sigma

WORK FLOW	Design	Photo	Cosmetics	Packaging	Ink	Home Entertainment	Automotive	Plastics	Paint & Coatings	Textile	Retail Paint
Create/Design											
Specify											
Formulate and Produce					■			■	■		■
Quality Control			■		■			■	■	■	■

For more information, please visit [www.datacolor.com](http://www.datacolor.com)

### STANDALONE SYSTEM REQUIREMENTS

CRT or LCD monitor, Pentium 3 or higher with Serial or USB connection available, CD Reader, Windows<sup>®</sup> 2000, XP Pro or Windows 7

Committed to Excellence. Dedicated to Quality. Certified to ISO 9001:2000 in Manufacturing Centers Worldwide. ©2010 Datacolor Inc. Datacolor and other Datacolor product trademarks are the property of Datacolor Inc. Windows is either a registered trademark of Microsoft Corporation in the United States and/or other countries.

**datacolor**