



Simplex Lock Changing Instructions

Step 1: Enter Current combo - Do Not Turn The Thumb Knob

Step 2: Typically you will find a Push Pin on the left side of the lock body, push this Push Pin in

Step 3: Release Pin on the side

Step 4: Clear combo by twisting Thumb Knob counter-clockwise

Step 5: Enter your new combo

Step 6: Twist Thumb Knob Clockwise to release the locking mechanism

Step 7: Reset The Thumb Knob & test your new combination before closing the lid of the unit

To our Valued Customers:

Thank you for the purchase of your safe. We hope that you are satisfied with your new purchase. If we can help you in any way or if you have any questions or concerns about your safe, lock, warranty, or dri-rod please feel free to call:

Able Safe at (989)879-5477

Thank you.

Sincerely,

Your Able Safe Sales Team.

