



Getting Started with Your Hypex UcD400 Amplifier (assembled by Deer Creek Audio)

Please take a moment to review the following details on your new Hypex UcD400 Amplifier, assembled by Deer Creek Audio.

What's Included

- Assembled amplifier
- Printed test results
- Power cord
- Allen wrench for front cover

Break-in period

When you first turn on the amplifiers, allow approximately 60 minutes warm-up time before critical listening. After the amplifiers have broken in for several hours, the starting warm-up time should be approximately 10 minutes.

Amplifier gain setting

Amplifier voltage gain is fixed at 26 dB typical.

Installation

Be sure to install your Hypex Class D amplifier with adequate ventilation. You'll need at least one inch on top of the unit, preferably with an open front and rear.

Be sure to check out our Tech Blogs, Tech Videos and other Resources on deercreekaudio.com for the latest technology news and updates.

staff@deercreekaudio.com

720.726.9272