



**FOOD SAFETY SCIENTIFIC
AUSTRALIA PTY LTD**

PO Box 203, Baulkham Hills NSW 1755

T: +61 2 9674 2057 E: info@fssaust.com.au

FSSA

INNOVATIVE FOOD SAFETY SOLUTIONS

Digital Probe Thermometer

Model: Pocket Temp Pro

Digital thermometer with reduced tip & silicone sheath

Professional digital probe thermometer with many features which are required, and asked for, by people working in the food & medical industries. Each unit has a unique serial number printed on the side of the head of the unit (not hidden under the battery cover so that it can't be seen!). This is to help control the traceability of the unit - once the serial number is recorded you can track who the unit was allocated to and when it was last calibration checked. Accurate records can then be kept.

It has a food grade stainless steel probe with a reduced probe tip for fast temperature response. Comes with a protective silicone boot or sheath which provides extra water resistance when fitted to the head of the unit. HACCP Approved as it meets all of the requirements of the Australian & New Zealand Food Standards Code. The Pocket Temp PRO is dishwasher safe & can therefore be used to record dishwasher temperature. Perfect for use by anyone in food, aged care, hospital or hospitality industry.



Head of the Pocket Temp PRO with the silicone sheath fitted for extra water resistance.

SPECIFICATIONS

Temp Range	- 50°C to +300°C
Probe	120 mm Stainless Steel
Functions	Max/Min & C&F switchable
Accuracy	0.6°C between -20 ~ +100°C,
Serial number	Unique number on the side
Waterproof	Silicone sheath
Battery	CR2032 x 1 (included)

