

Step 1: Incisal Edge Photo



- Slightly angle the camera downward.
- Capture incisal edges clearly.
- Include adjacent teeth for reference.
- Place both tabs in the same vertical plane as tooth.
- Keep tabs parallel to the facial surface.

Step 2: Comparison Photo



- Select two to three candidate shade tabs that closely match the tooth.
- Place both tabs in the same vertical plane as tooth.
- Keep tabs parallel to the facial surface.

Step 3: Missing Tooth Site Photo



- Place shade tab in missing tooth space.
- Align tab in same plane as adjacent teeth.
- Keep tab parallel to the facial surface.

Step 4: Full Smile Photo



- Capture full smile including lips
- Ensure teeth are well exposed

Recommended Equipment & Settings

Recommended Equipment	Camera Settings	Tips
DSLR Or Mirrorless Camera	ISO: 100-200	Take photos in shaded area outdoors if possible.
Macro Lens (100mm Recommended)	Aperture: F/22 - F/32	Position Patient Upright
Twin Dual Flashes	Shutter Speed: 1/125 - 1/160	Remove Colored Lipstick