

# A Walk Around Tour of the Sanosil Halo Fogger



HFBS24ENA\_D

Become familiar with the parts and features of the Sanosil Halo.



**Rear Handle**

**High Precision Nozzle**

Ionized mist of disinfectant is dispersed via the nozzle.

**Timer Dial**

Turn the dial to set time for fogging treatment.

*Fogging Time Chart can be found on page 9 of Halo User Manual and on the rear panel of the Halo device.*

**Start Button**

Press and hold for 2 seconds to start room disinfecting.

**Disinfectant Fluid Level Indicator**

Shows how much disinfectant is in the reservoir and when it is time to refill.

**Reservoir Door**

Push and flip open for easy access and refilling.

**Front Handle**

**Status Indicator Light**

**Reservoir Door**

**Funnel Opening**

Use care to avoid splashing when pouring disinfectant.

**Large Wheels**

For easy maneuvering.

**Power Cord Connection**

Insert the power cord into the receptacle located on the rear of the Halo.

For more information, please contact

**MED EFFECT**  
INCORPORATED

(800)-472-5605

**Sanosil** | **AUTHORIZED RESELLER**  
Surface Disinfection Products