

ce200-white™ is an Ultra-High Performance Concrete (UHPC) developed at ceEntek Pte Ltd, Singapore, containing white cement, finely graded sand and other carefully selected components.

MIX COMPONENTS

1. ce200-white™ premix
2. cePBA1-385S (Admixture paste)
3. Potable water

MIX COMPONENTS QUANTITIES

Table 1 outlines the weight of each mix component used in the mixing of ce200-white™, for a typical batch sized in an IMER Mortarman 750 planetary mixer or equivalent planetary mixer.

The values below have been determined in order to simplify the weighing of components, as much as possible. In order to ensure the batch is mixed properly, a single batch requires a given weight of ce200-white™, based on the mixing capacity of the high-shear mixer used and the desired plastic properties of ce200-white™. When mixing a different volume than the volume in Table 1, each substituent weight is to be adjusted and verified by a ceEntek Technical Representative.

Table 1: Material quantities per 300 kg batch of ce200-white™

Mix Component	kg/m ³	lbs/yd ³	kg	Lbs
ce200-white™ premix	1995.6	3363.7	266.1	586.7
cePBA1-385S	38.8	65.4	5.17	11.4
Potable water	215.7	363.6	28.8	63.5

STORAGE AND SHELF LIFE

ce200-white™ Premix: Premix bags must be protected from moisture, freezing, and kept dry at all times. Unopened bags of ce200-white™ Premix have a shelf life of 6 months.

cePBA1-385S: cePBA1-385S must be stored in a dry place and be protected from sun and freezing. Unopened pail of cePBA1-385S has a shelf life of 6 months.

PROCEDURES

Mixing: Mixing ce200-white™ requires a high shear mixer and qualified personal on-site. The number of mixers should be adjusted to reduce the waiting time between batches, depending on the volume of material to be placed. Since a wheelbarrow or buggy will be used to transport the fresh material to the pouring location, the mixers must be raised high enough to ensure that it discharges properly. A platform can also be used next to the mixer to allow workers to batch properly and safely. The mixer should be kept as clean as possible between batches in order to guarantee the performance of subsequent batches.






Mixing Sequence: The following mixing procedure has been developed and tested thoroughly at an ambient temperature of 25 ± 1 °C when using an IMER Mortarman 750 planetary mixer or equivalent planetary mixer. The mixing procedure may be adjusted to better suit the temperature conditions, based on the recommendations of a ceEntek Technical Representative. Prior to the batching operation, the mixer must be inspected and cleaned so that no foreign material impacts the fresh ce200-white™ mixing.

Different models of high-shear mixer have successfully been used to batch ce200-white™. Refer to ceEntek Technical Representative to use a different high-shear mixer.

Table 2: Mixing procedure for ce200-white™

Step	Component to Introduce	Action	Mixer Speed	Start (mm:ss)	End (mm:ss)
1	ce200-white™ premix	Introduce ce200-white™ premix the mixer			
2	cePBA1-385S and potable water	Dilute cePBA1-385S with potable water to form paste suspension			
3	paste suspension	Slowly introduce the paste suspension into the mixer during mixing	Medium	00:00	01:00
4	-	Mix	Medium	01:00	05:00

Table 3: Precautionary measures

Cautions	
<p>1. All personnel involved in mixing operations are required to adhere to the PPE requirements as below.</p>	 <p>Hard Hat</p>  <p>Safety Glasses</p>  <p>Hand Protection</p>  <p>Foot Protection</p>  <p>Dust Mask</p>
<p>2. Make sure that the inside of the mixer has been pre-dampened slightly (remove any excess water) prior to the preparation of every batch on each batching day.</p>	
<p>3. The time to complete steps 1 to 4 outlined in the mixing sequence of Table 2 above may vary and must be validated by a ceEntek Technical Representative.</p>	
<p>4. Cover the mixer with plastic during mixing to help control dust emissions or alternately, use a dust collector mounted over the mixer.</p>	
<p>5. Clean and dry the mixer as best as possible between batches in order to help ensure consistency between batches. Remove any build up excess material on the mixer or mixing blades.</p>	

CURING

The curing of ce200-white™ is essential in obtaining the necessary mechanical and physical material properties. In order to properly cure the material, the contractor must cover the fresh material with formwork plywood, or plywood wrapped in a plastic film, immediately after pouring. Covering the material quickly after pouring prevents the top surface of the material from drying out. The ce200-white™ is demolded after 24 hours of casting and water-cured at approximately 23 °C (73 °F) in a humidity-controlled chamber.

MECHANICAL, DURABILITY AND TIME DEPENDENT PROPERTIES OF ce200-white™

The following data is representative of typical values achievable under laboratory conditions. Results in the field may vary.

Table 4: Mechanical properties of ce200-white™

Mechanical properties	Curing ages (day)	Parameter	Mean values (Standard deviation)	
			SI Unit	US Unit
Compressive strength ¹	28	$f_{c,28}$	128.1 MPa (2.6 MPa)	18579 psi (377 psi)
Flexural tensile strength ²	28	$f_{r,28}$	21.3 MPa (0.8 MPa)	3089 psi (116 psi)
Direct tensile strength ³	28	$f_{t,28}$	6.3 MPa (0.8 MPa)	914 psi (116 psi)
Static modulus of elasticity ⁴	28	E_c	39.1 GPa (0.1 GPa)	5671 ksi (15 ksi)

Table 5: Durability properties of ce200-white™

Durability properties	Mean values (S.D.)
Water absorption ⁵	0.667% (0.058%)
Chloride ion penetration ⁶	88 coulombs (2 coulombs)

Notes	
1	Compressive strength tests in accordance to BS EN 12390-3: 2009
2	Flexural tensile strength tests in accordance to ASTM C348: 2014
3	Direct tensile strength tests in accordance to ASTM C307: 2012
4	Static modulus of elasticity tests in accordance to ASTM C1856 and ASTM C469
5	Water absorption tests in accordance to BS 1881-122: 2011
6	Chloride ion penetration tests in accordance to ASTM C1856 and ASTM C1202