

2065-2 Cath Adapter Instructions.

Initial Setup

1. Insert rounded end of the cath adapter into the breather tube just enough to get the balloon in tube.
2. Using syringe inflate with water until the balloon fills to just touch the side of tube.
3. Empty the rest of the unused water out of syringe.
4. Using the syringe pull the water out of the balloon.
5. Make note of how many milliliters of water were needed to fill the balloon to the proper size.

General Use

1. Insert rounded end of cath adapter into breather past "ice hole".
2. Insert foam wedge along side of adapter to hold in place.
3. Using syringe fill adapter with proper amount of water as determined in the initial setup.
4. Remove adapter by using the syringe to remove water from adapter and then remove foam wedge and carefully pull adapter out.

Note:

Use care not to overfill adapter this can cause balloon to rupture.

It is advisable every so often to recheck the initial set up. As the balloon is filled and emptied it may stretch and cause its water need to change slightly.