



Assessment of hazards from loss of containment of LH2: Progress towards experimental tests on BLEVE with a shock-tube

A. Friedrich, S. Gabriel, T. Jordan, J. Knebel, N. Kotchourko, M. Kuznetsov, J. Rietz
L. Rudy , E. Torres de Ritter

ELVHYS International Stakeholder' Seminar, Bologna, Italy

E. Torres de Ritter (KIT)

30.09-01.10.2023



Co-funded by
the European Union



UK Research
and Innovation

KIT- ITES- H2 Department



ENERGY


EARTH and ENVIRONMENT

MATTER


INFORMATION



KIT- ITES- H2 Department




Institute for
Thermal
Energy Technology and
Safety



KIT- ITES- H2 Department

H2 Technology
Prof. Thomas Jordan




KIT- ITES- H2 Department



KIT Experimental Tasks 4.3.1

❑ Task 4.3 Performance of LH2 components and explosion consequences (Lead partner: **KIT**)

❑ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)



BLEVE : Boiling Liquid Expanding Vapor Explosion

The effect depends on a sudden phase change from liquid to vapor that might occur during a loss of containment.


We proposed to replicate this loss of containment using a shock tube, that consists in a tube with a calibrated rupture membrane.

Phenomena will be analyzed in inert atmosphere (rich in N2) and in air with ignition.

KIT Experimental Task 4.3.1


□ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)

- Dimensions: L=1000 mm; D=50 mm
- Hydrogen inventory: 68 – 93 g (h≈750 mm)
- P = 5.3, 8.5, 11.6, 14.8, 18, 21.2, 24.4, 27.6 bar
(preliminary values, definitive pressures after tests, not all will be used)
- T_i = 20 K (only initial T known ->heating)



KIT Experimental Task 4.3.1

□ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)



Internal measurements (cold):


- Dynamic pressure (5 positions along the tube)
- Static pressure (1 static in tee)
- Differential pressure (prototype to be tested)
- Temperature (5 positions along the tube: diodes & thermocouples type K)
- interface position (optical and thermos diodes)
- Optic sensor (prototype to be tested)

Procedure in Shock Tube

- Filling with LH2 up to exhaust level
- Heating up with wall heaters (outside)-> P rise
- Constant inventory, isochoric process
- Burst pressure regulated with burst membrane thickness
- Inventory sectioned with cryogenic check valves to minimized piping effect

KIT Experimental Task 4.3.1

□ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)




Observations:

- Vacuumized valve tank
- Two parts tank to put it upside down
- Angled insertions in/out
- Easy to manufacture
- Design 100% defined

KIT Experimental Task 4.3.1

□ Sub task 4.3.1 **BLEVE tests with a shock tube** filled with LH2 in an A2 vessel (Lead: KIT)




Observations:

- Vacuumized valve tank
- Two parts tank to put it upside down
- Angled insertions in/out
- Easy to manufacture
- Design 100% defined

KIT Experimental Task 4.3.1

❑ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)



- Vacuumized valve tank
- Two parts tank to put it upside down
- Angled insertions in/out
- Easy to manufacture.

Design 100% defined

Calculation of mechanical resistance of the shock's tube final design. **Iteration concluded (FEM)**
In construction in KIT Central Workshop
Procuring of peripherals (cryogenic)


Some challenges:

- Sealings:** Capton, Aluminium membrane, Helicoflex
- Glass fiber holder** KIT R&D

KIT Experimental Task 4.3.1

□ Sub task 4.3.1 **BLEVE tests with a shock tube** filled with LH2 in an A2 vessel (Lead: KIT)

MS16 P&ID / design drawings and experimental set up photos



- Vacuumized valve tank
- Two parts tank to put it upside down
- Angled insertions in/out
- Easy to manufacture

Design 100% defined

Calculation of mechanical resistance of the shock's tube final design. **Iteration concluded (FEM)**
In construction in KIT Central Workshop.
Procuring of peripherals (cryogenic)


Some challenges:

- Sealings:** Capton, Aluminium membrane, Helicoflex
- Glass fiber holder** KIT R&D

KIT Experimental Task 4.3.1

□ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)

A2 and BOS



4 Kameras / Winkel 70,7°

- **Outer measurements** inside A2 vessel (H=9 m, D= 6 m, V=220 m³):
 - Dynamic pressure (5 positions)
 - Static pressure (1 position)
 - Temperature sensors (approx. 3 positions)

- **Outer video recording** (BOS +high-speed movie+ webcam)
 - 3 cameras 100 images per second covering the lateral side
 - 1 zenithal camera
 - 1 camera 10.000 images per second covering the region close to the membrane burst
 - 3 web cams for overall process

KIT Experimental Task 4.3.1

□ Sub task 4.3.1 **BLEVE tests with a shock tube** filled with LH2 in an A2 vessel (Lead: KIT)



PRETESTS

We selected pure Aluminium membranes 99,9% to be used as burst membranes:

- Already used in KIT H2 department
- Good repeatability
- Cheap and easy to manufacture in house

Pre tests necessary to check at low temperature and different configuration:

- Liquid N2
- Test different membrane providers
- Test P sensors
- Test T sensors
- Test of optical probes
- Test cameras setting



KIT Experimental Task 4.3.1



□ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)

PRETESTS

Outcoming results:

- Plates with different thicknesses tested successfully
- Manufacturer matters
- Repeatability is good
- Temperature affects less
- Fast camera and webcam setting and processing ready
- Optics photo gates showed preliminary good result


Thickness [mm]	0,1	0,2	0,3	0,4	0,5	0,6	0,7	0,8
P [bar]	5,3	8,5	11,6	14,8	18,0	21,2	24,4	27,6



KIT Experimental Task 4.3.1

□ Sub task 4.3.1 BLEVE tests with a shock tube filled with LH2 in an A2 vessel (Lead: KIT)


A2 and BOS (CoStudy processing)





Thank you for your attention

eugenio.ritter@kit.edu



Co-funded by
the European Union



UK Research
and Innovation

ELVHYS project No. 101101381 is supported by the Clean Hydrogen Partnership and its members. UK participants in Horizon Europe Project ELVHYS are supported by UKRI grant numbers 10063519 (University of Ulster) and 10070592 (Health and Safety Executive).

Disclaimer: Despite the care that was taken while preparing this document the following disclaimer applies: Funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or Clean Hydrogen JU. Neither the European Union nor the granting authority can be held responsible for them.