


INSTALLING BLINDSPACE®

STANDARD WALL MOUNT



SCAN FOR
WEB VERSION




INSTALLING BLINDSPACE®

STANDARD WALL MOUNT

NOTE: Millimeter precision is important for perfect end result. Boxes must be securely attached within ceiling or wall. System fixings are never supplied by Blindspace, installer to ensure their fixing are suitable.


PARTS



Wall Mount



Hinge



Cover




Splice Pins




Splice Plates


TOOLS




Screw Driver/Driller




Power Chop Saw




Tape Measure



Spirit Level



Countersunk Screws



Drill Bits





INSTALLING BLINDSPACE®

STANDARD WALL MOUNT

WALL MOUNT FIXING POINT




PREPARE THE PRODUCT




INSTALLING BLINDSPACE®

STANDARD WALL MOUNT






INSTALL WALL MOUNT






PREPARE COVER





HINGE



CLOSE BOX



OPEN BOX



INSTALLING BLINDSPACE®

STANDARD WALL MOUNT

FINISHED LOOK

