

### **Three Ways To Connect**

#### 1. Work With WiFi

#### 2. Work With Roter





Al Motion Sensor



2-Way-Audio



## **Install Free App**

Download APP: scan the QR code below to download and install. Register and login: open the "MySmartH" APP to register and login according to the prompts.









# Add The Device-Scan QR Code Mode

Make sure Wi-Fi is available and connected to the Internet.

-Connect the camera to the power, then system startup completed.

-Open "MySmartH" APP, press the'+' in the upper right comer of the main screen;

-choose "VideoSurveillance", click "Smart Camera" to add camera; and then click "Next step";



	14:25 -		14:25 -		14:25 🕫		<b>'III \$ @</b> )
	Cancel		Cancel		Cancel		
-If the mobile phone is not connected to wi-fi, please click "Connect to Wi-fi" ;	Select 2.4 GHz Wi-Fi Network and enter password. If your Wi-Fi is 5GHz, please set it to be 2.4GHz. Common router setting method				A Ensure tha	Adding device Ensure that the device is powered on.	
-It will jump to the WLAN interface and connects Wi- Fi.Please note that only 2.4 GH Wi-Fi network is supported;							
-If the phone is connected to Wi- Fi ; click "Confirm". It will jump to the interface to prompt to scan the QR code with camera and click "Continue" ; A QR code will prompt on your screen and you need to scan it with the Smart Camera, (the camera is about 20-30 cm away from the mobile phone lens). Then click "hear the prompt sound"."connecting" ;	€ 2.4 <sub>GHz</sub>	с С 5GHz	Please scan the QR code from cm away	n 15 to 20		Q 1%	
	Rest   Next	÷ ⊙	No Prompts I Heard a Prompt	20	Scan devices.	Register Initi on Cloud. the d	C) ialize device.

At this time, the connected device will appear on the APP home page . Then you can click directly to the device interface to see the monitoring situation

