





## Weekly SuperBooth Maintenance and Cleaning Procedures

Check to make sure Camera is in focus. [See manual for help.]
 Check printer tray alignments. [Bend the metal tray to align.]
 Empty print cutoff tray. [Remove little strips so the printer doesn't jam]
 Check to make sure buttons are tight.
 Use Ammonia-free cleaner to clean both the inside and outside surfaces of the SuperBooth.
 Use Ammonia-free cleaner to clean the acrylic screens covering the monitors and camera hole.
 Dust off the top of the SuperBooth.
 Vacuum the curtain to remove dust and dirt.