

INSTALLATION INSTRUCTION


✂ Accessories Checking

List of Standard Accessories:

Please double-check the accessory list below and contact our company or distributor if there are any discrepancies.

Remarks:




1. Accessories may be changed without prior notice, without affecting their performance.
2. Drawings are for reference only; actual product size and shape may vary.



Accessories list		
No.	Name	Qty
1	Faucet Body	1
2	Rubber Washer	1
3	Metal Washer	1
4	Mounting Washer	1
5	Screw	2
6	Water purification connector	1
7	Desk Plate	1
8	Manual	1


✂ Installation Instructions

1. Do not disassemble the main body, as it has been installed and commissioned correctly and precisely before leaving the factory.
2. To avoid the faucet from jamming, flush the water pipe before installation.
3. After installation, make sure every joint is safely sealed and there are no leaks.
4. Using condition: Working pressure at 0.05-1.0 MPa (including cold and hot water pressure), with applicable water temperature: 4°C-90°C.
5. Make sure to connect the hot and cold inlet pipes correctly. When standing in front of the faucet, connect the hot water pipe to the left and the cold water pipe to the right.
6. The mounting hole size is Ø35mm.




✂ Installation Procedures

1




1. Thread the body (1) through the base (7) and the Ø35mm hole.

2




2. Install the rubber washer (2), metal washer (3), and nut (4) onto the body in sequence. Then, tighten the nut (4) and lock the screw (5).

3





3. Insert the water purification hose into one end of the connector (6), and then install the connector (6) onto the water purification pipe of the faucet and clip it into the groove.

4





4. Attach the hoses to water supplies. The red hose should be connected to hot water, and the blue hose should be connected to cold water.

✂ Usage



1. While facing the faucet handle, pull the handle outward to turn on the faucet, or push it back inward to turn it off. Turn left for hot water and right for cold water.




2. When the handle is in the open position, press the button to switch between stream mode and spray mode. When the handle is closed, press the water purification switch to dispense filtered water, and press it again to stop the water flow.

✂ Cleaning & Maintenance

To keep the product clean and shining, please follow these steps:

1. Flush with clean water and dry with a soft cloth only.
2. If there is dirt, clean it with a mild liquid detergent or transparent glass cleaner.
3. Do not use any abrasive detergents, polishes, scouring pads, paper tissues, or scrapers.
4. Do not use acidic detergents, insoluble grain-based detergents, or soap.
5. Unscrew the aerator and clean it when necessary.



✂Note: The installation manual is for reference only. Our company reserves the right to make final modifications and interpretations.