

Part# 8100 RL

INSTALLATION

PASSENGER HEEL GUARD

FOR DRESSER AND ROADKING

TOOLS

3/16" Hex Key

Blue Thread Lock

NOTE

This product may not be compatible with all after market accessories or exhaust systems.

Take a moment to visually determine the potential for interference between the Passenger Heel Guard and existing parts on the motorcycle before attempting installation.

INSTRUCTIONS

1. Position Passenger Heel Guard on stock passenger footboard mount. The ends of the round rod should curve inward. The Heel Guard can be moved in or out along the mount base for personal preference with existing accessories.
2. Apply blue thread lock (not included) to screw threads.
3. Install the clamp and secure it with the two 1/4" - 20 x 1-1/4" socket head cap screws provided.
4. Make any final adjustments to Passenger Heel Guard's position and then tighten the clamp screws securely with a 3/16 hex key.