Ayrtekk Booster Pump




Diagram 1

External air source (i.e., an air compressor). Powers the Booster Pump by supplying 125 psi of low-pressure compressed air directly to the Booster Pump. Single Air Tank supplying high-pressure compressed air to be boosted.

Ayrtekk Booster Pump




Diagram 2

Single Air Tank. One Air Tank, using Tee, supplying high-pressure compressed air to the Regulator and high-pressure compressed air to be boosted. The Regulator converts high-pressure compressed air to 125 psi, low-pressure compressed air, to power the Booster Pump.

Ayrtekk Booster Pump




Diagram 3

Dual Air Tanks. One Air Tank supplying high-pressure compressed air to be boosted. One Air Tank supplying high-pressure compressed air to the Regulator. The Regulator converts high-pressure compressed air to 125 psi, low-pressure compressed air, to power the Booster Pump.