




# KEGEL KODE 3240 (40 UL TR)



|                    |                |                 |                            |
|--------------------|----------------|-----------------|----------------------------|
| <b>DISTANCE:</b>   | <b>40 FEET</b> | <b>VOLUME:</b>  | <b>24 mL</b>               |
| <b>RATIO:</b>      | <b>3.16:1</b>  | <b>FORWARD:</b> | <b>15.48 mL</b>            |
| <b>DROP BRUSH:</b> | <b>40 FEET</b> | <b>REVERSE:</b> | <b>8.52 mL</b>             |
| <b>TANKS:</b>      | <b>KEGEL</b>   | <b>PUMP:</b>    | <b>40<math>\mu</math>L</b> |




## FORWARD LOADS DATA

| # | START | STOP | LOADS | MICS | SPEED | BUFF | TANK      | DISTANCE | T.OIL |
|---|-------|------|-------|------|-------|------|-----------|----------|-------|
| 1 | 2L    | 2R   | 3     | 40   | 14    | 3    | A - Kegel | 0 → 4    | 4,440 |
| 2 | 5L    | 5R   | 4     | 40   | 14    | 3    | A - Kegel | 4 → 12   | 4,960 |
| 3 | 9L    | 9R   | 4     | 40   | 18    | 3    | A - Kegel | 12 → 22  | 3,680 |
| 4 | 13L   | 13R  | 4     | 40   | 18    | 3    | A - Kegel | 22 → 32  | 2,400 |
| 5 | 2L    | 2R   | 0     | 40   | 18    | 3    | A - Kegel | 32 → 33  | 0     |
| 6 | 2L    | 2R   | 0     | 40   | 26    | 3    | A - Kegel | 33 → 40  | 0     |

## REVERSE LOADS DATA

| # | START | STOP | LOADS | MICS | SPEED | BUFF | TANK      | DISTANCE | T.OIL |
|---|-------|------|-------|------|-------|------|-----------|----------|-------|
| 1 | 2L    | 2R   | 0     | 40   | 30    | 3    | A - Kegel | 40 → 23  | 0     |
| 2 | 13L   | 13R  | 3     | 40   | 14    | 3    | A - Kegel | 23 → 17  | 1,800 |
| 3 | 9L    | 9R   | 3     | 40   | 14    | 3    | A - Kegel | 17 → 11  | 2,760 |
| 4 | 5L    | 5R   | 2     | 40   | 14    | 3    | A - Kegel | 11 → 7   | 2,480 |
| 5 | 2L    | 2R   | 1     | 40   | 10    | 3    | A - Kegel | 7 → 6    | 1,480 |
| 6 | 2L    | 2R   | 0     | 40   | 10    | 3    | A - Kegel | 6 → 0    | 0     |



KEGEL PATTERN LIBRARY APP



PATTERNLIBRARY.KEGEL.NET



SCAN QR CODE TO  
SHARE AND  
DOWNLOAD  
THIS PATTERN

