







# Experimenters HMD Assembly Instructions




Assembly and use of the AR4 headset.  
Starts with basic unpacking of the headset,  
which comes in a folded state.




1. **Unboxing your headset:**  
Remove all parts from the shipping box - Main headset,  
phone holder, light shield, headband.




**Folding and setup:** Begin by removing the headstrap and unfolding the lower visor (a). Next, take the large sides (b) and fold them downward - they will meet with the inner flaps (c). All flaps have Velcro and will align with minimal effort. Once this step is complete, the headset is ready for the remaining parts.




3. Next install the lens (d) with the smooth side facing down. After this is the phone holder (f) This part resembles a Z when folded correctly. Insert Velcro down and black side facing in. Finally, pulling the nylon band tight completes the assembly.



3. Installing the phone: Peel back the nylon band and insert the phone with screen facing in toward the mirror. Close the nylon band.



4. Adding the light shield is as simple as removing the Velcro tape and installing to the front of the lower lens. This will block your view of the world and creates a dark screen inside the headset.



5. Adjusting headstrap & aligning the image is very simple. The headstrap attaches to the Velcro hook and enough material is provided to allow for angle adjustment. The goal is to have the image from your phone in the direct field of view.

\*\*Note: Place bottom edge of foam in line with your brow.

