

XX
A

PROCESS BOX

TO CALIBRATE THE REGEN HEATER THERMISTOR, REMOVE THE SAMPLE SCREW AND INSERT A EXTERNAL TEMPERATURE PROBE. FIND THE HOTTEST TEMPERATURE IN THE TUBE. LOOSEN THE BRASS FITTING AND MOVE THE THERMISTOR IN AND OUT UNTIL THE TEMPERATURE READ-OUT IS THE SAME AS THE EXTERNAL PROBE. SNUG THE FITTING ONTO THE PROBE.DO NOT OVER TIGHTEN THE FITTING.

TO CALIBRATE THE PROCESS, POKE A HOLE IN THE HOSE CONNECTED TO THE PROCESS BOX TO CHECK THE TEMPERATURE WITH AN EXTERNAL PROBE.

SYM.	AMT	PART NO.	DESCRIPTION
XX			
XXX			

THORESON McCOSH			
1885 THUNDERBIRD ST. TROY, MICHIGAN			
PH. 248-362-0960 FAX 248-362-5270			
SCALE	DATE	DR. BY	DRAWING NO.
NOT TO SCALE	00-00-00	GLK	XX