

# On Top Production Systems



## FiFi XL



OTPSYS introduces a new type of male sex cushion, called FiFi XL, designed to provide the ultimate sensation of having sexual intercourse. Unlike sex dolls and other sexual stimulation devices, the OTPSYS FiFi XL cushion is discreet and can be left around the house without anyone knowing. When those morning urges get you in the mood, just setup FiFi XL with its liner and apply heat. FiFi XL will give you a great workout. Afterwards, simply remove the liner and wash it off. Just set the cushion aside and not worry about someone finding your toys.

FiFi XL comes with a set of cushions, liner, heating unit and two types of lubrication. Options include different types of liners, leather versions and a support cushion. FiFi XL is a patent pending design with a special type of foam to provide the best sensation. Unlike a lot of the silicon rubber products, FiFi XL will last for years, even with heavy usage.

### Setup

The cushion has four parts a bottom, top, liner and liner strap. The bottom section is a firm cushion for support while the top is soft. The liner has a smooth surface and is used to wrap inside the cushion to create a pocket for you rocket. Use the liner strap to hold the liner in place by attaching to the bottom cushion.

The top and bottom cushions are attached together using Velcro. You may want to attach the top cushion so it sets slightly back from the bottom to improve the sensation.



## Supporting Platform

For best result make a supporting platform with a supporting cushion forming a “T” shape using pillows at the head end. The supporting cushion should be about 40”x14” and 3.5” tall. The purpose of this platform is to get FiFi XL off of the bed and to allow your legs to go around the supporting cushion. This helps to provide pressure to certain parts of your body to give you that extreme orgasm. This might even benefit your partner by you leaning new tricks.

## Attaching the Liner

Place a towel over the support platform and then place the liner face down. Now place the FiFi XL cushion upside down on top of the liner and wrap one end of the liner around the top of the cushion and secure it with the liner strap. The liner can be folded over the strap to secure it better.



## Heating the Cushion and Liner

Flip the cushion over and tuck the liner into the front part of the cushion to create a pocket. Use the included hair dryer to warm up the cushion and liner by placing the hair dryer between the liner and cushion. Move the hair dryer around to keep from getting the liner or cushion too hot.

A heating pad can also be used to warm up the cushion. The hair dryer is faster.



## Applying Lubricant

Once you have finished heating up the cushion, tuck the liner back in and set it up to the desired depth. Make certain it is not too hot.

There are two types of water based lubricants, one is a creamy type and the other is a clear and slippery. The creamy type works best on the liner and the clear on you.

## Finishing up

Now that you have it setup, make a go at it and enjoy. When done, just undo the strap on one side and slowly pull the bottom of the liner out and fold it over on top side, keeping the messy stuff inside. Now just take it to a bathtub and clean it with hot water. Try not to get the backside wet.