



Tired of Repetitive Lifting and Moving?

ReadyVote reduces the necessity of lifting an AutoMark, precinct ballot scanner, and ballot box up to eleven times to just once! That one time is when the equipment is received from the manufacturer at the warehouse. After initial receipt of the equipment, it will never need to be routinely lifted! The time, effort and money saved by using the AutoKart is dramatic.

Traditional Storage & Deployment Methods	Traditional Lifts	AutoKart Solution	AutoKart Lifts
Lift equipment from the manufacturer to storage units	1	Lift equipment from the manufacturer and load onto the AutoKart	1
Lift the equipment from the storage units to a table for maintenance	1	Maintenance may be performed while the equipment remains on the AutoKart	0
Lift the equipment back into storage units	1	Equipment remains on the AutoKart	0
Lift equipment from the storage units and load into cases or bags	1	Equipment remains on the AutoKart	0
Lift the cases or bags into the trucks for delivery to the precincts	1	Equipment remains on the AutoKart. Roll the AutoKart into the truck	0
Lift the equipment from the truck to the precinct	1	Equipment remains on the AutoKart. Roll the AutoKart from the	0
Lift the equipment from the cases or bags to the appropriate location at the precinct. Store the cas-	1	Equipment remains on the AutoKart	0
Once voting has ended, retrieve the cases or bags and lift the equipment from the precinct loca-	1	Equipment remains on the AutoKart	0
Lift the equipment cases or bags from the precinct to the truck for transport back to the warehouse	1	Equipment remains on the AutoKart. Roll the AutoKart into the truck	0
Lift the equipment and move back into the warehouse	1	Equipment remains on the AutoKart. Roll the equipment from the	0
Lift the equipment from the cases and bags to the storage units	1	Equipment remains on the AutoKart	0
Totals: Remember to multiply the lifts by the number of pieces of equipment	11	After initial delivery, you need not move the equipment to or from the AutoKart	1