SVBA Test Using the Mako MK5 5-Valve Test Kit

Step	Procedure	SARY	
1.	NOTIFY OWNER, identify, inspect, and observe assembly.		
2.	SETUP TEST		
	a. Remove air inlet valve canopy		
	b. Bleed water through the test cock		
	, , , , , , , , , , , , , , , , , , , ,		
	d. Attach bleed-off valve arrangement to test cock		
	e. Attach high side hose of MK5 to the bleed-off valve		
		Verify MK5 is turned on and captured values are cleared (Hold Down the Back Button)	
	g. Close all MK5 test kit valves		
	Note: Install appropriate fittings if necessary		
3.	BLEED AIR FROM HOSE		
	a. Open test cock		
	b. Open high side bleed valve of MK5		
	c. Note: To aid in determining the opening of the air inlet valve, the area on to	op of the	
	valve may be filled with the water from the bleed valve of MK5 d. Close the high side bleed valve		
	e. Close #2 shutoff valve		
	f. Elevate the MK5 Rate-of-Change Graph to same level as the vent valve		
	g. Close #1 shutoff valve		
4.	CHECK VALVE TEST		
4.	a. Slowly Open vent valve (loosening or removing screw)		
	b. Once flow of water from vent valve stops or is no more than a drip AND th	a reading	
	on MK5 stabilizes:	c reduing	
	c. RECORD psid reading (Press the Capture Button)		
5.	IR INLET VALVE OPENING TEST		
J.	a. Maintain the MK5 Rate-of-Change Graph at same level as the vent valve		
	b. Slowly Open the high side bleed valve no more than ¼ turn		
	c. RECORD psid reading (Press the Capture Button) when air inlet valve ope	ens	
	d. Close the high side bleed valve		
	e. Remove the high side hose from the bleed-off valve to drain water from the	ne body	
	f. RECORD whether the air inlet valve fully opens	•	
	g. Close test cock		
	h. Close the vent valve (replace screw)		
6.	REMOVE ALL EQUIPMENT		
	a. Slowly open #1 shutoff valve	MK5	
	b. Slowly open #2 shutoff valve		
	c. Replace the ai <mark>r inlet</mark> valve ca <mark>nopy</mark>		
	d. Remove all test equipment and fittings		
	e. Open the high, low, bypass valves and the high/low bleed valves;		
	drain water from hose(s)		
	f. Notify owner		
	g. Fill out test report		



