

# AC Collar Users Guide

The AC Collar is designed not only to provide a quick and easy way to get a consistent fit when using an electronic collar but it is also designed to protect the unit from impact and abrasions.

Tired of getting stopped by every person and their unruly, PP (un-trained) mutt who insists on proving their unsolicited advice on how NOT to train your dog? Our hide-a-way collar is the answer!

## How to Install your Electronic Collar Receiver

Remove the collar extender panel and adjust the collar to the approximate diameter of your dog's neck.

Next, on your eCollar receiver, unscrew the contact points from the posts exposing the threads. Run the 'wing tabs' through the collar keepers located on the sides of the receiver.

Fold the wing tabs back and press them to the Velcro loop on the collar.



Put the posts through the corresponding holes on the collar and then reattach the contact points

Take the elastic webbing loop and place it around the receiver so that it sits between the posts.

Attach the extender panel to the underside of the outer part of the collar to extend it so that it covers the receiver. Massage the Velcro hook to the loop to secure it.



Make the final adjustments to the collar fit. The collar should fit snugly, you should be able to fit no more than two fingers between the dog's neck and the collar.

Shift the collar side to side to ensure that there is good contact with the dog's skin. If your dog has a thick coat, you may need to purchase longer contact points.

**(NOTE: If the fit of the collar is too loose, this could cause the contact points to rub against the dog's skin which may cause irritation or blistering)**

# AC Collar Users Guide

To attach the Adventure Lights K9 Guardian light to the collar, begin by threading the collar strap through the long side of the belt clip, once there is enough material to hold on to, twist the material slightly and slide it into the opposing clip. Pull the collar through ensuring that the edges of the collar strap is retained by the railing of the base of the light.

**(NOTE: the AC XL is not compatible with this mount and can only be used with the specified mounting strap)**



Thank you for choosing Cerberus K9!

Each and every product we create, is designed around the feedback and needs of our customers. Our products are always evolving, and we rely on your input to ensure that our products remain relevant.

Have some ideas on how we can make our products serve you better? We would love to hear from you!

Please send an email: [info@cerberusk-9.com](mailto:info@cerberusk-9.com)

Have some photos of you using our products you'd like to share with us?

You can email us or tag us on Social Media @Cerberus\_K9 for a chance to win some free schwag and be featured on our page!  
#cerberusk9solutions

