

BLUEFIRE

De-Icing Torch 32inch Weed Torch

With Rubber Cover Handle

MRAS-8340B

Features:

- Self ignition
- Adjustable flame
- 32 inch reach
- Lightweight Aluminum arm
- Rubber wrapped handle for easy grip

Ideal for:


- Weed Killing
- Ice Melting
- Camp Fire Starter
- Lighting charcoal
- Driveway crack & joints filler use

Flame Type

**KILL WEEDS FAST
WITHOUT
HARMFUL CHEMICALS!**

**2012°F
1100°C**


MAPP Gas



Heat the plant



The plant dries up



The plant dies



⚠ DO NOT DROP, THROW OR ABUSE
⚠ KEEP OUT OF REACH OF CHILDREN
GAS CYLINDERS NOT INCLUDED

www.bluefireusa.com

Specification

Size :	200x37x815mm
Torch Weight :	414g
Heat temp. :	Max.1100°C
Consumption rate	181g/hr(2.6 KW)
BTU :	9600BTU/hr

READ ALL INSTRUCTIONS

IMPORTANT INFORMATION:

The instructions outlined below should be read carefully before using the appliance, and then keep it for further references. All the instructions given are needed to use the appliance properly, to keep it in good order, and to avoid risks. We accept no responsibilities for any damages occurred as a result of improper use of the torch or any modifications made to it.

Use only high quality propane gas cylinder.

1. PREPARING FOR USE

1.1 FITTING THE GAS CONTAINER

Turn the regulating control (3) in clockwise. Hold the gas container in vertical position and screw it in counter-clockwise onto the torch (fig.1) Screw the gas cylinder connection (4) in clockwise onto the gas cylinder Check for a good sealing

1.2 REMOVING THE GAS CONTAINER

Make sure the gas supply is shut-off by turning the regulating control (3) to the right. Unscrew the gas cylinder locking (4) in counter-clockwise to separate it from the gas cylinder. Then hold the gas container in vertical position and unscrew it in clockwise to detach it from the torch (fig.2) Safety measures Gas containers should be fitted or removed in well-ventilated areas, preferably in the open air, away from flammable substances or materials and incandescent sources of heat (such as flames, lighted cigarettes, hotplates, etc.), and AWAY FROM OTHER PERSONS OR ANIMALS. The appliance must not be used if the sealing o'ring or grommet is not in perfect condition or missing. Do not perforate or burn the gas container even when empty. For environmental reasons these containers should be disposed in designated fumaces or, preferably, be left in specific containers for subsequent recycling.

2. OPERATING INSTRUCTIONS

2.1 LIGHTING

Turn the regulating control (3) 1/4 to 1/2 circle in counter-clockwise to ignite first before adjusting the flame. Push the ignition button (7) and the flame will lit instantly. If turn all the way to the maximum, will cause flame out and difficult to ignite. Cautions: The appliance must be pointed downward (max 45°) all the time and away from people or animals.

2.2 ADJUSTMENT

Flame intensity may be adjusted by turning the regulating control (3) in clockwise or counter-clockwise.

2.3 WEED KILLING

Applying heat is a non-toxic and environmentally friendly way of destroying unwanted plants on pathways. This appliance is not suitable for use on flower beds or lawns. The weeds are heated from above and then dry out. The burner should be moved around gently. The aim is not to burn the plants, but to heat them up with the tip of the flame, and for this reason the appliance must be kept at an appropriate distance from the plants (fig.3) Stronger or woody weeds (wild grass, roots, etc.) must be exposed to heat for a longer period of time than common garden weeds. The process may have to be repeated after a few days.

Cautions

This Torch must be used in the open air, away from flammable substances and materials. OUTDOOR USE ONLY.

LIST OF COMPONENTS

1. Valve
2. Burner head
3. Regulating control
4. Gas cylinder connection
5. Handle
6. Tube extension
7. Ignition button



Always point the appliance downwards to avoid the flame flaring. If flaring occurs, move the gas container to the upright position for a few seconds. Do not work on wet ground.

Important! If the ground is excessively dry, there is a risk of cracking the surface. Do not leave the Torch unattended at any time. The use of defective or damaged appliances is dangerous.

2.4 TURNING OFF

Turn the regulating control (3) in clockwise until the flame is completely distinguished. Cautions: Certain parts of the appliance may reach high temperatures. Let the appliance cool down for some time after turning off and before putting it away. Important! The burning flame will stay lit for a short time after turning the appliance off until the residue fuel inside the tube burns out.

3. STORAGE

Separate the torch from gas container when not in use (fig.2). Keep the appliance and gas cylinder in a cool, dry and well-ventilated place.

Cautions

Keep the gas container away from direct sunlight. Never expose the container to a temperature of over 50°C. Keep it out of children's reach.

4. TROUBLE SHOOTING

Do not carry out any maintenance or repair works by yourself. Take the appliance to a specialized store for attention if a problem arises. Tampering with the appliance can result in serious outcomes.

4.1 GAS LEAKS

In the event of a gas leak (smell of gas), take the appliance outside or to a well-ventilated place immediately, where the leak may be checked.

4.2 CHECK SEALING

The appliance must be checked for sealing outside, well away from any flame, using soapy water or a special leak detection spray. Spray the area to be checked. Bubbles or foam will form if there is a leak.

4.3 CHECK GAS CONTENT LEVEL

Unscrew the gas container from the appliance (fig.2). Shake it to see whether the sound of the liquefied gas can still be heard.

Note: Some of the illustrations shown in this instruction manual may not correspond exactly with the appliance supplied. The manufacturer reserves the rights to make modifications without prior notice.

IMPORTANT!

1. Maintain a 5" gap between tip of Weed Torch and weed. Having Torch too close can cause flame to go out.
2. When igniting your Weed Torch, slightly open the valve. Once lit, you can adjust the flame as needed.
3. After each use, remove the torch head from the fuel canister for safety

⚠ WARNING: This product contains chemicals, including lead and lead compounds in brass fittings. It also produces combustion by-products when used. These substances are known to the State of California to cause cancer, birth defects or other reproductive harm

⚠ Wash your hands after using this product.

Contains lead. May be harmful if eaten or chewed. Complies with federal standards

⚠ WARNING: Keep out of children's reach

For more information go to www.p65warnings.ca.gov

SAVE THESE INSTRUCTIONS

www.aerosolgas.com



WEAR YOUR SAFETY GLASSES

MRAS-8340B NEW



8 50007 13921 6

Distributed by Aerosol Gas Company, Inc

Design in USA