

METHOD STATEMENT

SILK / MATT FINISH PAINT SYSTEM for WET AREAS

Area: Internal Walls and Ceilings (Wet Areas)

Substrate: Cement Plaster and Gypsum Board

Surface Preparation

- Ensure that the plastered surface is cured at least 21 – 30 days;
- Remove all loose particles, sharp edges, nibs etc., by abrading the surface with sand paper, scrapper, rubbing stone, etc.;
- Ensure that surfaces to be painted must be clean, dry, and free of dirt, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew;
- Make sure the moisture content is below 5% and well-ventilated before painting;

Coat System

Coat Stage	Product Code	Product Name	VOC (gm/ltr)	DFT (µm)	No. of Coats	*Drying Time/ Over coating Interval	Application Tool
Prep	6004	Omega Powder Filler			1	1 Hour	Stainless Steel Trowel
Primer	2112	Omega Unikyd Undercoat SB	366	55	1	12 Hours	Roller, Brush or Spray
Top Coat	4005	Omega Unicryl Pure Silk Emulsion WB OR	24	30	2	4 Hours	Roller, Brush or Spray
	4050	Omega Unicryl Pure Matt Emulsion WB	15	40	2	6 Hours	Roller, Brush or Spray

**High humidity and cool temperatures will result in longer dry, recoat and service time.*

For more information please refer Omega Paints Technical Data Sheets.