

# METHOD STATEMENT

## WATER SEAL COAT SYSTEM

**Area:** Internal and External Surfaces

**Substrate:** Plaster, Concrete, Masonry, Wood and Others

### Surface Preparation

- Ensure that the plastered surface is cured at least 21 – 30 days;
- Remove all loose particles, sharp edges, nibs etc., by abrading the surface with sand paper, scrapper, rubbing stone, etc.;
- Ensure that surfaces to be painted must be clean, dry, and free of dirt, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew;
- Make sure the moisture content is below 12% and well ventilated before painting;
- A layer of Fiber Mesh is required on top of the first “mist” coat. Allow to dry thoroughly before applying second and third “final” coats;
- Apply the second coat horizontally and the third coat vertically;

### Coat System

Coat Stage	Product Code	Product Name	VOC (gm/ltr)	DFT (µm)	No. of Coats	*Drying Time/ Over coating Interval	Application Tool
Mist Coat	4030	Omega Water Seal – 15% diluted with water	22	100	1	6 Hours	Roller, Brush, or Airless Spray
Fiber Mesh	N/A	Omega Fiber Mesh	-	-	-	-	-
Top Coat	4030	Omega Water Seal	22	100	2	6 Hours	Roller, Brush or Airless Spray

*\*High humidity and cool temperatures will result in longer dry, recoat and service time.*

*For more information please refer Omega Paints Technical Data Sheets.*