



DHS Back Table Set Up



- | | | | |
|--------------------------------|---|----------------------------------|--|
| 1. DHS Angle Guide on T-Handle | 5. Tap (<i>connect T-Handle from 1.</i>) | 9. 3.2 mm Drill Bit | 13. 3.5 mm Hex Screwdriver |
| 2. 2.5 mm Threaded Guide Wires | 6. DHS Lag Screw Insertion Wrench | 10. 4.5 mm/3.2 mm Drill Sleeve | 14. DHS Compression Screw
(<i>optional</i>) |
| 3. Direct Measuring Device | 7. DHS Plate | 11. Depth Gauge | |
| 4. DHS Triple Reamer | 8. DHS Impactor (<i>used with mallet</i>) | 12. 3.5 mm Hex Screwdriver Shaft | |


Assembling DHS Triple Reamer



1. 8.0 mm Drill Bit
2. DHS Reaming Head
3. Nut
4. Large Quick Coupling




5. Slide cutting end of Reaming Head over coupling end of Drill Bit
Set reaming depth before locking Reamer Head in place with nut



6. Properly assembled DHS Triple Reamer attached to Large Quick Coupling

Assembling DHS Lag Screw Insertion Wrench



- 1. DHS Coupling Screw, short
- 2. DHS Guide Shaft with Flats
- 3. DHS Lag Screw
- 4. DHS Centering Sleeve, long
- 5. DHS Wrench



II. Tabs of Guide Shaft sit in slots of the Lag Screw



III. Insert Coupling Screw into Guide Shaft, screw into end of Lag Screw



IV. Slide Centering Sleeve over the Wrench



V. Insert Guide Shaft/Lag Screw assembly into Wrench