Remote Mast

Motorized Microphone Stands

Installation and Operation Manual for Studio Stands




Caution

This RM stand has been intentionally packaged very tightly to protect it during shipment.

TO REMOVE <u>DO NOT PULL</u> ON THE UPPER MAST!!

This portion should never be used to move the stand. This may result in damage to the motor and will void the warranty.



Assembly Instructions for Studio Stands

- 1) Unwrap all items
- 2) Assemble the casters to the base using the included screws and hex wrench.
- 3) Mount vertical mast to the base using 5 hex screws provided. Firmly tighten the screws.



- 4) Assemble the upper shaft as shown below:
- 5) Use the side set screw to secure the swivel adapter to the vertical shaft.



6) Insert the vertical shaft into the main mast. Secure with the knurled handle



7) Assemble the counter weight on the end of the long boom arm .



- 8) Manually adjust the stand to the lowest setting you would like. The mast will travel 12" Vertically.
- 9) Plug your controller in to the base then plug in power adapter.
- 10) Setup is complete.



Control Box for Wired Stands





- Insert the Power Supply <u>DC plug</u> into the(PS) jack for Power IN.
- Connect 2 wires from stage (Mic Stand) to grey and orange connector.
- Insert the wire with the 1/4 Plug into the (OUT) jack for Power OUT.
- Press power button to turn on (Blue Light)
- The top Arrow should be for running the stand up and the bottom Arrow for Down. If this is not the case reverse wires at the grey and orange connector.

CAUTION—Continuing to press the rocker switch when stand is at its highest or lowest limit may eventually damage the flexible coupling between the motor and drive screw. Release the switch at the limits of travel.

Updated RF Controller System



RF Transmitter Range is approx. 100-150ft or 30-50meters
Optional magnet included for mounting option



Newer designs may be different than pictured.

Please contact us if you have any questions about the use of the RF system. info@futureswiss.com 860-507-9292

Remote Mast Warranty

To the original purchaser, we warranty this **Remote Mast** remote controlled microphone stand to operate correctly and efficiently raise or lower a microphone in a vertical plain or horizontal plain as applicable. If at any time within **Two Years** after date of purchase it should develop any defect *traceable to faulty workmanship or defective parts or materials*, we agree to repair or replace the defective parts without cost to the registered purchaser. This includes Stand, Manual Controller and Power Supply.

Shipping of stand is the responsibility of registered owner. This warranty does not cover normal wear of parts or materials or damage due to voltage surge, lighting surge, improper setup or misuse of product. We reserve the right to determine the nature of any failure.

Remote Mast Products div of Futureswiss International

Purchase Date:	
Model:	
Serial Number:	

Futureswiss International LLC 139 Center St Bldg 30 Unit 1 Bristol, CT 06010

> info@futureswiss.com 860-507-9292

When calling or emailing in reference to a problem please have your model and serial number available. Serial number is located under the base of the stand.

www.Remote-Mast.com