



# ADJUSTABLE INLINE SKATES OWNER'S MANUAL

THE FOLLOWING INSTRUCTIONS APPLY TO BOTH SKATE MODELS. PLEASE READ THROUGH CAREFULLY BEFORE USE.



YOUTH/JUNIOR  
ADJUSTABLE SKATE SIZES

**12-2**

**4 WHEEL**

**AGES 5+**

**MAX WEIGHT 85 LBS**



JUNIOR  
ADJUSTABLE SKATE SIZES

**3-6**

**4 WHEEL**

**AGES 5+**

**MAX WEIGHT 110 LBS**

## INCLUDES


- 1 x PAIR OF INLINE SKATES
- 2 x SHORT AXLE & BOLT
- 2 x ALLEN KEYS

## ⚠ WARNING

- **ADULT ASSEMBLY REQUIRED:** INLINE SKATES MUST BE ASSEMBLED AND ADJUSTED BY AN ADULT TO ENSURE ALL COMPONENTS ARE SECURE BEFORE USE.
- **DO NOT MODIFY:** ALTERING THE SKATES, INCLUDING REMOVING OR REPLACING COMPONENTS NOT RECOMMENDED BY THE MANUFACTURER, CAN COMPROMISE SAFETY AND PERFORMANCE. USE ONLY AS INTENDED.
- **LEARN TO BRAKE FIRST:** BEFORE SKATING, USERS MUST PRACTICE USING THE ATTACHED BRAKE TO STOP SAFELY. SKATING WITHOUT PROPER BRAKING CONTROL CAN RESULT IN FALLS OR COLLISIONS.
- **CHOKING HAZARD:** SKATES CONTAIN SMALL PARTS THAT COULD POSE A CHOKING RISK. KEEP AWAY FROM YOUNG CHILDREN AND ENSURE ALL FASTENERS ARE SECURELY TIGHTENED.
- **ALWAYS WEAR PROTECTIVE GEAR:** A PROPERLY FITTED HELMET, KNEE PADS, ELBOW PADS, AND WRIST GUARDS ARE STRONGLY RECOMMENDED TO REDUCE THE RISK OF INJURY IN CASE OF FALLS.
- **SKATE IN SAFE AREAS:** AVOID ROADS, STEEP INCLINES, WET OR UNEVEN SURFACES, AND HIGH-TRAFFIC AREAS. SKATING ON UNSAFE TERRAIN INCREASES THE RISK OF FALLS AND ACCIDENTS.
- **SUPERVISE YOUNG SKATERS:** CHILDREN SHOULD ALWAYS BE MONITORED WHILE SKATING, ESPECIALLY IN PUBLIC SPACES OR NEAR POTENTIAL HAZARDS.
- **CHECK SKATES BEFORE EACH USE:** INSPECT WHEELS, BRAKES, AND STRAPS FOR WEAR OR DAMAGE. ENSURE ALL FASTENERS ARE SECURE AND THAT THE SKATES FIT PROPERLY BEFORE SKATING.
- **AVOID SKATING AT NIGHT:** LOW VISIBILITY INCREASES THE RISK OF ACCIDENTS. IF SKATING IN DIM CONDITIONS, WEAR REFLECTIVE GEAR AND STAY IN WELL-LIT AREAS.
- **FOLLOW LOCAL REGULATIONS:** OBSERVE ANY LAWS AND SAFETY GUIDELINES REGARDING INLINE SKATING IN YOUR AREA TO ENSURE RESPONSIBLE AND LEGAL USE.


## ADJUSTING BOOT SIZE

1. LOCATE THE 'PUSH' BUTTON ON THE SIDE OF THE CHASSIS.
2. PRESS THE 'PUSH' BUTTON AND HOLD TO RELEASE THE REAR OF THE BOOT SO AS TO MOVE FORWARD AND BACKWARD TO MAKE SIZE SELECTION.
3. RELEASE THE 'PUSH' BUTTON ONCE CORRECT SIZE IS SELECTED
4. ENSURE THE REAR OF THE BOOT HAS LOCKED INTO CORRECT SIZE POSITION.




## FITTING THE SKATES (BEFORE FITTING THE SKATES, ENSURE YOUR CHILD IS SITTING DOWN SAFELY.)

1. PRESS THE RATCHET TO RELEASE THE ANKLE STRAP.
2. REPEAT FOR THE FOOT STRAP.
3. INSERT FOOT INTO THE SKATE.
4. SECURE BY INSERTING AND TIGHTENING BOTH STRAPS IN THEIR BUCKLES.



## CONVERTING SKATE FROM INLINE TO TRAINING

1. USE BOTH SUPPLIED ALLEN KEYS TO LOOSEN AND REMOVE THE AXLE BOLTS AND SHORT AXLES FROM THE REAR AND MIDDLE WHEELS.
2. REMOVE THE REAR AND MIDDLE WHEELS FROM THE CHASSIS.
3. INSERT THE LONG AXLE (SUPPLIED) THROUGH THE FIRST WHEEL, THEN THROUGH THE CHASSIS AND METAL SLEEVE (POSITIONED BETWEEN THE CHASSIS), AND FINALLY THROUGH THE SECOND WHEEL, ALIGNING IT WITH THE HOLES.
4. SECURE THE AXLE BY TIGHTENING THE AXLE BOLT WITH THE ALLEN KEYS.
5. CHECK ALL BOLTS ARE SECURE BEFORE USE.
6. STORE ANY REMAINING PARTS FOR FUTURE ADJUSTMENTS.



WWW.HALORISEABOVE.COM  
@HALORISEABOVE

MADE IN CHINA  
DISTRIBUTED BY GILLYBOO CORP  
2600 NE 11TH STREET SUITE #101  
BENTONVILLE, AR 72712



ALL COPYRIGHT TRADEMARKS, INDUSTRIAL DESIGNS, AND PACKAGING DESIGNS ARE OWNED EXCLUSIVELY BY GILLYBOO CORPORATION 2025. ALL RIGHTS RESERVED.