

ECU
REMAPPING

CARS/TRUCKS/TRACTORS
MODULES

MOTORBIKES
MODULES

POWER TEST
BENCHES



User manual

1 KRBEVO-156 / KRBEVO-156B

Applicability

Honda Africa Twin CRF 1100 20→24

Honda NT 1100 21→24

Precautions/Disclaimers


For the correct RAPID BIKE module function (later shortened to 'RB'), the motorcycle system must be intact and fully functional. Installation must be carried out by competent personnel and the supply conditions such as "Appendix 1" at the end of this instruction manual, must be read and accepted.

1.1 Preliminary operations

1. Switch off the engine.
2. Remove the driver and passenger seat.
3. Remove the fuel tank.

1.2 INJECTION and POWER SUPPLY Section

1. Locate and disconnect the 2 black and blue 2-pin connectors.




2. Connect the RB connectors to the injectors and the original wiring harness from left to right.

The order to follow is as follows:


INJECTOR 1 → Red/green wire → left injector.

INJECTOR 2 → White/black wire → right injector.



1.3 PICK-UP (CRANKSHAFT sensor) Section

1. Locate and disconnect the 3 -pin gray connector on the lower left side.



2. Strip the part of the cable near the sleeve and remove it to identify the yellow wire corresponding to pin 1.




ATTENTION

DO NOT use the yellow wire corresponding to pin 3.



3. Using the provided wire splice connector, connect the yellow wire of the RB wiring (marked 'CRANK SENSOR') to the previously identified yellow wire.




4. After the operation, carefully reposition the sleeve and tape the cables and RB wire tap securely to prevent water and dirt infiltration.

1.4 THROTTLE POSITION SENSOR (TPS) Section

1. Locate the 6-pin black connector on the right side.



2. Using the wire tap, connect the green wire from the RB wiring (labeled "TPS") to the blue/black wire of the 6-pin connector.



1.5 LAMBDA SENSORS Section


1. Locate the 4 -pin black connector on the lower left side.



2. Disconnect and insert the RB connectors (labeled " O2 Sensor 1 ") between the original connectors.



3. Locate the 4 -pin black connector on the right side near the engine.



4. Disconnect and insert the RB connectors (labeled " O2 Sensor 2 ") between the original connectors.



1.6 FINAL OPERATIONS

1. Connect the eyelet from the RB wiring to the negative pole of the battery.




2. Connect the wiring to the RB control unit.
3. Check that all connectors have been connected correctly.
4. Place the RB control unit in the passenger under-seat compartment.
5. Reposition the tank and the seats.

1.7 Accessories and Extras

This RB harness is designed for the use of any accessories:

- A. Connection (aux. 3 PIN) for powering and using optional accessories such as QS/Blipper electronic shifter, Pit-Lane limiter, and You_Tune.
- B. Connection for the use of the map switch (aux.black 2-PIN).
- C. CAN line connection (3 PIN) for communication with optional modules.
- D. USB connection (4 PIN) for PC or Bluetooth module.



ATTENTION

Connectors for unused accessories must be sealed with the provided caps.

1.8 Online functionalities

Useful links for:

Information: <https://www.dimsport.it/en/rapid-bike/>

Reserved area: <https://reserved.dimsport.com/login.aspx>

Online help: <https://reserved.dimsport.com/kb/Filemanager.aspx?id=1032>

Appendix 1

The User declares, under his own responsibility, that RAPID device is realized to be used only for competitive purposes in race track which is not open to the public. It is understood that the infringement of the aforementioned limitation may entail a sanctions infliction.

Without prejudice towards what is set forth in previous paragraph, if vehicle performances or characteristics, as indicated in vehicle registration certificate, were to vary, it is necessary to revise such vehicle registration certificate. Therefore, the User shall bring, under his own responsibility, such operations.

RAPID device allows the User to have access to some engine parameters (for example: turbo/manifold pression, rail, speed limiter, etc.). Changing such parameters might make the vehicle non in compliance with some power and/or speed and/or emissions standards of Your Country and also might determine a superior wear and tear of mechanical and electrical components of the vehicle, to the point that manufacturer's (or seller's) warranty might be considered void.

Dimsport Srl (except as set forth hereafter) does not grant any warranty and shall never be considered liable for any disruption that may derive from using RAPID device, in particular with respect to any extra wear and/or deterioration of the engine or of any other mechanical and/or electrical part of vehicle.

The reading and understanding of RAPID device Instructions must forerun the use of RAPID device (in all its parts).

If the User is a consumer of the provisions of D.lgs 206/2005 which concern the conformity, warranty of purchased items shall apply (in accordance with such D.lgs 206/2005, a consumer is a person that buy products outside from his business). Therefore, the consumer with no extra expenses, has the right to obtain the conformity restatement of purchased item, by its replacement or reparation. For this purpose, Dimsport must be informed about item non-conformity within 2 (two) months from the discovery of such non-conformity. This warranty covers the defects that come within 2 (two) years from the delivery. The normal "wear and tear" shall never be considered non-conformity. This warranty shall never be applied if the consumer alters RAPID device and/or if the consumer directly or indirectly repairs it and/or if the non-conformity is due to improper, negligent or imprudent use of RAPID device.

If the User is a professional user, Dimsport only warrants that RAPID device is free from manufacture defects for 2 (two) years from the purchase date, provided that the professional user is able to demonstrate such date by showing proper documentation.

UNDER NO CIRCUMSTANCES SHOULD RAPID DEVICE BE USED TO BREAK THE LAW OF THE COUNTRY OF USE OF THE VEHICLE. FAILURE TO COMPLY WITH SUCH PROVISION WOULD DETERMINE THE IMMEDIATE TERMINATION OF THIS AGREEMENT.

Without prejudice to mandatory law provisions, Dimsport Srl shall be relieved from any and all contractual and / or extra-contractual liability for personal injury; for direct and / or indirect damage (both with reference to emerging damage and loss of profit); for any claim and / or cost of any kind; which has been suffered by the User or by any third parties and which may derive from the use or misuse and / or may depend and / or in any case may be attributable to RAPID device, except in the case that those events may be attributable to Dimsport for wilful misconduct or gross negligence. The foregoing limitations and exclusions shall be applied to the maximum extent permitted by legislation in force in the User's jurisdiction.



Località San Iorio 8/B 15020
Serralunga di Crea (AL) - Italia
Ph +39 0142 9552 Fax +39 0142 940094
Mail: support.rapidbike@dimsport.it
www.dimsport.it/it/rapid-bike/