

TEC Boat Lift Controls

3411 Chenunda Drive

Wellsville, NY 14895

1-888-775-0545

Operating Instructions – All One & Two Motor Units

DO NOT OPERATE THE LIFT WHILE OCCUPIED

MAINTAIN VISUAL CONTACT WITH LIFT WHILE IN OPERATION

Turn power ON to the remote control. Push key "IN" and turn to "ON" position.
(Indicator light will be lit)

To lower or raise lift manually, push and hold the switch on RIGHT side of control unit Down/Up until desired level is reached or until the limit switch is reached (if equipped).

To lower or raise lift using the radio transmitter, push "Down" or "Up" button and hold until the desired level is reached. If equipped with Auto Control, auto control will take over and lower or raise lift until you push the Stop button or lift reaches level set by limit switch.

To turn the lights on controlled by the remote control, press the yellow Light Button once. The lights will remain on until you press the Light button a second time. The Lights will operate without the Key Switch Turned On.

To Level Lift (TEC II only), use switch on Left side (Level Control) to disconnect power to one motor and push Up/Down switch on right side to raise or lower until desired position is reached.

Stop Button or Auto Control Switch (A/C Units, if equipped) are used to manually STOP Up/Down travel of Lift.

WHEN NOT IN USE, TURN KEY SWITCH TO OFF POSITION, REMOVE KEY AND TURN OFF THE POWER TO UNIT. FAILURE TO TURN OFF POWER TO UNIT COULD RESULT IN DAMAGE TO THE UNIT AND COULD VOID YOUR WARRANTY.

Check our Website TECRemotes.com for additional information, Spare/Replacement Parts, and Warranty Registration.

TEC Remotes Limited Warranty

General

All Controls are pre-tested for proper operation before shipping.

TEC Remotes will furnish a replacement control in the event of failure or will furnish a replacement part for any part that fails in normal use and service within the applicable Warranty Period below, in accordance with the terms of this warranty. TEC replacements will be warranted for only the unexpired portion of the original warranty.

The Effective Date

The Effective Date is the date of installation if properly documented; otherwise it is the date of manufacture plus 30 Days.

Warranty Period

If any part fails within TWO YEARS after the effective date, TEC will repair or replace that part.

The Warranty Will Not Apply:

1. to defects or malfunctions resulting from failure to properly install, operate or maintain the unit in accordance with the printed instructions provided;
2. to damage from abuse, accident, fire, hurricane, and the like;
3. to units not installed in accordance with these instructions, applicable local codes, ordinances and good trade practices.

Service Labor Responsibility

The warranty does not cover any labor expense for service, removal or re-installation. All such expenses are the owners responsibility.

Miscellaneous

In most cases, your contractor should be able to promptly take the necessary corrective action and, thereafter, notify us of the in-warranty claim. However, any replacements are made subject to validation by us of in-warranty periods specified above.

We suggest you immediately complete the information below and retain this Warranty Certificate in the event warranty service is needed. Reasonable proof of the date of installation must be presented; otherwise the effective date will be based upon the date of manufacture plus Thirty Days.

Name _____ Dealer _____

Address _____

Model Number _____ Serial Number _____

We would like to take a moment to tell you that we value your business and thank you for purchasing a product manufactured by TEC Remotes.

Should you need information or parts assistance, please contact us at our Toll Free Number (888-775-0545). Please have your serial number (found on the exterior bottom of the enclosure or inside on the bottom by the radio receiver) ready before you call. Do Not Return the Unit until instructed by a service technician and obtaining a RMA Number.