



Forward thrust shoulder adjustment – All Dunn Designs

By Patty Dunn


Make this adjustment if your tops pull to the back or you have fullness in the back neck across the shoulders.




TRACE the front pattern piece. Mark $\frac{1}{8}$ " or $\frac{1}{4}$ " down from the outside shoulder point.




Pivot the pattern from the neck shoulder point and match the shoulder to the marked point. Trace



TRACE the back pattern piece. Mark $\frac{1}{8}$ " or $\frac{1}{4}$ " (this measurement is the same as the front change) above the outside shoulder point.



Pivot back pattern piece at the neck shifting the pattern up to match the marked line. Trace.



Pin shoulder and side seam together. The back shoulder seam will pull to the front. Mark the folded point of the shoulder (this will not be your seam line) You will match this point with your center sleeve mark. These marked points are important so the sleeve will hang on grain.